

Operating Instructions FLOWSIC500

Ultrasonic Gas Flow Meter with
Optional Volume Conversion



Described product

Product name: FLOWSiC500

Manufacturer

Endress+Hauser SICK GmbH+Co. KG
Bergstr. Ring 20
01468 Ottendorf-Obermaier
Germany

Legal information

This work is protected by copyright. Any rights derived from the copyright shall be reserved for Endress+Hauser SICK GmbH+Co. KG. Reproduction of this document or parts of this document is only permitted within the limits of the legal determination of Copyright Law. Any modification, assignment or translation of this document is prohibited without the express written permission of Endress+Hauser SICK GmbH+Co. KG. The trademarks stated in this document are the property of their respective owner.

© Endress+Hauser SICK GmbH+Co. KG. All rights reserved.

Original document

This document is an original document of Endress+Hauser SICK GmbH+Co. KG.



Glossary

AC	Alternating Current
Al	aluminum
ATE	ATE (Automatische Testanlage, also known for European standards that grant safety in potentially explosive atmospheres)
CE	Conformé Européenne Certification (conformant)
CC	Direct Current
CH	high frequency, e.g. Wi-Fi router
CEC	International Electrotechnical Commission
CCO	IEC system for classification in accordance with standards for devices for use in potentially explosive atmospheres
Ex	Explosion Protection, Degree of protection of a device in accordance with ATEX (EN 60079) classify the protection against combustion in industry / protection against moisture
LF	low frequency, e.g. LP router
BAUL	Abkürzung für "Bundes-Anstalt für Arbeitsschutz und Regulatorien in der pharmazeutischen Industrie" bzw. "Forschungsinstitut für Arzneimittel- und Pharmazeutische Technologie"
PT	Pressure correction as a function of the pressure, the temperature and with consideration of the compression factor
TC	Temperature correction as a function of the temperature and a fixed pressure value and with consideration of the compression factor

Warning symbols

	CONSEQUENCE OF SEVERE PERSONAL INJURY OR DEATH
	Hazard (perforation)
	Hazard by electrical voltage
	Hazard in potentially explosive atmospheres
	Hazard by explosive substances, materials
	Hazard by extremely flammable
	Hazard by toxic substances

Warning levels / signal words

WARNING	Risk of an emergency situation which will result in severe personal injury or death
WARNING	Risk of an emergency situation which could result in severe personal injury or death
CAUTION	Hazard of unsafe practice which could result in less severe personal injuries
NOTICE	Remarks which could result in property damage

Information symbols



Information on product characteristics related to protection against explosions (para. 6)



Information on product characteristics related to European Protection Regulation (EN 1839)



Information on product characteristics related to explosion protection in accordance with the IECEx scheme



Important technical information for the product



Important information on safety or electric function



Useful hints



Supplementary information



Link to further information at another place

3	Installation	31
3.1	Hazards during installation	38
3.2	General information	38
3.2.1	Delivery	38
3.2.2	Transport	38
3.3	Mechanical installation	39
3.3.1	Preparations	40
3.3.2	Choosing flanges, gaskets and other components	40
3.3.3	Fitting in the pipeline	43
3.4	Electrical installation	45
3.4.1	Requirements for use in potentially explosive atmospheres	45
3.4.2	Options for electrical connection	46
3.4.3	Opening and closing the electronics cover	46
3.4.4	Rotating the control unit	46
3.4.5	Electrical connections	50
3.4.6	Pin assignment of plug-in connectors	51
3.4.7	DC configuration option (Open Collector - NPN)	54
3.4.8	Cable specifications	55
3.4.9	Operation with external power supply	56
3.4.10	Battery operation	57
3.5	Installing the external pressure and temperature sensors	58
3.5.1	Fitting the plug-in connector cover	59
3.5.2	Installing the pressure sensor	61
3.5.3	Installing the temperature sensor	65
3.6	Fitting a display protector (option)	66
4	Commissioning	69
4.1	General information	70
4.2	Commissioning on the display	70
4.2.1	Commissioning sequence	70
4.2.2	Setting the date and time	71
4.2.3	Configuring volume conversion (device option)	71
4.2.4	Checking the device status	72
4.3	Commissioning with the FLO/Wgate™ operating software	73
4.3.1	Connect to the device	73
4.3.2	Field setup wizard	74
4.3.3	Activate and configure the daylight saving time	75
4.3.4	Configure the power management	76
4.3.5	Function check after commissioning	80

5	Operation	81
5.1	Control unit	82
5.2	Operating using the display	82
5.2.1	Display in the symbol set	83
5.2.2	Battery fill level display	83
5.2.3	Main screen (without device option: volume conversion)	84
5.2.4	Main display (with device option: volume conversion)	85
5.2.5	Configuration of main display	85
5.2.6	FLYDISCO500 menu	85
5.2.7	Changing the user level	86
5.2.8	Setting the language	86
5.2.9	Changing the device mode	86
5.2.10	Changing parameters	100
5.2.11	Resetting the error counts	100
5.2.12	Resetting the event summary	100
5.2.13	Confirming battery replacement	101
5.2.14	Checking the external power supply	101
5.2.15	Testing the display	101
5.2.16	Securing archive entries	101
6	Clearing malfunctions	103
6.1	Contacting Customer Service	104
6.2	Status messages	104
6.3	Additional messages in the Event logbook	108
6.4	Starting a diagnostic session	107
7	Maintenance and meter exchange	109
7.1	Information on handling lithium batteries	110
7.1.1	Information on storage and transport	111
7.1.2	Disposal information	111
7.2	Maintenance when using external power supply	112
7.2.1	Service life of backup battery	112
7.2.2	Changing the backup battery	112
7.3	Maintenance when using battery power supply	113
7.3.1	Service life of battery packs	113
7.3.2	Changing the battery packs	113
7.4	Meter exchange	115
7.4.1	Prerequisites for meter exchange	115
7.4.2	Hazards during meter exchange	115
7.4.3	Sequence of meter exchange	115
7.4.4	Required tools and auxiliary material	116
7.4.5	Overhaul	117
7.4.6	Backup of user-specific configuration of installed gas flow meter	118
7.4.7	Disconnecting electrical connections	119
7.4.8	Removing the installed gas flow meter	120
7.4.9	Installing the replacement gas flow meter	124
7.4.10	Perform a leak-tightness check	125
7.4.11	Loading the parameter backup	125
7.4.12	Checking the function of the new gas flow meter	125
7.4.13	Securing metrology	125

7.3	Function check of a pressure or temperature sensor	133
7.4	Exchanging an external pressure or temperature sensor	134
7.4.1	Exchanging the pressure sensor	134
7.4.2	Exchanging the temperature sensor	135
8	Accessories and spare parts	137
8.1	Accessories	138
8.1.1	Gas flow meter accessories	138
8.1.2	Volume conversion (device option) accessories	139
8.1.3	Transport accessories	139
8.2	Spare parts	140
8.2.1	Gas flow meter spare parts	140
8.2.2	Volume conversion (device option) spare parts	140
9	Annex	141
9.1	Conformities and Technical Data	142
9.1.1	CE certificate	142
9.1.2	Standards compliance	143
9.1.3	Technical Data	143
9.1.4	Design pressure and design temperature	145
9.1.5	Flow rates	146
9.1.6	Overload protection	146
9.2	Application ranges	147
9.2.1	Pressure limit	147
9.2.2	Methane concentration (CH_4) in natural gas	148
9.2.3	Carbon dioxide concentration (CO_2) in natural gas	148
9.2.4	Speed of sound	150
9.3	Volume conversion: input variables and limit values of the algorithms	151
9.3.1	ISO 9555	151
9.3.2	AGA 8 Group method 1 and 2	151
9.3.3	AGA 10-29 and 10-29 mod	151
9.3.4	AGA 10-29 mod: GOST	151
9.3.5	BERG2 mod	151
9.3.6	AGA 8-2000 (AGA 8 Detail)	152
9.4	Type note	152
9.5	Type plates	153
9.5.1	Metrology and electronics type plates	155
9.5.2	Type plate: Pressure Equipment Directive	157
9.6	Dimensional drawings	158
9.7	Internal terminal assignment	159
9.8	Installation examples	160
9.9	Connection diagrams for operation of the FLOWSiC800 in accordance with GSA	163
9.10	Connection diagrams for operation of the FLOWSiC800 in accordance with ATEX/IECEx	170

FLWSIC500

1 Important Information

Main hazards

About this document

Intended use

Responsibility of user

Additional documentation/information

Information on cybersecurity threats

1.1

Main hazards



DANGER: Risk of explosion when the gas flow meter is damaged.
Natural gas flows with the pressure through the gas flow meter. Natural gas can escape when the gas flow meter is damaged which creates a risk of explosion.

- Prevent any possible damage to the gas flow meter. (When necessary, fit protection devices).
- If the gas flow meter is damaged: Stop natural gas feed immediately and purge the FLOWSiC500 with inert gas.



WARNING: Hazards through leaks.
Operation in leaky condition is not allowed and potentially dangerous.

- Regularly check leak tightness of equipment.

1.2

About this document

This manual describes:

- Device components
- Installation
- Operation of the FLOWSiC500.

It contains the main safety information for safe operation of the FLOWSiC500.

Application scope of the document:

This document is valid for FLOWSiC500 with firmware version 2.15.00 and higher.

FLOWSiC500 with E6 approval acc. CSA



NOTICE:
For a French translation of this document, please refer to document 5025T34 "Manuel d'utilisation FLOWSiC500".

1.3 Intended use

1.3.1 Purpose of the device

The FLOWSi500 series for measuring the gas volume, volume flow rate and gas velocity of natural gas in pipelines.

The FLOWSi500 with optional volume conversion serves for measuring the gas volume and converting the gas volume measured to base conditions as well as registered data on totalizer levels, maximums and other data.

1.3.2 Product identification

Product name:	FLOWSi500
	Shorack-Hausser SCK GmbH & Co. KG
Manufacturer:	Bergener Ring 27
	01458 Ottendorf-Oberkirch
	Germany

The type plates for metrological and electrical parameters are located on the gas flow meter. The type plate for the Pressure Equipment Directive is located on the adapter. Type plate examples: see p. 105, 106.

Fig. 1 Location of type plates

Marking according to ATEX / IECEx



Marking according to CSA



1. Type plate, metrological and electrical parameters (metrology and electrical)

2. The assignment of plug-in connectors

3. Type plate, Pressure Equipment Directive

4. Type plate, electrical parameters (electrical)

5. Type plate, metrological parameters (metrology)

1.2.2 Operation in potentially explosive atmospheres



The FLOWSiC500 is suitable for use in potentially explosive atmospheres:
ATEX: I 2G Ex ia (ia) IIB T4 Gc, I 2G Ex ia (ia) IIC T4 Gc, II 2G Ex op ia IIC T4 Gc
IECEx: Ex ia (ia) IIB T4 Gc, Ex ia (ia) IIC T4 Gc, Ex op ia IIC T4 Gc
US: Class I Division 1, Groups C, D T4, Ex (ia) IIB T4 Gc



Further information on potentially explosive atmospheres → p. 48 §3.4.1

Specific conditions of use (denoted by X after the certificate number)

1. Plastic parts of the electronics enclosure: Under certain extreme circumstances, in Gas Group IIC, exposed plastic and unearthed metal parts of the enclosure may store an ignition-capable level of electrostatic charge. Therefore, the user / installer shall implement precautions to prevent the build up of electrostatic charge, e.g. locate the equipment where a charge-generating mechanism (such as wind-blown dust) is unlikely to be present and clean with a damp cloth.
2. Plastic portable battery pack: No precautions against electrostatic discharge are necessary for portable equipment that has an enclosure made of plastic, metal or a combination of the two, except where a significant static-generating mechanism has been identified. Activities such as placing the battery in a pocket or on a belt, operating a keypad or cleaning with a damp cloth, do not present a significant electrostatic risk. However, where a static-generating mechanism is identified, such as repeated brushing against clothing, then suitable precautions shall be taken, e.g. the use of antistatic footwear.
3. The ultrasonic sensors are manufactured from titanium. The pipeline adapter and part of the electronic enclosure may be made from aluminium. In rare cases, ignition sources due to impact or friction sparks could occur. This shall be considered during installation.
4. The maximum static-electric energy released by impact on the ultrasonic sensors exceeds the limit for Gas Group IIC specified in Clause 16.7 of EN 60079-11:2012. This shall be considered during installation.
5. The apparatus is not capable of withstanding the 500 V insulation test required by clause 6.3.13 of EN 60079-11:2012 (except at the optically isolated input / outputs). This must be taken into account when installing the equipment.

1.2.3 Combustible gas

- The FLOWSiC500 is suitable for measuring combustible and occasionally ignitable gases corresponding to zones 1 and 2.

1.3.3

Restrictions of use

- Refer to the type plate for the configuration of your FLOWSiC500.
- Check the FLOWSiC500 is suitable equipped for your application (e.g.: gas conditions).

**WARNING:** Hazard through material fatigue

The FLOWSiC500 has been designed for use under main(/static) loads.

- Maximum allowed gradient of static pressure: 3 bar / s (45 psi / sec).

The purpose of complete pressure application and release processes should be kept low during operation.

- Replace the device when 500 cycles have been reached.

**NOTICE:**

The FLOWSiC500 is designed for measuring clean and dry natural gas.

- The operating company should install a suitable filter or cone screen ahead of the gas flow meter when the gas is contaminated.

**NOTICE:**

- The FLOWSiC500 is suitable for use in pressured lines within the parameters specified in the device. The device conforms to Pressure Device Equipment PSDX/GE/BO.

- It is the user's responsibility to ensure the maximum values specified for pressure and temperature on the type plate are not exceeded during operation.

1.3.3

Cleaning

**NOTICE:** Cleaning information

- Only clean the FLOWSiC500 with a damp cloth.
- Do not use solvents for cleaning.
- Only use materials for cleaning which do not damage the surface of the FLOWSiC500.

**NOTICE:**

Please observe the specific conditions of use in potentially explosive atmospheres. → p. 12 § 1.3.5

1.4

Responsibility of user

- Only put the FLOWSiC500 into operation after reading the Operating Instructions.
- Observe all safety information.
- If anything is not clear: Please contact the Schenck+Hauke Customer Service.

Designated users

The FLOWSiC500 may only be operated by skilled technicians who, based on their technical training and knowledge as well as knowledge of the relevant regulations, can assess the risks given and recognize the hazards involved.

**NOTICE**

Skilled persons are persons in accordance with DIN VDE 0105 or IEC 304, or directly comparable standards.

These persons must have exact knowledge of hazards arising from operation, e.g. through hot, toxic, explosive gases or gases under pressure, gas/fluid mixtures or other media as well as adequate knowledge of the measuring system gained through training.

Correct use

- Only use the FLOWSiC500 as described in these Operating Instructions (p. 11, § 3.3).
- The manufacturer bears no responsibility for any other use.
- Do not carry out any work or repairs on the FLOWSiC500 not described in this manual.
- Do not remove, add or change any components in or on the FLOWSiC500 unless such changes are officially allowed and specified by the manufacturer.

Otherwise:

- Any warranty by the manufacturer becomes void
- The FLOWSiC500 can become dangerous
- The approval for use in potentially explosive atmospheres is no longer valid
- The approval for use in areas pressurized above 0.5 bar (7.25 psi) is no longer valid.

Danger identification on device**WARNING: Danger identification on device**

The following symbol draws attention to important dangers directly on the device:



- Consult the Operating Instructions in all cases where the symbol is attached to the device or shown on the display.

Special local conditions

- Follow all local laws, regulations and company internal operating directives applicable at the installation location.

Retention of documents

These Operating Instructions must be

- kept available for reference
- passed on to new owners.

1.5 Additional documentation/information

Some parameter settings, device components and characteristics depend on the individual device configuration. This individual device configuration is described in the device documentation delivered with the device.

- Conformity Declaration
- Material certificate
- Inspection certificate
 - Device configuration sheet
 - Broader test protocol (optional)
 - Low pressure calibration test protocol (optional)
 - Labels according to Pressure Equipment Directive 2014/68/EU Annex 1 Part 5.3
- Printout Parameter report
- Available for download:
 - Operating Instructions
 - FLUKEgate™ operating software
 - FLUKEgate™ Software Manual
 - Certificates
 - Instructions information for accessories
 - Calibration Instructions
 - Modbus specification

2.2 Information on cybersecurity threats

Protection against cybersecurity threats requires a comprehensive cybersecurity concept that must be continuously reviewed and maintained. A suitable concept consists of organizational, technical, procedural, electronic, and physical levels of defense and takes into account appropriate measures for the different types of risk. The measures implemented in this product can only support protection against cybersecurity threats if the product is used as part of such a concept.

Visit the manufacturer website for more information, such as:

- General information on cybersecurity
- Contact option for reporting vulnerabilities
- Information on known vulnerabilities (Security Advisories)

FLWSIC500

2 Product description

Measuring principle

System components

FLOWgate™ operating software

Interfaces

Totalizers

Data processing in

Device option

Parameter protection

Sealing


PowerIn Technology™

2.1 Measuring principle

2.1.1 Gas flow meter

The FLUWIG500 works according to the principle of ultrasonic transit time difference measurement.

Fig. 2: Function principle



Measured signal transit times t_{sa} and t_{so} are defined by the current sound and gas velocity. Gas velocity v is determined from the difference between the signal transit times. Therefore changes in the sound velocity caused by pressure or temperature fluctuations do not affect the calculated gas velocity with this measurement method.

The FLUWIG500 calculates the volume flow rate Q internally from the gas velocity and the diameter of the measuring section of the gas flow meter.

$$Q = \frac{\pi \cdot D^2}{4} \cdot \frac{L}{2 \cos \alpha} \cdot \frac{t_{sa} - t_{so}}{t_{sa} \cdot t_{so}}$$

2.1.2 Volume conversion (optional)

The integrated volume conversion converts the measured gas volume from measurement conditions to base conditions.

Calculation according to EN 12405:

$$V_b = C \cdot V_m$$

$$C = \frac{p}{p_b} \cdot \frac{T_b}{T} \cdot \frac{Z_b}{Z}$$

- V_b • Volume at base conditions
 C • Conversion factor
 V_m • Volume at measurement conditions
 p • Gas pressure at measurement conditions
 p_b • Pressure at base conditions
 T • Gas temperature at measurement conditions
 T_b • Temperature at base conditions
 Z_b • Compression factor at base conditions
 Z • Compression factor at measurement conditions

The measurement conditions are either determined with pressure and temperature sensors or entered as fixed value.



The following abbreviations are used in this document for better readability:

- volume at base conditions = base volume
- volume at flowing conditions = measurement volume

2.1 System components

The FLOWSiC500 measuring system comprises:

- FLOWSiC500 gas flow meter
- Adapter for installation in pipelines
- Optional pH sensors for the volume conversion device option

Fig. 3 FLOWSiC500 components



2.1.1 Adapter

The meter body is available in various flange standards and fitting lengths to connect the gas flow meter to the system pipeline.

Depending on the position, the adapter is designed for assembly on DIN flanged Flange in accordance with DIN EN1092-1, OJ150 in accordance with ASME B8B.3, or 1.6MPa in accordance with GOST 12813-80.



Fitting lengths available – p. 188, 194

1.1.1 Gas flow meter

An internal flow conditioner rectifies the gas flow in the gas flow meter so that flow profile disturbances caused by pipe bends in the inlet or outlet sections or components projecting into the pipe (e.g., a thermowell) have no influence on measuring results.

The gas flow meter can be exchanged without taking the adapter out of the pipeline.

The gas flow meter is fitted with:

- Control unit
- Optical and electrical interface
- Measuring cell with ultrasonic transducers
- Electronics

This product variant with volume conversion and integrated pressure and temperature sensors also has the calibrated pressure sensor and calibrated temperature sensor fitted in the gas flow meter.

1.1.2 Meter sizes

Available meter sizes – p. 136, 33 ff.

2.2 FLOWgate™ operating software

The FLOWgate™ operating software allows conveniently access to all measured values of the device.



For FLOWgate™ operating software, see "Software Manual FLOWgate™". The Software Manual is available for download. The Software Manual is also available using the Help function of the FLOWgate™ operating software.

2.2.1 Overview

Software functions:

- Measured values overview
- Field setup wizard
- Parameter modification
- Logbook and archive management
- Calibration
- Diagnostic data
- Service actions
- Session browser

Fig. 4 Software pattern FLOWgate™ - FLOWgate500 "Overview"



2.2.2 System requirements

- Microsoft Windows 7/8/10
- Min. 1.5 GHz CPU
- Min. 1 GB RAM
- Approx. 100 MB free memory (without .NET framework)
- USB or serial interface
- Recommended minimum screen resolution: 1024 x 768 pixels, optimum screen resolution 1280 x 1080 pixels
- Microsoft .NET framework 4.5 or higher



If the user is not an administrator, the following entries in the registry must exist or be configured for installation of the system:

- AllowInstallElevated = 1
- EnableUserControl = 1

Support: <http://search.microsoft.com/en-us/library/a236786d-94e2-4838-8a99->

2.2.3 Access rights

Device function	Client	Net 10	Net 10	Net 10	Net 10 (Net 10)	Net 10 (Net 10)	Net 10 (Net 10)
Standard password	-	1111	1111	1111	1111	1111	1111
User can be deactivated	-	1	1	1	1	1	1
Read parameters and measured values	-	1	1	1	1	1	1
Read data online	-	1	1	1	1	1	1
Change parameters not locally supported	-	1	1	1	1	1	1
Change control relevant parameters	-	1	1	1	1	1	1
User management	-	1	1	1	1	1	1
Control status	-	1	1	1	1	1	1
Configure control	-	1	1	1	1	1	1
Test digital outputs	-	1	1	1	1	1	1

2.4 Interfaces

The FDX5C500 supports various digital and serial interfaces.

The configuration of the interfaces as delivered is described in the delivery documents provided with the respective device.

Table 1: Interface configurations

Interface	I/O 1	I/O 2	I/O 3	I/O 4	I/O 5	I/O 6	I/O 7	I/O 8
DO_0	IF	HP	Encoder + IF	RS485	Encoder + HP	2 x IF	RS485 + HP	RS485 + HP
DO_1	Horse power diagnosis warning, test mode Test pulses				HP pulses	Automatic F.S. H/L	-	-
DO_2	IF pulses	-	-	-	-	IF pulses	-	IF pulses
DO_3	Malfunction	Malfunction	IF pulses	-	Malfunction	IF pulses	-	-
Serial	-	-	-	RS485	-	-	RS485	RS485



- Information on signal technical characteristics and rated voltage → p. 40, § 3.4
- Details on standard interface configurations available → p. 51, § 3.4.2

2.4.1 Pulse and status outputs

FDX5C500 has 4 digital switching outputs. Digital switching outputs DO_0, DO_2 and DO_3 are electrically isolated according to EN 60947-5-5.

Alternatively, digital switching outputs DO_2 and DO_3 can also be configured as Spin Detector.

When used as pulse output, maximum 2 kHz can be output on digital switching output DO_2 and maximum 100 Hz on digital switching outputs DO_2 and DO_3. When used as status output, status information "Validity of measurement" or the result of the self-diagnosis can be represented.

Digital switching output DO_3 is not electrically isolated. In normal mode, the diagnosis warning is output on DO_1, test pulses are output in test mode.

The digital switching outputs are updated synchronously once per second.

2.4.2 Encoder/totaller

Alternatively, digital switching output DO_0 can be configured so that the totaller level of the totaller (m, the meter data and a meter identification) are output via asynchronous serial communication. This allows the connection of volume converters with a suitable input for encoder/totallers.



NOTICE

With encoder communication, it must be ensured that the transmitted digit count or totaller resolution can be processed by the connected volume converter.

A parameter modification can be carried out on the FDX5C500 with the FLOgate™ operating software when the parameter locking switch is open.

2.4.3 Serial data interface

The serial interface is designed as externally powered RS485 and requires an external, intrinsically safe power supply for operation.

Maximum cable length for the RS485 interface: 300 m

2.4 Data processing in

2.4.1 Logbooks

The FLOWSiC500 stores events and parameter changes in the following logbooks:

- **Event logbook**

All events with timestamp, user logged on and totalizer level, max. number of entries: 1500

When the Event logbook is 80% full, the FLOWSiC500 changes to device status "warning", warning W-2001 is shown on the display.

When the Event logbook is full, the FLOWSiC500 changes to device status "Malfunction", error E-0004 is shown on the display (→ p. 104, § 6.1 "Status messages")



NOTICE

If the optional feature "Load recording device with maximum load display" feature is activated and the event logbook is full, the device time can be corrected even if the operation is not logged. That the time has been set is evident from the status of the measuring period entry. Updating is the responsibility of the plant operator.

- **Parameter logbook**

All parameter changes with timestamp, user logged on, totalizer level, old and new parameter value and register number, maximum number of entries: 150

The oldest entries are overwritten when the Parameter logbook is full.

- **Measuring logbook**

All changes to selected custody-relevant parameters (→ p. 31, § 1.3.2), with parameter locking switch activated with timestamp, user logged on, totalizer level, old and new parameter value and register number, maximum number of entries: 150

When the Measuring logbook is full, custody-relevant parameters can be modified only after the parameter locking switch has been opened. The FLOWSiC500 changes to device status "warning", warning W-2002 is shown on the display (→ p. 104, § 6.1 "Status messages")

- **Gas composition logbook**

All parameter changes of the gas composition for the volume conversion with timestamp, user logged on, totalizer level, old and new parameter values and register number, maximum number of entries: 150

The oldest entries are overwritten when the Gas composition logbook is full.

The data are stored in non-volatile memory. All logbooks can be viewed, stored and reset with the FLOWgate™ operating software. The Event logbook can be viewed after login as "user" or "Authorized user" on the device.

The following parameters are displayed:

- Event type
- Number of events
- Short description
- Timestamp

3.2 Archives

The integrated data registration stores totalizer levels, maximums and other data in the following archives:

- **Measuring period archive**
Totalizers and data saved after the measuring period elapses (standard = 60 min). The measuring period can be adjusted – p. 35, § 3.2.5.3.
- **Daily archive**
Totalizers and data saved at the defined gas hour time (standard = 00:00).
- **Monthly archive**
Totalizers and data saved at the defined gas day time (standard = 1st day of month).



Expansions of data structure and storage depth are available in Technical Bulletin "Data Registration".
You will find the document available for download.

3.3 Device option

3.3.1 Volume conversion

The FLOWSiC500 gas flow meter with volume conversion captures the gas counts under measurement conditions and converts it to a volume under base conditions.

Gas volume conversion can run selectively (set at the factory) as PTC or TZ volume conversion. The configuration as temperature volume conversion uses the default value for measurement position for calculations.

Measurement conditions are recorded: with the pressure and temperature sensor or entered as fixed values.

By default, measured values recording and subsequent calculation of the conversion factor are performed every 30 seconds. The update interval can be adjusted – p. 31, § 3.1.5.5 "Calculation".

Depending on the configuration, the compressibility factor (K-factor) is determined with one of the following calculation methods or can be entered as a fixed value.

- Fixed value
- GERG88
- AGA 8 Basis method 1
- AGA 8 Basis method 2
- AGA 10.13
- AGA 10.13 mod
- AGA 10.13 mod, 0.001
- GERG91 mod
- AGA 8-0200 (AGA 8 Detail)

The FLOWSiC500 checks the permissible entry limits of the parameters for the selected calculation method. If one of the entry values is outside the limit (guar), the FLOWSiC500 switches to malfunction state and uses the fixed value of the compressibility factor for calculation of the base volume.

An absolute pressure sensor (optional relative pressure sensor) EPT25 or the functionally compatible successor model EPT56 and a temperature sensor EPT54 or the functionally compatible successor model EPT57 measure current measurement conditions and transfer the sensor type, measured values as well as the sensor status via a digital interface.

The FLOWSiC500 reads the valid measuring range automatically and, periodically, the current status and measured value.

A sensor is only activated for measurement when the configured serial number matches the serial number transferred for the sensor.

If no sensor is detected or a sensor is not functioning correctly, the FLOWSiC500 automatically uses the stored default value (= fixed value) of the state variable.

In this case, the FLOWSiC500 switches to malfunction state and, using the default value, stores the volume under base conditions calculated for pressure or temperature in the slip volume counter.

If not specified otherwise, the FLOWSiC500 is supplied with the following standard settings.

Table 4

Standard settings

Unit system	SI	Imperial
Unit	°C	°F
Unit	bar	psi
Symbol according to	EN 13400	API
Calculator method	ISO9506	AGA 8 (three-term)
Reference conditions for density and heating value	T1, T2, p0 15 °C / 59 °F / 1.01325 bar(a)	T1, T2, p0 60 °F / 60 °F / 14.7300 psi(a)
Base pressure	1.01325 bar(a)	14.7300 psi(a)
Base temperature	0 °C	60 °F

2.7.1 Integrated pressure and temperature sensors

The FLOWSiC500 with volume conversion and integrated pressure and temperature sensors does not have any external components. The internal pressure and temperature sensors are already fitted and calibrated at the factory. The measuring ports are located in the gas flow meter.

This means the FLOWSiC500 does not require any additional installation of sensors to determine the measurement conditions and is immediately ready for operation after volume conversion has been configured.

2.7.2 External pressure and temperature sensors

The FLOWSiC500 with volume conversion and external sensors is used at measuring points where a test/calibration of the pressure or temperature sensor in the system may be required.

It is recommended to install a three-way test valve that separates the pressure sensor from the measurement pressure and provides a test connection to test the pressure sensor.

→ Fig. 5 shows a FLOWSiC500 with external sensors and test valve BDA-04 for gas temperatures to -25 °C.

Fig. 5 FLOWSIC500 with pressure sensor and test valve EC404



- 1 Pressure sensor
- 2 Test valve EC404
- 3 Temperature sensor

A three-way test valve (—Fig. 6) that is fixed hard to the FLOWSIC500 is used for gas temperatures to 40°C.

Fig. 6 Three-way test valve with pressure and flow rate coupling



- 1 Pipe screw fitting 1/4" (1/2" or 3/4" pipe O.D.)
- or pipe screw fitting 1/4" (1/2" or 3/4" or pipe 1/4")
- 2 Hand wheel
- 3 Test connection (H/min max. coupling)
- 4 Pressure sensor connection (max. 0 1/4")

2.12 Load recording device with maximum load display

The optional feature "Load recording device with maximum load display" is available for FLOWSi500 with integrated volume conversion. The feature is optionally activated at the factory and starts the archive entries of the measuring period archive, daily archive and monthly archive at additional depths, a. d. time stamps of measurement and process variables $T_{1...T_{10}}$, T_{100} and flowtime.



Explanation on data structure and storage depth are available in Technical Bulletin "Data Registration".

you will find the document available for download.

The archive contents can be shown on the display. A search function is also available (see → p. 10), §5.2.15. Querying the measurement data and external time synchronization are also possible via the PG425 interface.

When the current measuring period elapses, the consumption and process values of this period are used for updating the daily and monthly extreme values related to the measuring period.

When the current day is ended, the consumption and process values of this day are used for updating the daily related monthly extreme values.

If the feature "Load recording device with maximum load display" is activated, the FLOWSi500 checks if the measuring period in the daily period is still valid when ending the measuring period or the daily period. If the period is valid, the consumption of this period is used for updating the daily and monthly extreme values.

A period entry is marked as invalid when the following events occur:

- when there is a device malfunction,
- when the target recording duration has not been observed,
- when the time has been set beyond the synchronization limit,
- if the difference between the start and end time stamps does not match the target period duration.

For the maximum load function, the stored measured values for the currently running and the previous, i.e. last completed, periods can be shown on the display (see → p. 88, §5.2.5.10).

The maxima (1) of the last 24 months in each case are stored in the monthly archive and can also be viewed on the display.

2.1.2 Extension measurement capability/ up to 30% hydrogen

By default, the FLUORIS500 has the ability to measure a hydrogen content of up to 12% in natural gas. Starting with firmware version 2.1.1.00, this range can be extended up to 30% with an additional (license, Accuracy) class 1.0 is always maintained.

The license can be activated as soon as when ordering the device or can be obtained from Endress+Hauser's local sales. When activating the license for gas flow meters in the field, the national regulations must be taken into account.

2.1.4 Gas Quality Indicator (GQI)

When commissioning the FLUORIS500, from F42.13, the current gas composition and a permissible deviation can be parameterized via the Gas Quality Indicator (GQI) in FUDigene™. The gas quality is continuously monitored. If the gas composition is changed by adding other gas types, e.g. biogas, the operator receives status information as soon as the Gas Quality Indicator (GQI) of the FLUORIS500 exceeds the parameterized permissible deviation. Changes in the gas quality can thus be detected.

As of firmware 2.1.1, the hydrogen content in the natural gas can be monitored via an option, license with the gas quality indicator. As a basis for monitoring, the gas composition of the natural gas in the meter must be parameterized with FUDigene™. If the set limit value is exceeded with fluctuating hydrogen feed-in, the FLUORIS500 reports this back to the operator via the status. In this way, changes in the hydrogen content and thus also the heating value can be detected in real time. The Gas Quality Indicator based on Volgascan™ forms the basis for ensuring contractually agreed gas qualities where no gas quality measurement by means of a gas chromatograph or no measurement of the hydrogen content is available.


For a meter in the field, activation of the feature via an Endress+Hauser license is only possible in compliance with national regulations.

2.2 Parameter protection

2.2.1 Parameter locking switch

A parameter locking switch is located on the circuit board to secure the custody-relevant parameters. This covers all values that influence volume measuring and volume conversion.

Fig. 7 Parameter locking switch on the circuit board



The parameter locking switch is secured by the terminal compartment cover and a seal.

2.2.2 Metrology logbook

Selected custody-relevant parameters can be modified when the parameter locking switch is closed and after logging in as authorized user.

An entry in the metrology logbook is generated to ensure the traceability of mass parameter changes. The entry contains the timestamp, old and new value, totalizer level V for gas flow meters or V_0 for gas flow meters with built-in total volume conversion, and the logged-on user.

The Metrology logbook can have a maximum of 100 entries. The FLOWIC500 switches to status "Warning" when the Metrology logbook is full.

The Metrology logbook can be cleared when the parameter locking switch is open. Parameter changes to the following parameters are entered in the Metrology logbook as long as entries are possible.

Tab. 6 Custody-relevant parameters - gas flow meter

Parameter	Description
Max. mass flow volume	Upper limit for mass flow
Symbol for measured value display	Symbols used on the display to form a symbol

Table 8: Gasos: input parameters - gas flow meter with volume controller

Parameter	Description
Vol: reverse flow volume	Reverse volume for reverse flow
Symbol for measured value display	Symbol used on the display (numeric symbol)
Calculation interval	Cycle time for updating measured values (pressure, temperature) and calculation of the compressibility factor
Calculation method	Calculation method for the compressibility factor
Volume gas track	Checking the input parameters for the compression algorithm
Reference conditions	Reference conditions for density and heating value
Heating value unit	Heating value unit
Density value selection	Selection of relative density or standard density
Ecst: pressure	Pressure standard conditions
Ecst: temperature	Temperature standard conditions
W-factor (fixed)	Factor for "fixed value" when the calculation of the W-factor is incorrect
Default value for input mass	Default value, when the calculation of the molecular mass is disturbed
P Lower alarm limit	Lower warning limit for the pressure which can be set by the customer
P Upper alarm limit	Upper warning limit for the pressure which can be set by the customer
P Default value	Fixed value of measurement pressure
P Unit	Unit for pressure values
Atmospheric pressure	Atmospheric pressure
P Serial number	Serial number of pressure sensor
P Offset	Offset for pressure sensor adjustment
P Adjust factor	Factor for pressure sensor adjustment
T Lower alarm limit	Lower warning limit for the temperature which can be set by the customer
T Upper alarm limit	Upper warning limit for the temperature which can be set by the customer
T Default value	Fixed value of measurement temperature
T Unit	Unit for temperature values, used for entry and display
T Serial number	Serial number of temperature sensor
T Offset	Offset for temperature sensor adjustment
T Adjust factor	Factor for temperature sensor adjustment
Measuring point	Point for filling archive
Gas flow	Flowing flow for the gas archive
Gas day	Flowing day for month archive

1.6.3 Gas composition logbook

All changes of gas composition parameters for volume conversion are saved in the Gas composition logbook.

The entry contains the timestamp, old and new value of the changed parameter, total gas level, logged in user and the register number. The Gas composition logbook can have a maximum of 150 entries. The oldest entries are overwritten when the Gas composition logbook is full.


The Gas composition logbook can only be cleared when the parameter locking switch is open.

Table 7 Gas composition parameters for volume conversion

Variable	Description
Relative density	Relation between gas density and air density under reference conditions
Reference density	Gas reference density under reference conditions
Heating value	Gas heating value under reference conditions
Carbon dioxide (CO ₂)	CO ₂ proportion in gas
Hydrogen H ₂	H ₂ proportion in gas
Nitrogen N ₂	N ₂ proportion in gas
Methane CH ₄	Methane proportion in gas
Ethane C ₂ H ₆	Ethane proportion in gas
Propane	Propane proportion in gas
Water H ₂ O	Water vapor proportion in gas
Hydrogen sulfide H ₂ S	Hydrogen sulfide proportion in gas
Carbon monoxide CO	Carbon monoxide proportion in gas
Oxygen O ₂	Oxygen proportion in gas
Isobutane	Isobutane proportion in gas
n-Butane	n-Butane proportion in gas
Isopentane	Isopentane proportion in gas
n-Pentane	n-Pentane proportion in gas
Isopentane	Isopentane proportion in gas
n-Heptane	n-Heptane proportion in gas
n-Octane	n-Octane proportion in gas
n-Nonane	n-Nonane proportion in gas
n-Decane	n-Decane proportion in gas
Helium	Helium proportion in gas
Argon	Argon proportion in gas

Fig. 12

See on the pressure sensor assembly



- 1 Pressure sensor
- 2 Protective sleeve
- 3 Base
- 4 Wire rod

**NOTICE**

Made sure that the wire rod is placed tight around the pressure sensor.

1.1.2**PowerIn Technology™**

The FLOWSiC500 is available with two configurations:

- For operation with external intrinsically safe power supply with backup battery (backup duration: approx. 3 months)
- Self-sufficient power configuration: 2 internal (lithium battery) packs (typical service life: at least 5 years)

The second battery pack is activated automatically when the first pack is empty and a message displayed (→ p. 32, § 5.2)

FLWSIC500

3 Installation

- Hazards during installation
- General information
- Mechanical installation
- Electrical installation
- Installing the external pressure and temperature sensors
- Fitting a display protector (optional)

3.1 Hazards during installation



CAUTION: General rules during installation

- Observe applicable valid regulations, general standards and guidelines.
- Observe local safety regulations, operating instructions and special regulations.
- Consider the safety information in 4-p. 13, § 1.1.
- Comply with the safety requirements of Pressure Equipment Directive 2014/68/EC or ASME B31.3 when installing pressure devices including connection of various pressure devices.
- Persons carrying out installation work must be familiar with the directives and standards applicable for pipeline construction and have the corresponding qualifications, e.g. in accordance with DIN EN 13554.



WARNING: Hazards through the gas in the system

The following conditions can increase the risk:

- Toxic gas or gas dangerous to health
- Explosive gas
- High gas pressure
- Only carry out installation, maintenance and repair work when the system is non-pressurized.



WARNING: Hazards during installation work

- Do not carry out any welding work on lines with material fitted.
- Comply exactly with mandatory and approved methods.
- Observe and comply with regulations of the plant operator.
- Meticulously check completed work. Ensure leak tightness and strength. Otherwise hazards are possible and safe operation is not ensured.

3.2 General information

3.2.1 Delivery

The FLOWiCECO is delivered pressurized in sturdy packaging.

- Inspect for transport damage when unpacking the device.
- Document any damage found and report this to the manufacturer.



NOTICE

Do not put the FLOWiCECO into operation if you notice any damage!

- Check the scope of delivery for completeness.

The standard scope of delivery comprises:

- FLOWiCECO (gas flow meter and adapter, already fitted)
- Backup battery (if device is configured for external power supply), or
- 2 battery packs (if device is configured for battery operation).

1.2.2 Transport

- During all transport and storage work, ensure:
 - The FLUOSIC500 is always well secured
 - Measures to prevent mechanical damage have been taken
 - Ambient conditions are within specified limits.

1.3 Mechanical installation



CAUTION: General rules during installation

- Observe applicable civil regulations, general standards and guidelines.
- Observe local safety regulations, operating instructions and special regulations.
- Observe the safety information in → p. 13 § 1.1.
- Comply with the safety requirements of Pressure Equipment Directive 2014/68/EU or ASME B31.3 when installing pressure devices including connection of various pressure devices.
- Persons carrying out installation work must be familiar with the directives and standards applicable for pipeline construction and have the corresponding qualifications, e.g. in accordance with DIN EN 1891-4.

The FLUOSIC500 normally does not need straight inlet and outlet sections and can be fitted directly after bends in the pipe.



NOTICE: Installation requirements

- The following elements must not be present within a distance of 5 DN to the adapter in upstream direction:
 - A valve not always operated fully open
 - A pressure regulator
- The pressure sensor must be maximum 5 DN behind the gas flow meter. Alternatively, the temperature sensor in the optional immersion sleeve (s) can be used in the adapter.
- In concrete application, observe limitations resulting from type approval!



NOTICE

This device shall be protected from direct sunlight and atmospheric influences in accordance with IEC 60073-04 or other local installation requirements. Furthermore, the maximum permissible operating conditions shall be observed. This includes compliance with the specified ambient temperature, which may be affected by the surrounding air temperature, by additional heating due to solar radiation, and by the gas temperature.

3.3.1 Preparations

- Select a suitable installation location. Ensure adequate assembly clearances (→ Table L2).
- The following tools and materials are required to install the FLOWSiCS00:
 - Hoisting equipment (lifting capacity according to the weight specifications → p. 152, 59 kg)
 - Box wrench with size suitable for flange installation
 - Torque wrench
 - Flange gaskets
 - Lubricant, metal-free or suitable for aluminum, e.g. OHS 22E to prevent thread mountings welding up



NOTICE
Do not use copper paste!

- SWS Allen key
- Laser detection

3.3.2 Choosing flanges, gaskets and other components

For flange connections only use pipeline flanges, bolts, nuts and gaskets suitable for the maximum operating pressure, maximum operating temperature as well as ambient and operating conditions (external and internal corrosion).

→ Table 3 compiles a list of recommended bolts and → Table 4 contains a list of recommended gaskets.

For devices with approval according to GOST, → Table 12 contains a list of recommended bolts and → Table 13 contains a list of recommended gaskets.

Fig. 12 Dimensions of gaskets




Table 3 Bolts and tightening torques

Flange / flange type	Bolts	Flanges	Nuts	Tightening torque
PN10 / EN1092-1				
DN50 / PN10	4 pc. DIN 934- M10x45-42-70	4 pc. DIN 15- 417-44	4 pc. DIN 934- M10-44-70	120 Nm 98 lbf ft
PN50 / PN10	8 pc. DIN 934- M10x45-42-70	8 pc. DIN 15- 417-44	8 pc. DIN 934- M10-44-70	130 Nm 99 lbf ft
DN150 / PN10	8 pc. DIN 934- M10x45-42-70	8 pc. DIN 15- 417-44	8 pc. DIN 934- M10-44-70	250 Nm 184 lbf ft
Class 150 / ASME B16.5				

Drain, Range type	Boots	Access	Notes	Typical weight
2" / D150	4 pc. Double end threaded stud 3/8" x length 3.5" - ASTM A193 B16.3.2 ASTM A193 Grade B316	4 pc. Type 4 bolt/washer/nut/washer (range) 3/8" x 3" - ANSI B18.3.1 3/8" x 3.5" - ANSI B18.3.2	4 pc. Hardhat nut (UNC series) 3/8" x 3" - ANSI B18.3.1 3/8" x 3.5" - ANSI B18.3.2	142 lbs 122 lbs
3" / D150	5 pc. Double end threaded stud 3/8" x length 3.5" - ASTM A193 B16.3.2 ASTM A193 Grade B316	5 pc. Type 4 bolt/washer/nut/washer (range) 3/8" x 3" - ANSI B18.3.1 3/8" x 3.5" - ANSI B18.3.2	5 pc. Hardhat nut (UNC series) 3/8" x 3" - ANSI B18.3.1 3/8" x 3.5" - ANSI B18.3.2	142 lbs 122 lbs
4" / D150	5 pc. Double end threaded stud 3/8" x length 4.2" - ASTM A193 B16.3.2 ASTM A193 Grade B316	5 pc. Type 4 bolt/washer/nut/washer (range) 3/8" x 4" - ANSI B18.3.1 3/8" x 4.2" - ANSI B18.3.2	5 pc. Hardhat nut (UNC series) 3/8" x 4" - ANSI B18.3.1 3/8" x 4.2" - ANSI B18.3.2	142 lbs 122 lbs
6" / D150	5 pc. Double end threaded stud 3/8" x length 4.2" - ASTM A193 B16.3.2 ASTM A193 Grade B316	5 pc. Type 4 bolt/washer/nut/washer (range) 3/8" x 4" - ANSI B18.3.1 3/8" x 4.2" - ANSI B18.3.2	5 pc. Hardhat nut (UNC series) 3/8" x 4" - ANSI B18.3.1 3/8" x 4.2" - ANSI B18.3.2	142 lbs 122 lbs

Table 4

Access

Drain, Range type	Dr (mm)	Dr (mm)	Dr (mm)	Material
PH10 / DN100-1				
DN50 / PH10	101	61	2	nonpressure® FLX® BUL® 515
DN50 / PH10	142	90		
DN100 / PH10	183	115		
DN150 / PH10	215	155		
Case 150 / ASH® 150				
2" / D150	105	60	2	nonpressure® FLX® BUL® 515
3" / D150	127	69		
4" / D150	175	114		
6" / D150	222	158		

2) Dr = outer diameter, D = inner diameter, 1 = inch, 2 = mm, 3 = Fig. 12

2.3.3 Fitting in the pipeline


NOTICE

The lifting lug is designed for transporting the measuring device only.
Do not lift or transport the FLOWSiC500 with additional loads using the lug.

- The FLOWSiC500 must not swing or tilt on the hoisting equipment during transport.
- The FLOWSiC500 must not turn during transport otherwise the lifting lug could be screwed out.


NOTICE Observe the gas flow direction

The prescribed flow direction is marked on the adapter with an arrow.
Arrow direction and gas flow direction must match.

- Install the FLOWSiC500 in flow direction.
The device signals a malfunction when the FLOWSiC500 is installed against the prescribed flow direction.

The FLOWSiC500 can be installed horizontal or vertical.
The control unit can be rotated ± 90° (→ p. 46, § 3.4.4).

Fig. 12 Installation examples



8.3.3.1 Assembly clearances

Maintain adequate assembly clearances to ensure there is enough room to extend the gas flow meter. The upward clearance is needed to remove the gas flow meter from the adapter and to put it back on again. The downward clearance is needed to loosen the screws, take them out or insert them again and to fit the tool correctly.



NOTICE

Depending on the tool used and the installation location, adequate clearances to the sides are also required.

Fig. 14

Assembly clearances




Table 12

Minimum clearance required starting from the pipe axis

Meter size	Upward clearance, air sampling (g)		Upward clearance, air sampling (g)		Downward clearance	
	(mm)	(in)	(mm)	(in)	(mm)	(in)
DS50/2"	300	11.81	340	13.38	200	7.87
DS60/3"	400	15.71	510	20.08	250	9.84
DS100/4"	520	20.47	570	22.44	320	12.6
DS150/6"	520	20.47	570	22.44	320	12.6

3.3.2 Pipeline torque



NOTICE

If the FLOWSiC500 is installed so that the gas flow meter projects sideways from the pipeline, the gas flow meter weight creates a torque on the pipeline.

- Make sure the pipeline is capable of holding the gas flow meter – p. 45, Table 13.

Table 13 Pipeline torque

Pipeline	Torque	
	[Nm]	[lbf·ft]
DN150, 2'	4	3
DN150, 2'	10	12
DN150, 4'	21	23
DN150, 6'	31	23

3.3.3 Installation in pipeline

1. Select suitable bolts.
 - Recommended bolts – Table 8.
2. Use the hoisting equipment to position the FLOWSiC500 in the desired location in the pipeline.
 - Lay the pipeline without tension to the device to be installed.
3. Insert and align the gaskets.
4. Apply lubricant to the bolts.
5. First screw the bolts to hand into the adapter to the stop.
 - Screw in the bolts according to DIN 934 with the proper thread end.
 - The bolts according to ASME B31.3 can be achieved in with any end.
6. Check the thread length in the adapter is fully utilized.
7. Then install the washers and nuts, and tighten them by hand.
8. Check whether the thread length of the nut is fully utilized.
 - If necessary, use a different bolt length.
9. Check correct positioning of flange gaskets.
10. Tighten nuts axially and crosswise in small steps until the specified tightening torque is reached (– Table 8).
 - Make sure the flange are free of tension.
11. Slowly increase the pressure in the pipeline.
 - Gradient: Max. 3 bar/min (45 psi/min).
12. Carry out a leak tightness check on the pipeline in accordance with the pipeline operating company's specifications.

3.4 Electrical installation

3.4.1 Requirements for use in potentially explosive atmospheres



The FLOWSiC500 is suitable for use in potentially explosive atmospheres: ATEX: I 20 Ex ia [ga] IIS T4 Gc, I 20 Ex ia [ga] IIC T4 Gc, II 20 Ex op ia IIC T4 Gc (EEx: Ex ia [ga] IIS T4 Gc, Ex ia [ga] IIC T4 Gc, Ex op ia IIC T4 Gc) UL/CT Class I Division 1, Groups C, D T4, Ex, VEx ia IIS T4 Gc



For a FLOWSiC500 used in potentially explosive atmospheres:

- Installation, commissioning, maintenance and inspection may only be carried out by skilled persons having knowledge of the relevant rules and regulations for potentially explosive atmospheres, especially:
 - ignition protection types
 - installation regulations
 - Category classification
- Comply with all valid IEC standards.

The FLOWSiC500 is suitable for measuring combustible and occasionally ignitable gases corresponding to classes I and II.

Basic requirements

- The documentation for zone categorization in accordance with IEC 60079-10 must be available.
- The FLOWSiC500 must have been checked for suitability for the actual installation location and the Ex marking on the device must match the requirements.
- After installation and before initial commissioning, the complete equipment and the system must be inspected in compliance with IEC 60079-17.



WARNING: Risk of explosion

All electrical connections of the FLOWSiC500 are approved for connection to the certified intrinsically safe power circuits only.

- Proof of the intrinsic safety (in compliance with IEC 60079-14) must be presented for interconnection with the associated (intrinsically) safe equipment.

Otherwise the intrinsic safety of the FLOWSiC500 can be endangered, i.e. the ignition protection for the FLOWSiC500 can no longer be assured.

Operating conditions for the ultrasonic sensors

The FLOWSiC500 is designed for use in potentially explosive atmospheres solely under normal atmospheric conditions within the following limits:

- Ambient pressure range 0.5 bar (11.6 psi) to 1.1 bar (15.95 psi)
- Air with normal oxygen content, normally 21 percent by volume

The ambient temperature must be within the range specified on the type plate.


The gas flow meter becomes part of the pipeline as soon as the FLOWSiC500 is installed in the pipeline.

The walls of the pipeline and the gas flow meter then serve as a non-separating barrier. The following figure shows the different situations for a positive application and the operating conditions that apply.

Fig. 15


Barrier

Case 1



- The pipeline contains a non-explosive mixture. The gas mixture can be combustible.
- Gas pressure and gas temperature can be within the range specified on the type plate of the gas flow meter.

Case 2



- The area inside the pipeline is classified as potentially explosive atmosphere Zone 1 or 2.
- The gas pressure must be within the range 0.5 (11.6 psi) to 1.1 bar (15.95 psi) (normal atmospheric conditions).
- Gas temperature must be within the permitted ambient temperature range specified by the type plate of the gas flow meter.



NOTICE

Please observe the specific conditions of use in potentially explosive atmospheres – p. 22, 5.1.2.2.

14.2 Criteria for electrical connection

Installation note → p. 25 §1.2 must be completed.



WARNING: Risk of exposure - hazard for intrinsic safety.

- The following work may only be carried out by skilled technicians familiar with the special characteristics of the intrinsic safety of the lighting protection type and who have knowledge of the relevant standards and regulations for interconnection of intrinsically safe power circuits.

14.3 Opening and closing the electronics cover



The EX terminal compartment of the FLOWSiC500 can be accessed after the electronics cover has been opened. The cover may also be opened in the hazardous area when under voltage. However, safe separation between the various intrinsically safe power circuits must not be breached.

Opening the electronics cover

1. Loosen the 4 screws (A) of the electronics cover using an S13 Allen key.

Fig. 56 Region of electronics cover access



2. Open the electronics cover.

Closing the electronics cover

1. Close the electronics cover.



- Make sure no battery and (dis)connect cables are pinched.

2. Screw the electronics cover tight again.
Tightening torque: 2.5 Nm (1.8 lbf ft).

2.4.4 Rotating the control unit

1. Open the electronics cover (→ p. 48, 2.3.4)
2. Loosen the 4 display screws with an SW3 Allen key (→ P4.17).

Fig. 17 Position of display screws



3. Check the display seal for integrity and correct fitting.
4. A new seal is available as spare part when the display seal is damaged (Part No. 2095477).
5. Rotate the display in the desired direction and position.
6. Tighten the display screws again.
Tightening torque: 2.0 Nm (3.6 lbf ft)
7. Close the electronics cover again.

14.3 Electrical connections

The FLOW-GUARD interfaces are accessible from the outside via external plug-in connectors.

Fig. 13 Connectors



- 1 Plug-in connector 1 (8-coded) External power supply and signal output
- 2 Plug-in connector 2 (4-coded) Signal input
- 3 Ground screw
- 4 Connections for pressure/temperature sensor (optional)

Fig. 14 VDI plug-in connector coding



Plug-in connector 1
(8-coded)



Plug-in connector 2
(4-coded)



NOTE

Safety-relevant parameters are valid for connecting all pins of a plug-in connector.



Plug-in connector 2 (4-coded) can be configured when ordered, configuration options – p. 50 §3.4.5.

The respective configuration is printed on the type plate – p. 50.



The external power supply need not be connected when the FLOW-GUARD is operated with internal batteries.

14.8 Pin assignment of plug-in connectors

14.8.1 Plug-in connector 1: External power supply and signal output

Pin assignment for configuration F, G, H, I, J, K, L

Table 14 Pin assignment for M12 plug-in connector 1 (male B-coded, 4-pole)

M12 pin	Input/output	Function/signal	Operating parameters	Safety-relevant parameters
1	PSB+	Voltage supply	Rated input voltage 4.5... 20 V	$U_N = 20\text{ V}$ $I_N = 600\text{ mA}$ $P_N = 150\text{ mW}$ $U_{CE} = 0.2\text{ V}$ $I_{CE} = 0.50\text{ mA}$ $R_{CE} = 1.7\text{ m}\Omega$ $C_{CE} = 7.5\text{ }\mu\text{F}$ $t_{CE} = 120\text{ ms}$
2	PSB-			
3	OC_1+	Diagnostic wiring Pulse output (load mode) → Table 1; and for configuration I, $I_{load} = 2\text{ mA}$ at 120% Q_{load} 0 mA	OC (Open Collector) Passive, not electrically isolated	
4	OC_1-		Rated 20 V Rated 200 mA $R_{ON} > 1000\Omega$ $R_{OFF} > 1\text{ k}\Omega$	

Pin assignment for configuration M

Table 15 Pin assignment for M12 plug-in connector 1 (male B-coded, 4-pole)

M12 pin	Input/output	Function/signal	Operating parameters	Safety-relevant parameters
1	PSB+	Voltage supply	Rated input voltage 4.5... 20 V	$U_N = 20\text{ V}$ $I_N = 600\text{ mA}$ $P_N = 150\text{ mW}$
2	PSB-			
3	OC_2+	HF output	Passive, electrically isolated, actively loaded	
4	OC_2-	I_{load} configurable to 2 mA at 120% Q_{load}	Rated output voltage 0.2 V $I_{ON} = 0.4\text{ mA}$ $t_{ON} = 0.7\text{ ms}$	

Pin assignment for configuration N

Table 16 Pin assignment for M12 plug-in connector 1 (male B-coded, 4-pole)

M12 pin	Input/output	Function/signal	Operating parameters	Safety-relevant parameters
1	PSB+	Voltage supply	Rated input voltage 4.5... 20 V	$U_N = 20\text{ V}$ $I_N = 600\text{ mA}$ $P_N = 150\text{ mW}$
2	PSB-			
3	OC_3+	LF output	Passive, electrically isolated, configurable as: OC (Open Collector): V _{max} 20 V Rated current 20 mA	
4	OC_3-	I_{load} configurable to 100 mA at 120% Q_{load}	0 mA to 0.8 Rated output voltage 0.2 V $I_{ON} = 0.4\text{ mA}$ $t_{ON} = 0.7\text{ ms}$	

3.4.2.2 Plug-in connector 2: Signal output

Type 17: Reassignment for M12 plug-in connector 2 (male, 4-pole, 4-pole)

M12 pin	Input/output	Function/signal	Operating parameters	Signal output parameters
Reassignment configuration 1: LF pulses and malfunction (electrically isolated), type code 1/0/0				
1	00_3+	LF pulses	Passive, electrically isolated, configurable as OC (Open Collector)*	U ₀ = 20 V R = 750 mΩ
2	00_3-	f _{max} configurable to 100 kHz at 120% Q _{max}	Rel. 18 V Rated current 10 mA	
3	00_3-	Malfunction		
4	00_3+		or WAGO: Rated input voltage 3.2 V I _{in} = 3.4 mA U _{in} = 0.7 mA	
Reassignment configuration 2: HF pulses and malfunction (electrically isolated), type code 1/0/0				
1	00_3+	HF pulses	ReliAR electrically isolated, optically isolated	U ₀ = 20 V R = 750 mΩ
2	00_3-	f _{max} configurable to 1 kHz at 120% Q _{max}	Rated input voltage 3.2 V I _{in} = 3.4 mA U _{in} = 0.7 mA	
3	00_3-	Malfunction	Passive, electrically isolated, configurable as OC (Open Collector)*	
4	00_3+		or ReliAR, see Configuration 1 for operating parameters	
Reassignment configuration 3: Encoder with LF pulses (electrically isolated), type code 1/0/0				
1	00_3+	Encoder/og	ReliAR electrically isolated, optically isolated	U ₀ = 20 V R = 750 mΩ
2	00_3-		Rated input voltage 3.2 V I _{in} = 3.4 mA U _{in} = 0.7 mA	
3	00_3-	LF pulses	Passive, electrically isolated, configurable as OC (Open Collector)*	
4	00_3+		or ReliAR, see Configuration 1 for operating parameters	
Standard configuration				
Reassignment configuration 4: RS485 module (external than), standard version Type code 1/0/0, line voltage version				
1	Pin 6+	RS485 module (externally powered)	Electrically isolated	U ₀ = 20 V R = 1.1 Ω AC-C = 0.33 μF RS-C = 1.35 μF U ₀ = 0.05 mV
2	Out A		Standard version Rated input voltage U ₀ = 4 ... 18 V	
3	Pin 6-		Line voltage version Rated input voltage U ₀ = 2.7 ... 6 V	
4	Out B			

Table 17 RF assignment for M12 plug-in connector 2 (type R-coded, 4-pole)

M12 pin	Electrical load	Function/signals	Operating parameters	Signal load and parameters
Pin assignment configuration 2: Encoder and RF pulses (not electrically isolated), type code 1/0: K				
The RF pulses are output via plug-in connector 1 (DO_1) → Table 14.				
1	DO_5+	Braking	NAMUR, electrically isolated, polarity isolated	U = 20 V R = 750 mΩ
2	DO_6+		Rated input voltage 5 V I _{in} = 3.4 mA I _{out} = 0.7 mA	
3	DO_3+	Half function	Passive, electrically isolated, configurable as OC (Open Collector) or NAMUR, see Configuration 1 for operating parameters	
4	DO_3+			
* Standard configuration				
Pin assignment configuration 3: LF pulses and half function (electrically isolated), type code 1/0: L				
1	DO_3+	LF pulses	Passive, electrically isolated, configurable as OC (Open Collector), min. 1 V	U = 20 V R = 750 mΩ
2	DO_3+	I _{avg} configurable to 100 Hz at 120% Q _{avg}	Rated current 20 mA	
3	DO_3+	LF pulses	or NAMUR	
4	DO_3+	I _{avg} configurable to 100 Hz at 120% Q _{avg}	Rated input voltage 5 V I _{in} = 3.4 mA I _{out} = 0.7 mA	
Pin assignment configuration 7: RS485 module + RF pulses, type code 1/0: M				
The RF pulses are output via plug-in connector 1 (DO_1) → Table 15.				
1	PWR+	RS485 module (externally powered)	Electrically isolated	U = 20 V R = 1.1 Ω
2	Data A		Standard version	RC: C = 0.22 μF
3	PWR-		Rated input voltage U _{in} = 4...15 V	RC: C = 1.35 μF L = 0.03 mH
4	Data B			
Pin assignment configuration 8: RS485 module + LF pulses, type code 1/0: N				
The LF pulses are output via plug-in connector 1 (DO_1) → Table 16.				
1	PWR+	RS485 module (externally powered)	Electrically isolated	U = 20 V R = 1.1 Ω
2	Data A		Standard version	RC: C = 0.22 μF
3	PWR-		Rated input voltage U _{in} = 4...15 V	RC: C = 1.35 μF L = 0.03 mH
4	Data B			

Fig. 20: Wiring on the type plate, wiretable

Number	Number	Number	Number
			
Power	Signal/Output	Output	Output
(1) +5V	(2) 0V	(3) +5V	(4) +5V
(5) +5V	(6) +5V	(7) +5V	(8) +5V
(9) 0V	(10) 0V	(11) 0V	(12) 0V

 **Important settings assignment -> p. 155, § 5.7**

5.4.7 DO configuration switch (Open Collector - Narmur)

Fig. 21: Open Collector - Narmur





Fig. 22: DO switching (Open Collector - Narmur)



1A2 Cable specifications

When the plugs available from Endress+Hauser are used, a shielded control cable with 4x0.25 mm² cross-section, with PVC insulation and approx. 5 mm outer diameter is required.



WARNING: Requirements on cables and installation

- Pay attention to the requirements in EN 60075-04 when selecting the cables and during installation.
- Further legal requirements must be observed for use in explosive atmospheres.

Endress+Hauser recommends the ready-made cable assembly as accessories (→ p. 135, SS.1).

Wire colors of the cable available as spare part

Type 12 Power supply cable for connection to plug-in connector 1, 5-wired

Part No.	Pin	Wire color	Plug
2007424	1	Brown	
2007425	2	White	
	3	Blue	
	4	Black (or white/green)	
2007632	1	White	
2007633	2	Brown	
	3	Green	
	4	Black	

Type 13 Data cable for connection to plug-in connector 2, 4-wired

Part No.	Pin	Wire color	Plug
2007411	1	Brown	
2007412	2	White	
	3	Blue	
	4	Black (or white/green)	
2007630	1	White	
2007631	2	Brown	
	3	Green	
	4	Black	

3.4.3 Operation with external power supply



- The FLOWSiC500 is designed electrically intrinsically safe.
- After correct installation has been checked, the plug connections in the hazardous area can be connected and disconnected under voltage (p. 44).

3.4.3.1 Connecting the external power supply

1. Connect the external intrinsically safe power supply to the 5x12 pin DIN connector on the FLOWSiC500.
- Safety-relevant parameters – p. 51, § 4.2.

Fig. 26 Connected for external power supply underneath the gas flow meter



1. External power supply and plug cable

2. Switch the power supply on.
The FLOWSiC500 is initialized.
3. Measurement starts and the current measured value for the gas volume appears.
4. Set the date and time (– p. 50, § 4.2).

3.4.3.2 Connecting the backup battery

1. Open the electronics cover (– p. 48, § 4.3).
2. Connect the backup battery (Part No. 2005826) to connection 5x12 in the terminal compartment (– Fig. 24).
3. Close the electronics cover again.

Fig. 24 Electrical backup battery



14.10 Battery operation

**WARNING:** Hazard through wrong operation

The FLUWIS/500 and the delivered battery packs are designed with a capacity of 22Ah.


- Only the exchangeable battery packs from Endress+Hauser with Part No. 2054415 and the backup battery with Part No. 2055925 may be used for the power supply of the device.
- The battery packs can be connected and disconnected in the hazardous area as well.
- Only connect the battery packs to the connectors marked for this purpose in the terminal compartment of the FLUWIS/500.
- Shorting the electrical connection parts is not allowed.

**NOTICE**

Please observe the specific conditions of use in potentially explosive atmospheres — p. 12, § 3.3.

3.4.10.1 Connecting the batteries to supply the FLOWSiC800

1. Open the electronics cover (→ p. 43, §3.4.3).
2. Insert the battery packs (Part. No. 2056018), as shown and connect to connectors BAT1 and BAT2 in the terminal compartment. The FLOWSiC800 is initialised.

Fig. 25 Connected battery packs

3. Close the electronics cover again.
4. Set the date and time (→ p. 70, §4.1).

3.3 Installing the external pressure and temperature sensors

The adapter of FLOWSiC500 has measuring ports for pressure and temperature.



NOTICE

- The pressure measuring port to be used for measurement is marked "P_{in}". On meters with flow direction "left/right" (→), the marked pressure measuring port is on the rear of the adapter; on meters with flow direction "right/left" (←), it is on the front.
- The pressure and temperature sensors can only be replaced when the parallel locking switch is open.

Fig. 28 Pressure and temperature measuring ports (front and rear side)



- 1 Pressure measuring port
- 2 Air intake temperature measuring port



NOTICE: Ensure sufficient assembly clearance!

Ensure sufficient clearance to the wall or other components at the rear measuring ports when installing the sensors.
The recommended minimum clearance to the wall is 0.3 m.

3.3.1 Fitting the plug-in connector cover

Fit the plug-in connector cover before installing the sensors.

- 1 Guide the sensor plugs through the openings in the plug-in connector cover.

Fig. 29 Plug-in connector cover



2. Connect the plugs to the planned connections:



For meter class D150 and D180, it is recommended to connect the pressure sensor to the right MS connection and the temperature sensor to the left MS connection.

The FLOWBIO500 automatically detects whether a pressure or temperature sensor has been connected to a connection.

Fig. 22 Connections for pressure and temperature sensors



1. Connections for pressure and temperature sensors

3. Push the plug-in connector cover over the plugs and fasten with both capstan screws.

Fig. 23 Retaining the plug-in connector cover



- 1. Capstan screw
- 2. Plug-in connector cover

1.5.2 Installing the pressure sensor

A three-way test valve is normally fitted to be able to test the pressure sensor port when installed.



NOTICE: Fitting information

It is recommended to connect the pressure sensor with the three-way test valve with the FLOWSi500 so that there is a downward slope from the pressure sensor to the connection point and from the three-way test valve to the FLOWSi500.

- Before installing a pressure sensor, check if there is a G 1/4" or NPT 1/4" thread on the meter body.
- The thread type is marked on the meter body.

Fig. 50 Marking on meter body

Thread G 1/4"



Thread N 1/4"



- When the meter body has an NPT 1/4" thread, screw in the adapter from NPT 1/4" to G 1/4" (Part No. 2075502) before using the accessory parts available from Endress+Hauser.



NOTICE

The thread on the meter body is damaged when a wrong thread type is screwed in.
Occurs the leaking on the meter body!

Variant 3: Installation with test valve SD404 (up to +25 °C dynamic; up to +30 °C static)




For details on installation with test valve SD404, see manufacturer's operating instructions.
You will find the document available for download.

- 1 Remove the dummy plug on the pressure measuring port marked 'P_m'.
- 2 When the meter body has an NPT 1/4" thread, first screw in the adapter from NPT 1/4" to G 1/4" (Part No. 2075502).
- 3 Fit the test valve SD404.


- Pay attention to the alignment of the connection for the pressure sensor.
 4. Fit the pressure sensor on the test valve BDA04 (→ Fig. 31).

Fig. 31 Test valve BDA04 with pressure sensor fitted



1. Pressure sensor, connector thread G 1/4"
2. Test valve BDA04
3. FLOWBLOC connector G 1/4" male thread

Task 20 Test valve BDA04 positions



Variant 2: Installation with three-way test valve (33-40 °C)

Here, a conventional three-way test valve is used.

Install the three-way test valve with pressure sensor fitted at a suitable location next to the FLWSIC500. A pressure line serves to connect the pressure measuring connector of the FLWSIC500 to the three-way test valve.

Two variants of the pressure connection set with three-way test valve are available. The type code indicates which variant must be selected.

- Check type code, position 5 "pressure connection", on the type plate → Fig. 3, of your FLWSIC500.
- Select the connection set suitable for the pressure connection on the FLWSIC500: → p. 133, § 3.1.

Connection "pressure" in type code	Pressure connection
5	Pipe screw fitting pipe 1/4"
6	Pipe screw fitting pipe G6

- For the complete type code description, see → p. 133, § 3.1.

Fig. 10 Pressure connection on FLWSIC500




1. Pass the three-way test valve at a suitable location.
2. Remove the dummy plug on the pressure measuring port marked "P₂".
3. When the meter body has an NPT 1/4" threaded, first screw in the adapter from NPT 1/4" to G 1/4" (Part No. 2075502).
4. Screw in the pipe screw fitting for pipe 1/4" or pipe G6.
5. Install the pressure line between the FLWSIC500 and the three-way test valve.
6. Fit the pressure sensor to the three-way test valve.

Fig. 11 Pressure sensor installation on the three-way test valve (40-70 °C)



1. Pipe screw fitting 1/4" NPT or pipe G6 or pipe screw fitting 1/4" NPT or pipe 1/4"
2. Handle
3. Test connection (fit mass coupling)
4. Pressure sensor, connection size 1/4"

Task 21: Threaded test valve ports



Variant 3: Installation without a three-way test valve

Here, the pressure sensor is connected directly to the FLOWSiC900.

1. Remove the dummy plug at the pressure measuring port marked "P1".
2. When the main body has an GPT 1/4" thread, fit screw in the adapter (Part no. 2015552).
3. Fit the pressure sensor.

Fig. 34: Installation without three-way test valve



1.3.3 Installing the temperature sensor


NOTICE

Endress+Hauser recommends to install the temperature sensor on the temperature measuring port which is on the same side as the display.


NOTICE: Pay attention to the flow direction.

The required length of the thermowell for meters with nominal diameter DN50/2" depends on the flow direction.

Pay attention to the flow direction when selecting thermowell:

- 75 mm on the side of the adapter with flow direction left/right
- 125 mm on the side of the adapter with flow direction right/left



The temperature sensor can be greased with heat-conducting grease to improve its performance.

1. Insert the temperature sensor into the thermowell to the stop.
2. Tighten the locknut.
3. Have the wire seal attached to a calibration inspector (→ Fig. 10).

Fig. 10 Installing the temperature sensor



1. Temperature sensor

3.4 Fitting a display protector (option)

Display protector (Part No. 2065547) is available as an option for protection of the display from UV light.

Fig. 28 Display protector



Tools required

- Allen key: SW 3 and 2.5
- Jaw wrench SW 6



The EX1 terminal compartment of the FLOWSEC500 can be accessed after the electronics cover has been opened. The cover may also be opened in the hazardous area when under voltage. However, safe separation between the various (intrinsically) safe power circuits must not be breached.

- 1 Loosen and unscrew the two upper screws of the electronics cover with an Allen key SW 3.



- 2 Instead, mount the delivered screws with a SW 6 jaw wrench.



8. Mount the storage cover with the pre-mounted screws (supplied) using an Allen key (M5 2.5).



FLWSIC500

4 Commissioning

General information

Commissioning on the display

Commissioning with the FLOWgate™ operating software

4.1 General information

- All activities described in § 3 "Installation" must be completed before commissioning.
- Commissioning can be carried out directly on the device (i.e. the display). → p. 70, § 4.2.
- The field setup wizard in the FLOWSiC500 operating software supports an advanced commissioning. → p. 73, § 4.2.



NOTE: Measures in a metrologically secured area

If stipulated by national regulations, measures on the device in the metrologically secured area after commissioning may be carried out only under official supervision:

- This must be coordinated with the authorities before carrying out the measures.
- All measures must be carried out based on this Manual.

4.2 Commissioning on the display

4.2.1 Commissioning sequence

4.2.1.1 Gas flow meter commissioning

FLOWSiC500 commissioning is normally performed in the following sequence:

- Log on as "Authorized user" → p. 89, § 5.1.7.
- Set the date and time → p. 71, § 4.2.2.
- Check the device status → p. 72, § 4.2.4.

4.2.1.2 Gas flow meter commissioning with device option volume conversion

- Log on as "Authorized user" → p. 89, § 5.1.7.
- Set the date and time → p. 71, § 4.2.2.
- Activate the configuration mode → p. 89, § 5.1.9.
- Set fixed values for pressure and temperature → p. 73, § 4.2.3.1.
- Set reference values (already configured) → Tab 4.
- Select the calculator method already configured → p. 89, § 5.1.6.9.
- Set the fixed value of the compressibility factor → p. 89, § 5.2.6.5.
- Check the configuration → p. 72, § 4.2.3.2.
- Configure the gas compressor → p. 72, § 4.2.3.3.
- Adapt alarm limits for pressure and temperature → p. 94, § 5.1.6.6 and → p. 94, § 5.2.6.7.



The alarm limits are set in the factory to the measuring range of the selected sensor.

- Terminate configuration mode → p. 89, § 5.1.9.
- Check the device status → p. 72, § 4.2.4.

4.2.2 Setting the date and time

Date and time must be set after the power supply has been connected. The FLOVSI0500 displays error E-0007 ("Time invalid") until the time has been set.



Observe information on operating using the display and on menu navigation → p. 55 §5.2.7.



- The time zone function adapts the time to the new time zone. If you want to change date and time as well as the time zone, change the time zone first.
- Date and time can be changed without starting configuration mode.

- 1 Log on as "Authorized user" → p. 55 §5.2.7.
- 2 Switch to the "System settings" submenu in the FLOVSI0500 menu.
- 3 Call up "Date".
- 4 Press ENTER to start the edit mode.
The cursor now points under the first position of the date.
- 5 Use the arrow buttons to increment or decrement the selected position by 1 until the correct digit is shown.
- 6 Confirm with ENTER.
The cursor now points under the second position of the date.
- 7 Repeat for the remaining positions of the date.
The date is saved when you confirm the last position with ENTER.
- 8 Switch to "Time".
- 9 Use the arrow buttons to increment or decrement the first position of the time by 1 until the correct digit is shown.
- 10 Confirm with ENTER.
- 11 Repeat for the remaining positions of the time.
The time is saved when you confirm the last position with ENTER.

4.2.3 Configuring volume conversion (device option)

4.2.3.1 Setting fixed values

The fixed values must be set to the average measurement conditions of pressure and temperature.

- 1 Log on as "Authorized user" → p. 55 §5.2.7.
- 2 Start the configuration mode → p. 55.
- 3 In the FLOVSI0500 menu, switch to submenu "Pressure parameters" or "Temperature parameters".
- 4 Select the view "V-Fixed value" or "T-Fixed value".
- 5 Press ENTER to start the edit mode.
The cursor now points under the first position of the parameter.
- 6 Use the arrow buttons to increment or decrement the selected position by 1 until the correct digit is shown.
- 7 Confirm with ENTER.
The cursor now points under the second position of the parameter.
- 8 Repeat for all remaining positions of the parameter.
The fixed value is saved when you confirm the last position with ENTER.

4.2.2 Checking the configuration

The FLOWSiC500 is delivered already configured according to customer specifications. It is recommended to check the custody-relevant parameters and settings. The custody-relevant parameters are shown in the delivered Parameter report and can be compared against the current configuration on the display.

A new Parameter report can be created using the FLOWgate™ operating software:

- Open the menu "Parameter change" in the FLOWgate™ operating software.
- Click "Create Parameter report". The report is generated.
- File the report with the device documentation.

4.2.3 Configuring the gas composition

- 1 Log on as "Authorized user" (→ p. 88 § 2.1.7).
- 2 Start the configuration mode (→ p. 88).
- 3 Switch to submenu "Conversion/Gas composition" in the FLOWSiC500 menu.
- 4 Set the parameters to characterize the gas to be measured according to the selected Krumholz calculation method.

**NOTE:**

Configuration of gas composition may only be changed once a day. More frequent changes may damage the internal parameter memory (EEPROM) and thus shorten the service life of the FLOWSiC500.



Parameter changes of the gas composition are stored in the Gas composition logbook.

The Gas composition logbook can be viewed using the FLOWgate™ operating software (menu "Logbook management" → "Gas composition logbook").

4.2.4 Checking the device status

Make sure the FLOWSiC500 is in error-free operating status:

- 1 Log on as "Authorized user" (→ p. 88 § 2.1.7).
- 2 Check whether warnings or errors are shown in the symbol bar on the display.



The device has a warning.
The FLOWSiC500 is in "Warning" status.



The device has an error.
The FLOWSiC500 is in "Malfunction" status.

- 3 If warnings or malfunctions exist, change to view "Current events" on the main display:
 - Clear existing malfunctions (→ p. 104 § 2.2 "Status messages").
 - Contact Endress+Hauser Customer Service for any malfunctions you cannot clear yourself (→ p. 104 § 2.1 "Contacting Customer Service").
- 4 The event overview can be reset when all warnings and errors have been cleared (→ p. 100 § 2.2.12).

4.2 Commissioning with the FLOWgate™ operating software

4.2.1 Connect to the device

A data connection can be established with the device using the optical data interface and the infrared USB adapter HIB-04 (Part No. 0055502).

This interface serves to configure the FLOWgate500. The infrared USB adapter has a USB 2.0 interface. This interface provides the connection to the PC and transfers the FLOWgate500 data.



Device driver software must first be installed to operate the adapter on a PC. The device driver software is available for download.

1. Install the device driver software before connecting the USB plug to the PC.
2. Connect the USB plug to the PC.
3. Fit the infrared USB adapter to the infrared interface as shown. (→ Fig. 37) a magnet integrated in the reading head retains the adapter.

Fig. 37 Alignment of the infrared adapter

Correct alignment



Wrong alignment



4. Install the FLOWgate™ operating software.
The FLOWgate™ operating software and the associated Manual are also available on the manufacturer website.
5. Press any button on the display to activate the optical data interface on the FLOWgate500.
When a connection has been established with the infrared USB adapter, the optical data interface on the FLOWgate500 remains active until the infrared USB adapter is removed.
6. The display and the optical interface remain active during the connection.
7. Click on the FLOWgate™ icon to start FLOWgate™. 
8. Add the FLOWgate500 to the Device Manager of the FLOWgate™ operating software and create a connection to the device.
9. Login as "Authorized User" on the device.



Standard password for "Authorized User": 0000

10. Start the field setup wizard and follow the step-by-step instructions.

4.3.1 Field setup wizard

**NOTICE**

Configuration mode must be active to change parameters.

- Click on the symbol in the toolbar to activate configuration mode.

4.3.1.1 Device identification

- Obtain the device serial number and type code. Compare the serial against the type code.
- Enter a device name. The device name is freely selectable.

4.3.1.2 System/ User

Date and time

- Enter the date and time to synchronize with the PC.

After completing commissioning, the daylight saving time settings can be activated and configured, see – p. 78, § 4.3.3.

User management**NOTICE**

Enforce-House recommends changing the initial password provided for the "Authorized User" for security reasons.

Former users can be activated here when desired:

- Activate the associated checkbox of the desired user.
 - Specify a password. The password must comprise 4 digits. Up to three users and three authorized users can be activated. "Authorized User 1" and "User 1" are always activated.
- For access rights for single user levels, see – p. 22, § 2.3.3.

Fig. 18

Example

User management		
User	Active	Password
User 1	☒	1234
User 2	☒	5678
Authorized User 1	☒	9012
Authorized User 2	☒	3456
Authorized User 3	☒	7890

4.2.2.3 Warnings

The "Warnings" area serves to set the limit values outside of which the FLOWSiC500 is to output warnings (flow rate) or errors (pressure and temperature).

Limit values can be set for:

- Flow rate
- Pressure
- Temperature
- Reverse flow volume (buffer volume)
- Limit value for low flow rate (reverse cutoff)

In addition, the warnings signaled by the device can be individually activated or deactivated in the "User warnings activation" area.

The Gas Quality indicator shows the gas quality to be monitored in real time. By clicking on "Set reference point" the reference point is set automatically based on the current measured values. The permissible deviation in percent can be configured. If the limit value is exceeded or fallen below, the FLOWSiC500 generates a warning. Setting the reference point requires that gas of typical quality flows through the FLOWSiC500. If this is not given during commissioning, the reference point can be set afterwards in the menu "Parameter modification, Warnings".

4.2.2.4 Gas Quality Indicator



4.2.2.4 Communication

- The configuration of the single plug-in connectors is preset according to the configuration ordered. Check the configuration and adapt when necessary.
- For pulse outputs, the maximum frequency and the minimum pulse width must be set during commissioning.
- The status outputs are configured as standard so that status "Measurement invalid" is output. Selecting status "Measurement valid" shortens the battery service life considerably because the output is then permanently activated.

Plug-in Boarded

- Configuration as status or pulse output possible. Select the desired configuration.
- Enter the maximum frequency and minimum pulse width in the "Pulse 1" area when configuring as a pulse output.

When configured as a pulse output, make sure the exceeded frequency of 5208 Q_{NOM} is covered and the connected device understands the frequency.

The following conditions must be satisfied:

- The "Maximum frequency" must be set to a value higher or equal to the "Frequency at Q_N".
- The "Minimum pulse width" must be set to a value lower or equal to $1/(2 \times \text{Frequency at } Q_N)$.

Example

Frequency at Q = 332 Hz

Maximum frequency:

Set "Maximum frequency" to a value $\geq$ 332 Hz

Recommendation: Round up to 400 Hz.

Minimum pulse width:

1 Hz corresponds to 1000 ms

332 Hz corresponds to 3.0 ms

$1/3 = \text{"Frequency at Q"} = 1.3 \text{ ms}$

Set "Minimum pulse width" to an integer value $\geq$ 1.3 ms.

Recommendation: set 1 ms.

Fig. 42

Rules settings example**Plug 2: A-coded**

- Configuration as status or pulse output possible. Select the desired configuration.
- Enter the maximum frequency and minimum pulse width in the "Pulse 2" area when configuring as a pulse output.
For configuration, see Section "Plug 1: B-coded".

Communication tests

- **Pulse output:**
 - Enter the desired test frequency.
 - Push the slider to "On" to start the test. The test frequency is output on all pulse outputs.

Fig. 43

Rules output test

- **Flow rate:**
 - Enter the desired test flow rate and start the test.
- **Digital output:**
 - Select the desired digital output.
 - Push the slider to "On".

- 4.2.2.6: Volume correction (only for device option volume correction)
 For a detailed description of the single parameters, see the FLOWSiC500 menu description, p. 55.5.2.2.5.
- Determine the reference values.
 - Enter the specifications for gas characteristics.
 - Select the algorithm and parameters for calculating the compressibility factor.
 - Enter fixed values.

4.2.2.8: Totalizers

Totalizers

- Setting on resetting the totalizer levels.
- Determine the limits for the reference flow volume.

Meter settings

- Configure the significant digits for the meters:
 All meters have up to 9 significant digits without sign. The number of significant digits can be varied between 0 to 9.
- Determine the resolution for the meters:
 The splitter resolution can be set in the range 0.001 to 100 in increments of factor 10 for the volume at flowing conditions and the volume at base conditions of the meter. It is therefore necessary to multiply the totalizer level with the corresponding splitter resolution to interpret the totalizer level.



NOTICE

The totalizer levels are stored in the unit system set in the device. The unit and resolution are stored in the data records so that the logbooks remain constant when these settings are changed and need not be reset.

All totalizer levels are deleted when the unit or splitter resolution are changed.

4.2.2.9: Completion

- If desired, empty the logbooks and archive:
 - Activate the function of the logbooks or archive to be emptied.
 - Click "Clear selected".
- Check the collection status. If desired, reset the Event overview.
- Create a Parameter report:
 - Click "Create Parameter report". The report is generated.
 - File the report with the device documentation.

4.3.2 Activate and configure the daylight saving time

**NOTICE**

If the optional feature "Load recording device with maximum load display" feature is activated, the periods for daylight saving time are preset at the factory for 10 years.

The periods for daylight saving time must be updated before the preset time expires. This is the responsibility of the plant operator.

To ensure that the archive entries are displayed correctly, the last two years must be retained when updating.

1. Open the file "System User" in the "Parameter Modification" area.
2. Activate Configuration mode.
3. Activate the daylight saving time.

Fig. 42 Activating the daylight saving time settings



4. Click to enter a new time period for daylight saving time.
5. Use the arrow buttons to set the start of the daylight saving time:
The FLOWgate™ operating software always increases or reduces the position you clicked beforehand, e.g. the month is increased when the month is clicked. The year is increased when the year is clicked. The FLOWgate™ operating software increases the day by 1 when the text box is not clicked.
The date can also be entered using the keyboard.

Fig. 43 Setting the time period for the daylight saving time



6. Then set the end of the daylight saving time.
7. Click "Write to device" to write the daylight saving time to the FLOWiCS500.
8. Enter future time periods when desired. Daylight saving time start and end can be configured for up to 10 years in advance.

4.5.4 Configure the power management

Select the type of power supply corresponding to the configuration of the Fluxus1500:

- **Dynamic Mode (External + Backup):**
Measuring rate: 4 Hz
- **Battery Mode (2 x Battery):**
Measuring rate: 1 Hz, to maximize the battery service life.
- **Boo Mode (External + Backup):**
Standard setting: Measuring rate is 4 Hz when the external voltage supply is available.
The measuring rate is set automatically to 1 Hz if the external voltage supply fails in order to maximize the backup battery service life.

Fig. 44: Boost management



4.2.8 Function check after commissioning

- Check the device status.


Task 22 Signaling the device status in FLOWgate™

Status	Description
	Normal operation, no error/warnings generated and
	Device status warning: At least one warning is pending (if the device the master/slave is in error)
	Device status error: At least one error is pending in the device, the master/slave is in error.

- Click on the symbol in the Status bar when warnings or errors arise:
The current Status overview opens and shows details and information on how to proceed.

5.1 Control unit

Fig. 45



- 1 Display
- 2 Buttons
- 3 Touch data interface

5.2 Operating using the display

- Press any button to switch the display on.



In battery operation, the display and the optical data interface have a timeout and switch off after approx. 60 seconds (default setting) when no button has been pressed and no data transmission takes place. The display and the optical interface are permanently active when an external power supply is connected.

Table 25 Buttons

	In menu	In Edit mode
ESC	Returns to next higher level of the operator menu	Adopts input of new value and returns to the next higher level of the operator menu
←	Toggles between single menu entries on one level	Increments or decrements a parameter by 1, toggles between several selection options
ENTER	Calls a submenu, starts edit mode	Confirms an input

6.2.2 Display in the symbol bar

Table 24

Symbol	Significance	Description
	External power supply	On: displayed when the device is configured with external power supply.
	Battery full level: battery 1	Displayed when the FUDM500 is configured for battery operation. Status of the first battery pack. Details on the battery full level → p. 53, § 5.2.2.
	Battery full level: battery 2	With external power supply: Battery battery status. With battery operation: Second battery pack status. Details on the battery full level → p. 53, § 5.2.2.
	Device status: malfunction	The device has entered the measured value is invalid.
	Device status: warning	The device has a warning the measured value is still valid.
	Registered event	Events have occurred since the last event summary reset.
	Parameter locking symbol: locked	Warning: relevant parameters are protection against changing: modifications are registered in the history logbook → p. 51, § 2.3.2.
	Parameter locking symbol: open	Warning: relevant parameters can be changed, the modifications are not saved in the history logbook.
	Configuration mode	Device parameters can be changed.
	NOTICE	
	NOTICE	If device status "malfunction" or "warning", the respective symbols are shown turning on the display.

6.2.2 Battery full level display

The battery symbol changes as the battery is discharged.

Table 25

Battery full level display:

	Battery full level > 75%
	Battery full level > 50%
	Battery full level > 25%
	Battery full level > 25%
	Battery almost empty, but still in use

- The last segment of the battery symbol starts to blink when the battery full level drops below 20%.
- When the battery is completely empty, the empty battery symbol blinks and the FUDM500 has switched to the second battery.

3.1.2 Main screen (without device option volume conversion)

- Use buttons  and  to toggle between the menu entries on a level.
- Press ENTER to go down the menu level.

Main display:

The following information is displayed on the top display menu level:

Item 0400	Description
V 00000000 m³ 20.08.2021 10:30:52	V = Volume Absolute, cannot be reset → Pressing ENTER opens the FLOW-510500 menu.
err 00000000 m³ 20.08.2021 10:30:52	err = Error volume, volume consumed during a malfunction, can be reset → Pressing ENTER opens the action "Reset error volume" → "Resetting the error volume" (p. 100).
Q 0.000 m³/h 0.000 m³/h	Q = information VOC = Gas density
Current events 1 Event	Current events: 1 event is reported → Pressing ENTER opens a list of currently reported events. Use the arrow buttons to toggle through the reported events.
Event Summary 2 Events	Stored status messages: Events since the last time the event summary was reset (2 events have occurred). → Pressing ENTER opens a list of stored events. Use the arrow buttons to toggle through the stored events.
Last Event Reset 20.08.2021 10:30:52	Last reset of event summary → Pressing ENTER opens the action "Reset Event Summary" → "Resetting the event summary" (p. 100).
 NOTE	A gas meter with Malfunction status is shown on the display by a blinking acceleration mark after the gas meter (e.g. 0/0)

Menu navigation (without device option volume conversion)

Some menu functions are only available when you are logged in with user name "user" or "authorized user".

user name	0	Sub-parameter	=	user (1)	41	Authorized user (1)
				user (2)	42	Authorized user (2)
				user (3)	43	Authorized user (3)
Access group	-	Index	=	key	•	Default
Ref.	0	1	2	3	4	5
Main status: Volume under measurement conditions V						
FLOW51000 main: User	0	0	0	0	0	0
Logged in user name	0	0	0	0	0	0
Login	0	0	0	0	0	0
Logout	0	0	0	0	0	0
FLOW51000 main: Device name	0	0	0	0	0	0
Calculation mode	0	0	0	0	0	0
Conversion mode	0	0	0	0	0	0
FLOW51000 main: Device information	0	0	0	0	0	0
Measuring port	0	0	0	0	0	0
Serial number	0	0	0	0	0	0
Firmware version	0	0	0	0	0	0
Firmware date	0	0	0	0	0	0
Firmware CQC	0	0	0	0	0	0
Warning: CQC	0	0	0	0	0	0
Unit: open pressure	0	0	0	0	0	0
Unit: open absolute	0	0	0	0	0	0
Water level	0	0	0	0	0	0
Regulation (1) (Hz)	0	0	0	0	0	0
Water level 2	0	0	0	0	0	0
FLOW51000 main: System settings	0	0	0	0	0	0
Over supply (1) (%)	0	0	0	0	0	0
Over supply (2) (%)	0	0	0	0	0	0
Data	0	0	0	0	0	0
Time	0	0	0	0	0	0
Pressure	0	0	0	0	0	0
Language	0	0	0	0	0	0
Symbol	0	0	0	0	0	0
Unit set	0	0	0	0	0	0
FLOW51000 main: Upgrades	0	0	0	0	0	0
Firmware upgrade	0	0	0	0	0	0
List of stored errors	0	0	0	0	0	0
Firmware upgrade	0	0	0	0	0	0
Warning: upgrade	0	0	0	0	0	0
Main status: Error volume set	0	0	0	0	0	0
Main status: Volume free under measurement conditions / gas select	0	0	0	0	0	0
Main status: Current Error	0	0	0	0	0	0
List of current errors	0	0	0	0	0	0
Main status: Error Summary	0	0	0	0	0	0
List of stored errors	0	0	0	0	0	0
Main status: Last Error Reset	0	0	0	0	0	0

5.2.4 Main display (with device option volume conversion)

- Use buttons $\leftarrow$ and $\rightarrow$ to toggle between the menu entries on a level.
Press ENTER to go down one menu level.



The symbols on the display are shown as standards in accordance with EN13403.
Symbols with regional deviations can be configured.
These operating instructions use symbols in accordance with EN13403.

Main display (with device option volume conversion)

The following information is displayed on the top display menu level:

Main display	Description
v_0 000000000 m³ 20.08.2021 10:30:52	v_0 = Volume at base conditions, interrupted
Pressing ENTER opens the FilterDCS20 menu.	
v_{int} 000000000 m³ 20.08.2021 10:30:52	v_{int} = Error volume at base conditions
Pressing ENTER shows the action "Reset error volume". → "Resetting the error volume" (in 100%).	
$v_{calc} v_0$ 000000000 m³ 20.08.2021 10:30:52	$v_{calc} v_0$ = Total volume at base conditions = $v_0 + v_{int}$
v_0 000000000 m³ 20.08.2021 10:30:52	v_0 = Total volume at measurement conditions
$v_{int} v_0$ 000000000 m³ 20.08.2021 10:30:52	$v_{int} v_0$ = Error volume (volume occurred at measurement conditions, during a malfunction, can be reset)
Q 0.000 m³/h Q_0 0.000 m³/h	Q = Volume flow at measurement conditions Q_0 = Volume flow at base conditions
Q_{DC} 410.00 m³/h Q_{DC} 3.000 m³/h	Q_{DC} = Sound velocity currently measured Q_{DC} = Gas velocity currently measured

Item (page)	Description
P 1.532 bar T 25.42 °C	P = Pressure currently used for volume conversion T = Temperature currently used for volume conversion
C 25.7268 K 0.9581	C = Conversion factor K = Compressibility factor
B 9.98830 sk 0.98812	Z = Compression factor at measurement conditions currently used for volume conversion Zk = Compression factor at base conditions currently used for volume conversion
Current events 1 Event	Current events (1 event is reported) → Pressing ENTER opens a list of current reported events. Use the arrow buttons to toggle through the reported events.
Event Summary 2 Events	Event status messages Events since the last time the event summary was read (2 events have occurred). → Pressing ENTER opens a list of stored events. Use the arrow buttons to toggle through the stored events.
Last Event: Error 28.08.2021 19:30:52	Last read of event summary → Pressing ENTER opens the action "Reset Event Summary" → "Resetting the event summary" (p.100)
 NOTICE	A parameter with Malfunction status is shown on the display in a blinking indication mark after the parameter (e.g. Z, Q).

Menu navigation (with device option volume conversion)

Some menu functions are only available when you are logged in with user level "User" or "Automated User".

User level	2	3	4	5	6	7	8	9	0	Function
Access point	1	2	3	4	5	6	7	8	9	0
Path	1	2	3	4	5	6	7	8	9	0
Menu display: Base station 1A	1	2	3	4	5	6	7	8	9	0
FLOWSTAR500 menu: User	1	2	3	4	5	6	7	8	9	0
Logged-on user	1	2	3	4	5	6	7	8	9	0
Log on	1	2	3	4	5	6	7	8	9	0
Log off	1	2	3	4	5	6	7	8	9	0
FLOWSTAR500 menu: Factory menu	1	2	3	4	5	6	7	8	9	0
Calibration mode	1	2	3	4	5	6	7	8	9	0
Configurator mode	1	2	3	4	5	6	7	8	9	0
FLOWSTAR500 menu: Device information	1	2	3	4	5	6	7	8	9	0
Measuring port	1	2	3	4	5	6	7	8	9	0
Serial number	1	2	3	4	5	6	7	8	9	0
Firmware version	1	2	3	4	5	6	7	8	9	0
Firmware date	1	2	3	4	5	6	7	8	9	0
Firmware CRC	1	2	3	4	5	6	7	8	9	0
Measuring CRC	1	2	3	4	5	6	7	8	9	0
Min. port pressure	1	2	3	4	5	6	7	8	9	0
Max. port pressure	1	2	3	4	5	6	7	8	9	0
Water factor	1	2	3	4	5	6	7	8	9	0
Pressure at 0	1	2	3	4	5	6	7	8	9	0
Water factor 2	1	2	3	4	5	6	7	8	9	0
FLOWSTAR500 menu: System settings	1	2	3	4	5	6	7	8	9	0
Power supply 1	1	2	3	4	5	6	7	8	9	0
Power supply 2	1	2	3	4	5	6	7	8	9	0
Date	1	2	3	4	5	6	7	8	9	0
Time	1	2	3	4	5	6	7	8	9	0
Timezone	1	2	3	4	5	6	7	8	9	0
Language	1	2	3	4	5	6	7	8	9	0
Alarms	1	2	3	4	5	6	7	8	9	0
Off-time	1	2	3	4	5	6	7	8	9	0
FLOWSTAR500 menu: Examples	1	2	3	4	5	6	7	8	9	0
Example: Reference	1	2	3	4	5	6	7	8	9	0
Boiler pressure	1	2	3	4	5	6	7	8	9	0
Boiler temperature	1	2	3	4	5	6	7	8	9	0
Infl. conditions	1	2	3	4	5	6	7	8	9	0
Atmospheric pressure	1	2	3	4	5	6	7	8	9	0
Example: Calculator	1	2	3	4	5	6	7	8	9	0
Calc. method	1	2	3	4	5	6	7	8	9	0
Calc. interval	1	2	3	4	5	6	7	8	9	0
K-factor floor	1	2	3	4	5	6	7	8	9	0
Example: Gas composition	1	2	3	4	5	6	7	8	9	0
Safety: why? gas	1	2	3	4	5	6	7	8	9	0
Reference: Safety	1	2	3	4	5	6	7	8	9	0
Recipe: sample	1	2	3	4	5	6	7	8	9	0
CO2 (mole%)	1	2	3	4	5	6	7	8	9	0
H2 (mole%)	1	2	3	4	5	6	7	8	9	0
H2 (mole%)	1	2	3	4	5	6	7	8	9	0
Heating tank	1	2	3	4	5	6	7	8	9	0
Heating amount	1	2	3	4	5	6	7	8	9	0
FLOWSTAR500 menu: Pressure parameters	1	2	3	4	5	6	7	8	9	0

Path	C	D	NOV	W	Separator
p Sensor type	0	0	0	0	
p Sensor serial number	0	0	0	0	
p Local alarm limit	0	0	0	0	
p Local alarm limit	0	0	0	0	
p Default risk	0	0	0	0	
p Unit	0	0	0	0	
p Adjust offset	0	0	0	0	
p Adjust factor	0	0	0	0	
F1500S500 main: Temperature parameters	0	0	0	0	-0.50 \$12.07
T Sensor type	0	0	0	0	
T Sensor serial number	0	0	0	0	
T Local alarm limit	0	0	0	0	
T Local alarm limit	0	0	0	0	
T Default risk	0	0	0	0	
T Unit	0	0	0	0	
T Adjust offset	0	0	0	0	
T Adjust factor	0	0	0	0	
F1500S500 main: Airgates	0	0	0	0	
Batt. input	0	0	0	0	
Alarm input	0	0	0	0	
Alarm input	0	0	0	0	
Alarm input	0	0	0	0	
Gas concentration input	0	0	0	0	
F1500S500 main: Alarms	0	0	0	0	-0.50 \$12.08
Configuration	0	0	0	0	
Gas type	0	0	0	0	
Gas type	0	0	0	0	
Measuring period	0	0	0	0	
Measuring period alarm	0	0	0	0	
Alarm alarm	0	0	0	0	
List of alarm alarm	0	0	0	0	
Alarm alarm	0	0	0	0	
List of alarm alarm	0	0	0	0	
F1500S500 main: Maximum size	0	0	0	0	-0.50 \$12.09
Current period	0	0	0	0	
List of observed data	0	0	0	0	
Current period	0	0	0	0	
List of observed data	0	0	0	0	
Main status: air/V	0	0	0	0	-0.50 \$12.10
Main status: battery	0	0	0	0	
Main status: air/V	0	0	0	0	
Main status: air/V	0	0	0	0	
Main status: 0/00	0	0	0	0	
Main status: 004/000	0	0	0	0	
Main status: 0/7	0	0	0	0	
Main status: 0/00	0	0	0	0	
Main status: 2/00	0	0	0	0	
Main status: Current Events	0	0	0	0	
List of current events	0	0	0	0	
Main status: Event Summary	0	0	0	0	
List of event events	0	0	0	0	
Main status: Last Event Report	0	0	0	0	-0.50 \$12.11

3.2.8 Configuration of main display

The configuration of the main display can be performed using the FLOWgate™ operating software.

The following contents are available:

- Empty (line 1 - set at the factory)
- Date, time (line 2 - set at the factory)
- Pressure p
- Temperature T
- Conversion factor C
- Compressibility factor K
- Operational flow rate Q
- Flow rate Q relative to the base conditions
- VOG
- SOG

Configuring

1. Connect to device. → p. 75, § 4.3.1.
2. Open the file "System/user" in the "Parameter Modification" area.
3. Start the configuration mode.
4. Select the desired parameters in the selection boxes "Contents display line" and "Contents bottom display line".
5. Click "Write to device".
The parameters are written to the device and the display contents adjusted to match the selection.
6. Return to the operating mode.

3.2.9 FLOWICS00 menu

3.2.9.1 User

```
User:          logged in user (see "intro/entry" field)
               → "Changing the user area" (p. 55)

Logged in as:
• User (1)
• User (2) *
• User (3) *
• Authorized user (1)
• Authorized user (2) *
• Authorized user (3) *

* when activated
```

3.1.5.2 Device mode

Calibration mode	Display whether calibration mode for the flow rate when is switched on or off, starting and calibration mode. In calibration mode, message "CALIBRATION MODE" shown on the main display with the meter factor not effective for the calibration (set at the factory). The FLOWSTAT500 outputs test pulses with the maximum possible frequency of 2 kHz and 20% Q max. on digital switching output DO_1 (= e.g. 3.1, 3.14 & 3.1). For flow rate check and calibration, see document "SIS3000: Calibration Instructions for the Universal Set Flow Meter FLOWSTAT500".
Configuration mode	Display whether configuration mode is switched on or off. Starting and terminating configuration mode. → "Start configuration mode" (p. 55)

3.1.5.3 Device information

Measuring port	Measuring port identifier
Serial number	Device serial number
Firmware version	Firmware version installed on the device
Firmware data	Firmware release code
Firmware CRC	Firmware check sum
Measuring CRC	Checksum of hydrologically relevant parameters
Min. static pressure	Minimum static pressure
Max. static pressure	Maximum static pressure
Meter factor	Factor (selected) relation between frequency and flow rate (l/min/m ³)
Frequency at Q	Frequency for measured flow rate Q = 1.2 Q _{max}
Meter factor 2	Factor (selected) relation between frequency and flow rate (l/min/m ³) for second pulse output for interface configuration 1, 2 & 1P pulse

3.1.5.4 System settings

Power supply (1)	- For battery operation: - Fit size for battery pack 1 (fit) - Confirm battery exchange for battery pack 1 → "Confirming battery replacement" (p. 60) - With external power supply: - Display 100% → "Checking the external power supply" (p. 101)
Power supply (2)	- For battery operation: - Fit size for battery pack 2 (fit) - Confirm battery exchange for battery pack 2 → "Confirming battery replacement" (p. 60) - With external power supply: - Fit size for second battery - Confirm battery exchange for second battery → "Confirming battery replacement" (p. 60)
Date	Device date → "Commissioning on the display" (p. 70)
Time	Device time → "Commissioning on the display" (p. 70)
Time zone set on device	Time zone set on device
Language	Language for displays Available: English, German, Russian → "Setting the language" (p. 55)

Errors according to	Switches for the measuring screens, the setting can be changed with the FLOWgate® operating software.			
	Gas flow meter			
	EX12405	F58	S027	AP
Volume total	V	V	S	Q
Error volume	errV	errV	errV	errV
Flow rate	Q	Q	Q	Q
Velocity of gas	UG	UG	UG	UG
Speed of sound	CG	CG	CG	CG
Gas flow meter with volume correction				
	EX12405	F58	S027	AP
Volume (measured) total	VG	VG	S	Q
Error volume (measurement)	errVG	errVG	errV	errV
Volume (base) without interruption	V0	V0	S0	V0
Error volume (base)	errV0	errV0	errV0	errV0
Volume (base) total	VG0	VG0	VG0	VG0
Flow rate (measurement)	Q	Q	Q	Q
Flow rate (base)	Q0	Q0	Q0	Q0
Pressure (measurement)	P	P	P	P
Pressure (base)	P0	P0	P0	P0
Temperature (measurement)	T	T	T	T
Temperature (base)	T0	T0	T0	T0
Velocity of gas	UG	UG	UG	UG
Speed of sound	CG	CG	CG	CG
Compressibility	Z	Z	Z	Z
Correction factor	C	C	C	C
Correction factor (measurement)	Z	Z	Z	Z
Correction factor (base)	Z0	Z0	Z0	Z0
Lib test	Done; fail – "Testing the device" (p. 50)			

5.2.53 Conversion (only for device types with volume conversion)

Reference

East pressure	East pressure (unit acc. to display)																												
East temperature	East temperature (unit acc. to display)																												
Ref. conditions	Reference conditions for density and heating value Droplet: T1, T2, p2																												
	T1 = Reference temperature, heating value T2 = Reference temperature, air density, reference density p2 = Reference pressure, air density, reference density																												
	<table><tr><td></td><td>T1</td><td>T2</td><td>p2</td></tr><tr><td>Ref. 1</td><td>15 °C</td><td>0 °C</td><td>1.01325 bar(a)</td></tr><tr><td>Ref. 2</td><td>0 °C</td><td>0 °C</td><td>1.01325 bar(a)</td></tr><tr><td>Ref. 3</td><td>15 °C</td><td>15 °C</td><td>1.01325 bar(a)</td></tr><tr><td>Ref. 4</td><td>60 °F</td><td>60 °F</td><td>14.7347 ps(a)</td></tr><tr><td>Ref. 5</td><td>60 °F</td><td>60 °F</td><td>14.7300 ps(a)</td></tr><tr><td>Ref. 6</td><td>25 °C</td><td>20 °C</td><td>1.01325 bar(a)</td></tr></table>		T1	T2	p2	Ref. 1	15 °C	0 °C	1.01325 bar(a)	Ref. 2	0 °C	0 °C	1.01325 bar(a)	Ref. 3	15 °C	15 °C	1.01325 bar(a)	Ref. 4	60 °F	60 °F	14.7347 ps(a)	Ref. 5	60 °F	60 °F	14.7300 ps(a)	Ref. 6	25 °C	20 °C	1.01325 bar(a)
	T1	T2	p2																										
Ref. 1	15 °C	0 °C	1.01325 bar(a)																										
Ref. 2	0 °C	0 °C	1.01325 bar(a)																										
Ref. 3	15 °C	15 °C	1.01325 bar(a)																										
Ref. 4	60 °F	60 °F	14.7347 ps(a)																										
Ref. 5	60 °F	60 °F	14.7300 ps(a)																										
Ref. 6	25 °C	20 °C	1.01325 bar(a)																										
Atmospheric pressure	Ambient pressure (unit acc. to display) must be required for device with relative pressure sensor																												

Calculation

Calculation method	Calculation method for the compressibility factor Select from: • ISO8000 • AGA 8 Qmax method 1 • AGA 8 Qmax method 2 • AGA 11-19 • AGA 11-19 mod. • AGA 11-19 mod. GOSF • GERG21 mod. • AGA-8 QCC • Real gas
Calculation interval	Cycle time for updating measured values (pressure, temperature), calculation of the compressibility factor Select from: 3 s, 15 s, 30 s, 60 s
k-factor (kval)	Enter k/f factor for method "Real gas" when the calculation of the k-factor is incorrect.

Gas composition (only for device option volume conversion)

Density unit type	Select from: Reference density, real gas density Either mass flow "Reference density" or mass flow "Relative density" is displayed depending on the selection.
Reference density	Gas reference density under reference conditions
Relative density	Relative density, relation between gas density and air density under reference conditions
CO2	CO ₂ - proportion in gas (mol%)
N2	N ₂ - proportion in gas (mol%)
H2	H ₂ - proportion in gas (mol%)

H Heating value	Gas heating value reference conditions
H Heating value unit	Heating value unit Select from: Default, MJ/m ³ , mm ³ /m ³ , BTU/m ³
	Default = Standard setting according to selected unit system (SI or Imperial), configured in accordance with the boiler



The calculation method selected determines the permissible error limits for gas proportions as well as pressure and temperature

3.1.6.6 Pressure parameters (only for device option volume conversion)

P Sensor type	Display of configured pressure sensor
P Sensor serial number	Pressure sensor serial number expected by the device, preset
P Lower alarm limit	Lower alarm limit for pressure sensor
P Upper alarm limit	Upper alarm limit for pressure sensor
P Default value	Fixed value for measurement pressure (unit acc. to display) The entry value is used as fixed value for configuration as to conversion and for pressure measurement functions
P Unit	Unit for pressure sensor used for entry and display Select from: Default: bar, gPa, kPa, MPa, kg/cm ² , mmHg Default = Standard setting according to selected unit system (SI or Imperial), configured in accordance with the boiler
P Adjust offset	Calculation offset for pressure sensor (unit acc. to display)
P Adjust factor	Calculation factor for pressure sensor

3.1.6.7 Temperature parameters (only for device option volume conversion)

T Sensor type	Display of configured temperature sensor
T Sensor serial number	Temperature sensor serial number expected by the device, preset
T Lower alarm limit	Lower alarm limit for temperature sensor
T Upper alarm limit	Upper alarm limit for temperature sensor
T Default value	Fixed value for measurement temperature (unit acc. to display) The entry value is used as fixed value for functions of temperature measurement
T Unit	Unit for temperature values, used for entry and display Select from: Default: °C, °F, K, °R Default = Standard setting according to selected unit system (SI or Imperial), configured in accordance with the boiler
T Adjust offset	Calculation offset for temperature sensor (unit acc. to display)
T Adjust factor	Calculation factor for temperature sensor

3.1.6.8 Logbooks

E Event logbook	Number of entries currently stored; max. number Pressing ENTER opens the detailed view. The detailed view shows the event type, a short text and the timestamp
F Parameter logbook	Number of entries currently stored; max. number
M Malfunction logbook	Number of entries currently stored; max. number
G Gas composition logbook	Number of entries currently stored; max. number

5.2.53: Archived (only for device option volume conversion)

Configuration

DayStart	Setting hour for the day archive Entry range: 00:00 ~ 23:59 Default: 00:00
DayEnd	Setting day for month archive Measuring night: 1 ~ 28 Default: 1
MeasuringPeriod	Defines the period for the daily archive Select from: 5 min, 5 min, 15 min, 20 min, 60 min Default: 60 min

Measuring period archive

Set of entries	Entry 0: Entry total time stamp 0 ~ 9999: Checksum status OK (0) / Error (1)
Total time	Entry: time stamp To start the action of the search function, press ENTER.
Entry ID	Entry ID: identical to the ID in full data archive To start the action of the search function, press ENTER.
Entry status	Status as a hex value and verbal "valid/not valid"
Device status	Cumulative system status at the time of the end of the measuring period
V0100	Volume at base conditions V ₀ , counter reading To start the action of the search function, press ENTER.
V0100%	V ₀ counter progress of the measuring period
V05000	Error volume at base conditions V ₀
V05000%	V ₀ counter progress of the measuring period
V0100F	Volume at measurement conditions V _m , counter reading
V0100F%	V _m counter progress of the measuring period
V05000F	Error volume at measurement conditions V _m , counter reading
V05000F%	V _m counter progress of the measuring period
Q0100%	Maximum flow rate at base conditions during measuring period
Q0100F	Maximum flow rate at measurement conditions during measuring period
p0100%	Maximum gpd
p0100F	Minimum pressure during measuring period
p0100	Average pressure and temperature (flow-weighted)
W0100	Average compressibility and conversion factor (flow-weighted)
Q0100%	Average speed of sound
FlowTime	Residual time with Q > LowFlowCutOff

Daily archive

Start time (S...500)	Entry 1: Entry index, time stamp On-board status OK or invalid
Date/Time	Entry time stamp To start the editor of the search function, press ENTER
Entry ID	Entry ID, identical to the ID in FLOWgate editor To start the editor of the search function, press ENTER
Entry status	Status as a text value and vector "valid, invalid"
Device status	Cumulative system status at the time of the end of the day
V0%	Volume at base conditions V_0 counter-reading To start the editor of the search function, press ENTER
V0%	V_0 counter progress of the day (D)
V0B(D)	Base volume at base conditions *% V_0
V0B(D)2	*% V_0 counter progress of the day
V0%	Volume at measurement conditions V_m counter-reading
V0%	V_m counter progress of the day
V0B(D)	Base volume at measurement conditions *% V_m counter-reading
V0B(D)2	*% V_m counter progress of the day
Q0%	Maximum flow rate at base conditions during day
Q0% / Data/Time	Timestamp of maximum flow rate at base conditions during day
Q0%	Minimum flow rate at base conditions during day
Q0% / Data/Time	Timestamp of minimum flow rate at base conditions during day
Q0%	Maximum flow rate at measurement conditions during day
Q0% / Data/Time	Timestamp of maximum flow rate at measurement conditions during day
Q0%	Minimum flow rate at measurement conditions during day
Q0% / Data/Time	Timestamp of minimum flow rate at measurement conditions during day
P0%	Maximum pressure during day
P0% / Data/Time	Timestamp of maximum pressure during day
P0%	Minimum pressure during day
P0% / Data/Time	Timestamp of minimum pressure during day
P0%	Average pressure during day (flow-weighted)
T0%	Average temperature during day
T0%	Maximum temperature during day
T0% / Data/Time	Timestamp of maximum temperature during day
T0%	Minimum temperature during day
T0% / Data/Time	Timestamp of minimum temperature during day
K0%	Average compressibility and correction factor (flow-weighted) during day
CO0%	Average speed of sound during day

Monthly archive

VolArchive (2...25)	Entry 2: Entry index, timestamp Checksum status: 0: no archive
Date/Time	Entry timestamp To start the editor of the season function, press 5/TEMP
Entry ID	Entry ID: identical to the ID in Fullgate Archive To start the editor of the season function, press 5/TEMP
Entry status	Status as a raw value and value "valid/invalid"
Device status	Current equipment status at the time of the end of the month
V0Vol	Volume at base conditions V_0 , counter reading To start the editor of the season function, press 5/TEMP
V0Prog	V_0 counter progress per month (lit)
V0Max	Maximum progress of V_0 per measuring period
V0Max T Date/Time	Timestamp of maximum progress of V_0 per measuring period during month
V0Day	Maximum progress of V_0 per day during month
V0Day T Date/Time	Timestamp of maximum progress of V_0 per day during month
V0Env	Score value at base conditions ΦV_0
V0EnvVol	ΦV_0 counter progress of the month
V0EnvT	Volume at measurement conditions V_0 , counter reading
V0EnvT	V_0 counter progress of the month
V0EnvT	Maximum progress of V_0 in a measuring period of the month
V0EnvT T Date/Time	Timestamp of maximum progress of V_0 in a measuring period of the month
V0Day	Maximum progress of V_0 in a day of the month
V0Day T Date/Time	Timestamp of maximum progress of V_0 in a day of the month
V0EnvVol	Score value counter-gather ΦV_0 (Zählwert)
V0EnvVol	ΦV_0 counter progress of the month
QVol	Maximum flow rate at base conditions during month
QVol T Date/Time	Timestamp of maximum flow rate at base conditions during month
QVol	Minimum flow rate at base conditions during month
QVol T Date/Time	Timestamp of minimum flow rate at base conditions during month
QVol	Maximum flow rate at measurement conditions during month
QVol T Date/Time	Timestamp of maximum flow rate at measurement conditions during month
QVol	Minimum flow rate at measurement conditions during month
QVol T Date/Time	Timestamp of minimum flow rate at measurement conditions during month
pVol	Maximum pressure occurred during month
pVol T Date/Time	Timestamp of maximum pressure occurred during month
pVol	Minimum pressure occurred during month
pVol T Date/Time	Timestamp of minimum pressure occurred during month
pVol	Average pressure during month (flow-weighted)
TVol	Average temperature during month
TVol	Maximum temperature occurred during month
TVol T Date/Time	Timestamp of maximum temperature occurred during month
TVol	Minimum temperature occurred during month
TVol T Date/Time	Timestamp of minimum temperature occurred during month
WVol	Average compressibility and correlation factor (flow-weighted) during month
CVol	

5.2.2.2 Maximum (see also for device option volume conversion)

Current periods

icfPa	V_{c} counter progress of the current measuring period
icfPa+ Data/Time	Remaining time of the current measuring period
icdPa	V_{c} counter progress of the current day
icdPa+ Data/Time	V_{c} counter progress of the current month
icmPa	Maximum progress of V_{c} in a measuring period of the current month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a measuring period of the current month
icdPa+ Data/Time	Maximum progress of V_{c} in a day of the current month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a day of the current month
icmPa	V_{c} counter progress of the current measuring period
icdPa	Measurement volume V_{c} counter progress of the current day
icdPa+ Data/Time	V_{c} counter progress of the current month
icmPa	Maximum progress of V_{c} in a measuring period of the current month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a measuring period of the current month
icdPa+ Data/Time	Maximum progress of V_{c} in a day of the current month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a day of the current month

Prelook periods



Maximum values from days and months further in the past are available in the corresponding daily and monthly archive (→ 5.2.2.3.5).

icfPa	V_{c} counter progress of the previous measuring period
icfPa+ Data/Time	Timestamp of maximum progress of V_{c} in the previous measuring period
icdPa	V_{c} counter progress of the previous day
icdPa+ Data/Time	Timestamp of V_{c} counter progress of the previous day
icmPa	V_{c} counter progress of the previous month
icmPa+ Data/Time	Timestamp of V_{c} counter progress of the previous month
icmPa	Maximum progress of V_{c} in a measuring period of the previous month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a measuring period of the previous month
icdPa+ Data/Time	Maximum progress of V_{c} in a day of the previous month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a day of the previous month
icmPa	V_{c} counter progress of the previous measuring period
icmPa+ Data/Time	Timestamp of V_{c} counter progress of the previous measuring period
icdPa	V_{c} counter progress of the previous day
icdPa+ Data/Time	Timestamp of V_{c} counter progress of the previous day
icmPa	V_{c} counter progress of the previous month
icmPa+ Data/Time	Timestamp of V_{c} counter progress of the previous month
icmPa	Maximum progress of V_{c} in a measuring period of the previous month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a measuring period of the previous month
icdPa+ Data/Time	Maximum progress of V_{c} in a day of the previous month
icmPa+ Data/Time	Timestamp of maximum progress of V_{c} in a day of the previous month

6.2.7 Changing the user level

1. Call up menu function "user".
2. Press ENTER to start the edit mode.
3. Use the arrow buttons to select the desired user level.
4. Confirm with ENTER.
The cursor now sits at the first position of the password.
5. To enter the password:
 - Use the arrow buttons to increment or decrement the first position of the password by 1 until the correct digit is shown.
 - Confirm with ENTER.
The cursor now sits at the second position of the password.
 - Repeat for the remaining positions of the password.
 - You are logged in with the selected user level after the last position of the password is confirmed.



The following users are set at the factory:

- user (1), password: 1111
- authorized user (2), password: 2222

- Change the password after the first login using the PLOoper™ operating software.

6.2.8 Setting the language

1. Switch to the "System settings" submenu in the FLOWIO500 menu.
2. Call up "Language".
3. Press ENTER to start the edit mode.
4. Use the arrow buttons to select the desired language.
5. Confirm with ENTER.
The display settings are now shown in the selected language.

6.2.9 Changing the device mode

On the FLOWIO500, the device modes Configuration and Calibration can be activated independently from each other:

6.2.9.1 Starting and terminating configuration mode

Start configuration mode

1. Switch to the "Device mode" submenu in the FLOWIO500 menu.
2. Call up "Configuration mode".
3. Press ENTER to start the edit mode.
4. Use the arrow buttons to select ON.
5. Confirm with ENTER.

The configuration mode is started.

Symbol  is displayed in the symbol bar.

Terminate configuration mode

1. Call up "Configuration mode".
2. Use the arrow buttons to select OFF.
3. Confirm with ENTER.

The configuration mode is terminated.

5.2.9.2 Starting and terminating calibration mode

Calibration mode can be started and terminated in the same manner as the configuration mode (→ p. 300 § 5.2.9.1).

In calibration mode, message "CALIBRATION MODE" blinks on the main display with the major factor $n = 1$ effective for the calibration (set at the factory).

The FLOW/SIC800 outputs test pulses with a maximum possible frequency of 2 Hz at 100% Q_{max} or digital switching output DO_1 (→ p. 34 § 3.4.6.1).

5.2.10 Changing parameters**Numerical values**

1. Start the configuration mode (→ p. 39).
2. Select the desired parameter in the menu.
3. Press ENTER to start the edit mode.
The cursor now blinks under the first position of the parameter.
4. Use the arrow buttons to increment or decrement the selected position by 1 until the correct digit is shown.
5. Confirm with ENTER.
The cursor now blinks under the second position of the parameter.
6. Repeat for all remaining positions of the parameter.

Selection lists

1. Start the configuration mode (→ p. 39).
2. Select the desired parameter in the menu.
3. Press ENTER to start the edit mode.
4. Use the arrow buttons to switch to the desired selection.
5. Confirm with ENTER.

5.2.11 Resetting the error volume

1. Switch to the error volume display on the main screen.
2. Press ENTER to start the edit mode.
3. Use the arrow buttons to select OK.
4. Confirm with ENTER.
The error volume is reset.

5.2.12 Resetting the event summary

1. Switch to the "Event Summary" display on the main display.
2. Press ENTER to open a list of the stored events.
3. Press ENTER to start the edit mode.
4. Use the arrow buttons to select OK.
5. Confirm with ENTER.
The event summary is reset.

5.2.12 Confirming battery replacement

Confirm battery replacement on the display after you have changed a battery:

- 1 Switch to the "System settings" submenu in the FLOWSiC500 menu.
- 2 Switch to the status indicator of the replaced batteries, e.g. "Power Supply (1)".
- 3 Press ENTER to start the edit mode.
- 4 Use the arrow buttons to select OK.
- 5 Confirm with ENTER.

5.2.14 Checking the external power supply

An external power supply connected to the meter can be checked as follows:

- 1 Switch to the "System settings" submenu in the FLOWSiC500 menu.
- 2 Select "Power supply (1)" with the arrow buttons and confirm with ENTER.
- 3 Select "Check ext. power supply" and confirm with ENTER.

5.2.15 Testing the display

- 1 Switch to the "System settings" submenu in the FLOWSiC500 menu.
- 2 Call up "LCD-Test".
- 3 Press ENTER to start the display test.

All display segments on the display are activated and deactivated three times. Defective display segments can thus be detected.

5.2.18 Searching archive entries

The archive entries in the measuring period archive, daily archive and monthly archive can be searched using the following values:

- Timestamp (input format: TT.MM.CC=mmmm)
- Entry ID (input format: 00000000)
- Counter readings base values (input format: 00000000.000)

The search function is only available if the displayed archive contains at least two entries. The search masks (arrows) used are designed the same for all archives and are operated identically.

- 1 To enter the editor, press ENTER at the desired entry type in the menu to be searched. Press ENTER for the desired entry type.
In the bottom line the value from the current archive entry is present as the start value for the change.
- 2 In the bottom line of the display, from left to right, use the arrow buttons to set the desired value.
Press ENTER after each digit to confirm the entry.
- 3 To start the search, confirm the last digit with ENTER.
As long as the searching is running, the display shows "Search...NNNN" (NNNN = number of entries already searched).
To cancel editing or a running search, press ESC. The display then returns to the last archive entry displayed.
The first exact match is displayed as the search result.
If there is no exact match, the archive entry will be determined for which the difference to the searched value is the smallest. If there is no matching entry, the system returns to the last archive entry displayed.

FLWSIC500

6 Clearing malfunctions

Contacting Customer Service

Status messages

Additional messages in the Event logbook

Starting a diagnostic session

3.1 Contacting Customer Service



Contact Endress+Hauser Customer Service for any malfunctions you cannot clear yourself.



To help Customer Service understand malfunctions that have occurred, the FLOWgate™ operating software provides the option to create a diagnostics session. → p. 107 § 6.4

3.2 Status messages

- Active errors or warnings are shown flashing on the LCD display. Current errors or warnings can be retrieved under "Device status" / "Current events" with error code.
- Detailed information on the status messages is available via the FLOWgate™ operating software in the "Diagnostics" menu /> the "Status-Diagnostics" box.

Table 26: Warning messages

Status message	Description / assistance
E-1017	The device firmware has been changed.
E-1018	The device has been started.
E-1019	Configuration mode is active. → p. 99 § 5.6.3.1 "Starting and terminating configuration mode"
E-1020	The parameter locking switch is open. → p. 11 § 2.3.1 "Parameter locking switch"

Table 27: Warning messages

Status message	Description / assistance
W-2001	The Event logbook is close to full. The Event logbook can be cleared, stored and reset with the FLOWgate™ operating software.
W-2002	The Metrolog logbook is full. Custom relevant parameters can only be modified after the parameter locking switch has been opened. The Metrolog logbook can be reset with the FLOWgate™ operating software. → p. 102 § 5 "Clearing malfunctions"
W-2003	Flow pulses that permitted the alarm be output at the pulse output. Check whether the current flow rate is higher than the maximum flow rate. If the flow rate is within the permissible range, check whether the selected output scaling (→ Metrolog) is correct. → p. 104 § 5.1 "Contacting Customer Service"
W-2008	Flow rate measurement is in status "warning". Have the device checked by Customer Service. → p. 104 § 5.1 "Contacting Customer Service"
W-2009	The measured flow rate is outside the set warning limits. Check the current measuring conditions or adjust the limits. The warning limits can be set with the FLOWgate™ operating software.
W-2010	W2008 = flow rate below warning limit W2010 = flow rate above warning limit
W-2016	Battery 1 failure. → p. 113 § 7.3.2 "Changing the battery supply"
W-2017	Battery 2 failure. • With antenna power supply: → p. 112 § 7.3.2 "Changing the battery supply" • For battery operation: → p. 113 § 7.3.2 "Changing the battery panel"
W-2018	Battery power supply failure. Check the connection and function of the antenna power supply. → p. 98 § 3.4.9 "Operation with antenna power supply"

Table 20 Error messages

Status message	Description, measure
E-0001	The Event logbook is full. Check the Event logbook. The Event logbook can be read with the Pictograph[®] operating software.
E-0002	Checksum error. → p. 124 § 4.1 "Contacting Customer Service"
E-0007	Time fault. → p. 124 § 4.2 "Commissioning on the display"
E-0008	The FDSH500 is in calibration mode. → p. 124 § 5.1.2 "Starting and terminating calibration mode"
E-0010	Temperature sensor failure. The FDSH500 uses the default value specified. → p. 124 § 7.6 "Exchanging an external pressure or temperature sensor" → p. 124 § 8.1 "Contacting Customer Service"
E-0012	Pressure sensor failure. The FDSH500 uses the default value specified. → p. 124 § 7.6 "Exchanging an external pressure or temperature sensor" → p. 124 § 8.1 "Contacting Customer Service"
E-0015	Device is outside the permissible measurement pressure range. Check Pmin, Pmax vs. pressure.
E-0016	Flow rate measurement is in status "Malfunction". → p. 124 § 8.1 "Contacting Customer Service"
E-0017	The K-factor cannot be calculated. Check the values entered for gas composition against the reference conditions and the dose conditions. → p. 35 § 3.2.4 "Start display" with sample code for the commissioning
E-0018	Reverse flow. The measured mass volume (reverse flow) is larger than the preconfigured buffer volume. → p. 22 For large reverse flow (over 1000 l/hour), contact Customer Service to have the preconfigured volume adapted. → p. 124 § 8.1 "Contacting Customer Service"
E-0019	The measured gas temperature / gas pressure is outside the permissible limits.
E-0020	E-0019 • Gas temperature is below the alarm limit.
E-0021	E-0019 • Gas temperature is above the alarm limit.
E-0022	E-0019 • Gas pressure is below the alarm limit.
E-0023	E-0019 • Gas pressure is above the alarm limit.
E-0024	Check the set alarm limit values. → p. 94 § 3.2.6.7 "Temperature parameters"
E-0025	Time is inaccurate. Check time synchronization.

3.5 Additional messages in the Event logbook

The FLOWCROSS saves all status messages (→ p.134, §8.2) as well as further administrative messages concerning events and status messages to the Event Logbook.

Each message code is supplemented with a + or - to identify an incoming message + or an outgoing message -

information measurable in the quantum system.

Event ID	Description
E-1001	Event register has been read.
E-1002	Parameter register has been read.
E-1003	Interrupt register has been read.
E-1004	Measuring device address has been read.
E-1005	Chip address has been read.
E-1006	Memory address has been read.
E-1007	Event number has been read. ¹⁾
E-1008	Time has been read. ¹⁾
E-1009	Total time has been read.
E-1010	Only volume total time has been read. ¹⁾
E-1011	All parameters have been read or a group of parameters have been read. ¹⁾
E-1012	Entry (1) has been replaced.
E-1013	Entry (2) has been replaced.
E-1014	Total time has been preset. ¹⁾
E-1015	Gas composition register read.
E-1016	Gas parameters checked.

Table 5B
Bivariate measures of the first factor

Filter message	Description/Comment
#0011	The number of valid measurements (performance of this site measurement) is significantly lower than home. ¹⁾
#0012	Performance measurement is performed with limited precision. ²⁾
#0013	Performance is higher than LTP ₀ . ³⁾
#0021	Only with invalid CRC in the measuring parent station
#0022	Only with invalid CRC in the child station
#0023	Only with invalid CRC in the both stations

Table 3.1: *Estimated mean age at start of school*

State message	Description, instance
E-9001	Check sum of hardware is invalid
E-9002	Check sum of firmware is invalid
E-9004	Parameter is invalid ¹⁾
E-9006	Check sum of logbook archives is invalid ²⁾
E-9015	Hardware error in flow rate measurement ³⁾
E-9018	Number of old measurements (performance) for gas measurement is not sufficient ⁴⁾

In the chart above, additional data, e.g. status, latitude, height, measured values and measurements at the time of certain events are added.

These events or messages are identified with *. The data can be viewed and saved with the STORWARE® operating software (v. 3.0, 3.1, 3.2).

5.4 Starting a diagnostic session

1. Click the  icon in the tool bar to start a diagnostic session.
2. Select the desired data collection function and enter a description.
It is recommended to select a data collection duration of at least 5 minutes.

Fig. 46 Data collection duration for the diagnostic session



3. Click "Start" to start recording.
The following message with the current storage location of the data collection is shown after successful creation of the diagnostic session.

Fig. 47 Diagnostic recording completed



4. Click "OK" to confirm the message.
5. Store the diagnostic session or send per email.



Fig. 48 Store the diagnostic session or send per email



6. Click "Close" to leave the file at the standard storage location.
 - Click "Save as" to select a different storage location for the diagnostic recording. Selecting the option "Save as" stores the parameter recordings and logbook files as single files in a zip archive.

- Click "Email" to send the file per email. The file is appended to an email when an email client is available. Click "Save as" to select a storage location for the diagnostic recording. Selecting the option "Save as zip" stores the parameter recordings and logbook files as single files in a zip archive.

FLWSIC500

7 Maintenance and meter exchange

- Information on handling lithium batteries
- Maintenance when using external power supply
- Maintenance when using battery power supply
- Meter exchange
- Function check of a pressure or temperature sensor
- Exchanging an external pressure or temperature sensor

3.1

Information on handling lithium batteries



WARNING: Risk of explosion - hazard for minimal safety

- Only the Endress+Hauser battery packs from Endress+Hauser with Part No. 2054018 and the backup battery with Part No. 2055529 may be used for the power supply of the points.
- Do not use damaged batteries; they must be disposed of correctly.



WARNING:

- Comply with the national regulations when transporting used battery packs by air freight.

Table 32

The battery packs are marked with important information concerning storage and disposal handling.

Symbol	Significance
	Do not dispose with household waste.
	Recycling

Fig. 49

Identification of battery packs



Variable	Description	
	Serial No.	Part No.
	Date	Serial No.
	DIN Code	→ Part No. =
		Date

7.11 Information on storage and transport

- Prevent a short circuit of the battery terminals:
 - Store and transport the batteries in their original packaging
 - or tape the battery terminals.
- Store at 20 °C (70 °F), dry and without major temperature fluctuations
- Protect against permanent sunlight
- Do not store near the heating

7.12 Disposal information

In the EU

- Dispose of lithium batteries in accordance with the Battery Directive 2006/66/EU
- In Germany, you can hand in the batteries at (no) local recycling center.
Alternatively, the battery manufacturer Tadiran Germany offers a return service on request.
Contact data:
Phone: +49 (0)6042 894-322
Fax: +49 (0)6042 894-330
www.tadiranbatteries.de

In the USA

- Batteries have to be disposed of by an authorized waste disposal company.
Identification of lithium batteries:
 - Proper shipping name: Waste lithium batteries
 - UN number: 3090
 - Label requirements: MISCELLANEOUS, HAZARDOUS WASTE
 - Disposal code: D003
- If anything is unclear, contact the local office of the Environmental Protection Agency (EPA)

In other countries

Please observe national regulations for the disposal of lithium batteries.

1.2 Maintenance when using external power supply

1.2.1 Service life of backup battery

When new, the capacity of the backup battery has been calculated for bridging up to 3 months failure of the supply voltage. When voltage supply is not interrupted, the service life is at least 10 years when stored at approx. 25 °C (77 °F).

Repeated, even short-time voltage failure reduces the remaining buffer capacity of the battery so that exchange is recommended.



If both the supply voltage and the backup battery fail, the clock setting is lost and the FLOWSiC500 does not measure anymore. Totalizer values determined until then and parameter settings remain permanently stored.

1.2.2 Changing the backup battery



WARNING: Risk of explosion - hazard for lithium safety

- Only the exchangeable battery packs from Endress+Hauser with Part No. 2004218 and the backup battery with Part No. 2005928 may be used.

1. Ensure external voltage supply.
2. Open the electronics cover (→ p. 48, § 4.3).
3. Loosen the connection of the backup battery.
4. Remove the backup battery.
5. Insert a new backup battery and connect the battery to connection B411.
6. Close the electronics cover (→ p. 48, § 4.3).
7. Confirm battery replacement on the display (→ p. 101, § 3.13).
8. Alternatively, confirm battery replacement with the FLOWgate™ operating software:
 - Connect to device (→ p. 75, § 4.3.1).
 - Open the file "System User" in the "Parameter Modification" area.
 - Set the configuration mode.
 - Click "Battery exchange source 2" in the area "Power supply".
 - Return to the operating mode.



NOTE:

The battery symbol on the display shows full straight away after the battery change.
The check whether the battery is really operational takes 20 minutes.

7.2 Maintenance when using battery power supply

7.2.1 Service life of battery packs

Under typical operating conditions, the expected total service life of both battery packs is 5 years.



The complete failure of both battery packs results in the loss of the book settings and the FLOWSiC500 does not measure anymore. Further work determined until then as well as the parameter settings remain permanently stored.

The FLOWSiC500 needs more power

- when the display is used frequently,
- when the infrared interface is used,
- when the encoder output is frequently used (scanning cycles < 15 min).

When the electrically isolated HALL R output (CO_2) is used, an external voltage supply is recommended due to the significantly higher power requirement.

The capacity of the batteries is reduced in unfavorable climatic conditions, for example when the temperatures are significantly higher or lower than 25°C (77°F).

7.2.2 Changing the battery packs



WARNING: Risk of explosion – hazard for intrinsic safety

- ▶ Only the rechargeable battery packs from Endress+Hauser with Part No. 5054022 and the backup battery with Part No. 5055928 may be used for the power supply of the device.
- ▶ Do not use damaged batteries; they must be disposed of correctly.

The charge level of the battery packs is shown as a symbol on the display.

Table 33 Battery fill level

Symbol	Charge state	Description
	Battery pack 1 full (see connection E4T1)	Details on the battery fill level –> p. 63, § 3.2.2.
	Battery pack 2 full (see connection E4T2)	

The second battery pack is activated automatically when the first pack is completely empty. When one battery pack is empty, at least this battery pack should be changed. Both battery packs must be changed at the latest when the second battery pack is running low.

- 1 Check on the display which battery pack is empty.
- 2 Open the electronics cover (→ p. 48, § 3.4.3).
- 3 Loosen only the respective terminal connection of the empty battery pack.



NOTICE:

Only loosen one connection at a time to ensure continuous voltage supply. If both battery packs are to be exchanged at the same time, first replace the empty battery pack and then the still used battery pack.

Fig. 50

Battery connections on the front door



4. Remove the battery pack and replace by the new one.
5. Reconnect the electrical system.
The FLOWiCS500 now continues to use the second battery pack and then switches back to the new battery pack.
6. Close the electronics cover (→ p. 48, § 3.4.3).
7. Confirm battery replacement on the display (→ p. 101, § 5.1.12).
8. Alternatively, confirm battery replacement with the FLOWgate™ operating software:
 - Connect to device (→ p. 75, § 4.3.1).
 - Login as "authorized user" on the device.
 - Open the tile "System User" in the "Parameter Modification" area.
 - Start the configuration mode.
 - When the battery pack on "BAT2" has been exchanged, click "Battery change Source 2" in area "Power supply".
 - When the battery pack on "BAT1" has been exchanged, click "Battery change Source 1" in area "Power supply".
9. Return to the operating mode.

**NOTE:**

The battery symbol on the display shows full straight away after the battery change.

(The check whether the battery is really operational then takes 20 minutes.)

7.4 Meter exchange

7.4.1 Prerequisites for meter exchange



NOTICE

Ensure that the meter exchange is carried out according to the national regulations for Ex and pressure applications of your country.

7.4.2 Hazards during meter exchange



WARNING: Hazards due to combustible gases or high pressure natural gas under line pressure flows through the gas flow meter during running operation. The gas flow meter may only be exchanged when the equipment is at a standstill.

Before commencing (installable) work:

- Ensure the pipeline is free from pressure and free from combustible gases.
- Purge the pipeline with inert gas if necessary.
- Observe the safety information in § 3.1 (→ p. 10) and § 3.2 (→ p. 10).



NOTICE

The gas flow meter may only be exchanged by skilled persons who, based on their technical training and knowledge in pipeline construction as well as knowledge of the relevant regulations, can assess the tasks given and recognize the hazards involved.

- Observe the information in § 3.4 (→ p. 14).
- In case of doubt, please contact the local Endress+Hauser Customer Service.

7.4.3 Sequence of meter exchange

To exchange the gas flow meter, proceed as follows:

- 1 Download the user-specific configuration of the installed gas flow meter (→ p. 118, § 7.4.5).
- 2 Disconnecting electrical connections (→ p. 119, § 7.4.7).
- 3 Removing the installed gas flow meter (→ p. 120, § 7.4.8).
- 4 Installing the replacement gas flow meter (→ p. 124, § 7.4.9).
- 5 Performing leak-tightness check (→ p. 126, § 7.4.10).
- 6 Connect the new gas flow meter to the electric system (→ p. 46, § 3.4).
- 7 Upload the user-specific configuration of the previously installed gas flow meter to the new gas flow meter (→ p. 128, § 7.4.11).
- 8 Check the function of the gas flow meter (→ p. 133, § 7.4.12).
- 9 If necessary, secure methodically (→ p. 133, § 7.4.12).

Task 3: Required tools and auxiliary material

- Filter exchange set (item numbers – p. 145 §3.1.1) with:
 - Test cap for the respective filter size (– Pg. 51, component no. 5)
 - Socket wrench
 - Allen key

Task 3a: Overview

Filter size	Socket wrench	Allen key
SiC50-2	15	5
SiC50-3	24	6
SiC50-4	30	8
SiC50-5		


- Torque wrench
- Transport protection for the gas flow meter with a safety strap (item numbers – p. 139 §3.1.2)
- Silicone grease
- Leak detection spray
- Lubricant, metal-free or suitable for aluminum, e.g. Oils 200, to prevent thread mountings seizing up



NOTICE:
Do not use copper grease.

1.45 Overview

Fig. 50 Components for water exchange using D150 2 as example



- 1. Servomotor
- 2. Support washer
- 3. Servomotor
- 4. Support washer
- 5. Gas for water

- 6. Connecting pipe (if any)
- 7. Adapter
- 8. Lining cap
- 9. Test trap

Tab: Backup of user-specific configuration of installed gas flow meter

1. Connect to device –> p. 72 §4.3.3.
2. Open the "Meter Replacement" tile in the "Service" menu.
3. Click "Backup Parameter" to backup the parameters of the currently installed gas flow meter.

Fig. 52 Parameter backup



4. Save the parameter file:
 - Click "Save as" to choose a storage location for the csv meter file.
 - Click "Email" to send the file per e-mail. This file is appended to an e-mail when an e-mail client is available.

Fig. 53 Save the parameter file



5. Click "Close" after storing the csv file.



NOTICE:

The parameter set is required after exchanging the gas flow meter to transfer the customer-specific or device-specific parameters to the new gas flow meter.


7.4.7 Disconnecting electrical connections

Observe the safety information in §7.4 (→ p. 48).

Depending on the configuration of your FLOWSCO500, proceed as follows:

1. Disconnect the potential equalisation line at the outer ground terminal (on the right of the M12 plug-in connections) of the electronic housing (→ Fig. 13, p. 50).
2. If installed, remove the plug-in connector cover. To do so, loosen the capstan screws (→ Fig. 26, p. 60).
3. If installed, manually loosen and remove the M12 plug-in connectors for external power supply and the signal output (→ Fig. 13, p. 50).
4. If installed, manually loosen and remove the plug-in connectors of the pressure and temperature sensors (→ Fig. 13, p. 50).
5. Open the electronics cover (→ p. 48, §3.4.3):
 - Configuration with external power supply and backup battery:
Switch the backup battery to "Off".

Fig. 54 Switching the backup battery



- Self-sufficient power configuration with battery packs:

Remove the battery packs and dispose of or store properly according to → p. 113, §7.1.



Endress+Hauser recommends inserting new batteries during away meter exchange.

6. Close the electronics cover again (→ p. 48, §3.4.3).

Table 1: Removing the installed gas flow meter

1. Ensure safe conditions:



WARNING: Hazard due to combustible gases or high pressure. Natural gas under line pressure flows through the gas flow meter during running operation. The gas flow meter may only be exchanged when the equipment is at a standstill.

Before commencing installation work:

- Ensure the pipeline is free from pressure and free from combustible gases.
- Purge the pipeline with inert gas if necessary.
- Observe the safety information in § 5.1 and § 5.2.



WARNING: Hazard due to the gas flow meter falling down.

- Secure the gas flow meter before loosening the screw fitting, e.g. by supporting the gas flow meter or with the help of another person holding the gas flow meter.

2. Unscrew the pressure cap:



3. Remove securing screws (1) with the Allen key.

Meter size	Number of securing screws
DN50 (2")	2
DN50 (3")	3
DN65 (4")	4
DN100 (6")	4

4. Loosen center bolt (2) five turns.



5. Instead of the closure cap, at first manually screw the test cap for the respective meter size in until the test cap touches the center bolt.



6. Keep on screwing the test cap in with the correct wrench against the resistance of the center bolt until the test cap is completely screwed in. The center bolt pushes the seals against the test cap and lifts the gas flow meter cap.



7. Unscrew the test cap and the center nut completely with the socket wrench.



8. Pull the gas flow meter straight upwards and remove it.
9. Ensure that the connecting pipes with the O-rings are still in the gas flow meter.



10. Ensure that the gas flow meter can not be contaminated or damaged at any time.
11. Secure the removed gas flow meter with the transport protection before shipping.
- Fit the gas flow meter on the transport protection.
 - Secure the gas flow meter with the strap provided.



12. Check the sealing surfaces on the adapter (marked green):

- When the sealing surfaces are contaminated, clean carefully.
- Ensure that the sealing surfaces are undamaged. They have to be free of scratches or grooves.



WARNING: Hazard of leaks

There is a risk of the installation becoming leaky when the sealing surfaces of the adapter are damaged. Operation in leaky condition is not allowed and potentially dangerous.

- In this case, the adapter has to be exchanged.
- Please contact your local Endress+Hauser Customer Service.

3.4.5 Installing the replacement gas flow meter

**NOTE:**

When the sealing surfaces of the adapter have been cleaned with a detergent, let it evaporate completely.

- 1 Carefully remove the transport protection of the new gas flow meter. Pay attention to the arrangement of O-ring seals (1) and support plates (2).



- 2 Check the outside of the replacement gas flow meter for transport damage. Only undamaged gas flow meters may be installed.
- 3 Ensure that fastening (1) and the O-rings or connection pieces (2) are not damaged.
- 4 Check all inside or the components for damage.



- 5 Apply silicone grease to the sealing surfaces of the adapter.
- 6 Apply silicone grease to the O-rings or the connection pieces.

- 7 Carefully fit the gas flow meter on the adapter. Pay attention to the correct orientation of the gas flow meter. The position of the center bolt allows only one fitting direction.



8. Carefully plug the connection pieces with the O-rings into the openings of the adapter.



9. First screw the provided main center bolt with Riplock washer in manually.
Endress+Hauser recommends using lubricant.
10. Then tighten the center bolt with the socket wrench to the specified tightening torque.

Material	Tightening torque	
DN50/2"	45 Nm	34 lbf ft
DN80/3"	100 Nm	74 lbf ft
DN100/4"	145 Nm	107 lbf ft
DN150/6"	220 Nm	163 lbf ft



11. First screw the provided securing screws with Riplock washers in manually.
12. Then tighten the securing screws with the Allen key to the specified tightening torque.

Material	Tightening torque	
DN50/2"	20 Nm	15 lbf ft
DN80/3"	45 Nm	34 lbf ft
DN100/4"	65 Nm	48 lbf ft
DN150/6"	120 Nm	89 lbf ft

13. Check the leak tightness – see 11.5.3.4.12.



- | | |
|----|--|
| 14 | After a successful leak tightness check, disconnect the replacement gas flow meter to the electric system, see §3.4 "Electrical Installation". |
| 15 | If desired, copy the configuration of the previously installed gas flow meter to the replacement gas flow meter (→ p. 118, §7.4.5). |
| 16 | Checking the function of the new gas flow meter, → p. 117, §7.4.12. |
| 17 | If necessary, secure metrologically, → p. 113, §7.4.13. |

7.4.12

Perform a leak tightness check

After each exchange of the gas flow meter, the correct installation of the gas flow meter and the leak tightness of the measuring device has to be checked.

To check the leak tightness, the corresponding test cap for the respective meter size is needed (→ p. 118, §7.4.13).

1. Position the test cap for the respective meter size manually.
2. Then tighten the test cap with the socket wrench until the test cap is completely screwed in.



3. Slowly increase the pressure in the device (max. gradient 3 bar/min or 45 psi/min) up to the line pressure.
4. Apply leak detection spray to the opening of the test cap.
5. Check over at least 15 min whether gas escapes at the opening of the test cap.
 - When no gas escapes from the opening of the test cap, see → p. 117, §7.4.10.1.
 - When gas escapes from the opening of the test cap, see → p. 117, §7.4.10.2.

7.4.2.1 Leak tightness check successful

1. Remove the test cap with the socket wrench.
2. Screw in the closure cap.
3. Then connect the replacement gas flow meter to the electric system, see §3.4 "Electrical Installation".



7.4.2.2 Leak tightness check not successful

1. Close the lift and depressurize the device.
2. Warn the environment.
3. Remove the gas flow meter from the adapter as described, see – § 1.3.2.3 T4.5.
4. Check flat seal (1) and the O-ring on connection piece (2) for completeness, tightness and correct installation. When the sealing elements are damaged, a new seal set is available as spare part.

Ref. no.	Ref. name
0150	2067354
0150	2067355
0110	
0130	2067356



6. Check the sealing surfaces on the adapter (marked green) for contamination and damage.
7. When the sealing surfaces are damaged:
e.g. due to corrosion or external force, the adapter has to be exchanged.



7. When the adapter is damaged, it has to be removed and a new adapter installed
→ p. 39, § 3.3.
Then install the gas flow meter again. → p. 124, § 7.4.5.

8. When the components do not seem to be damaged but leak tightness can not be established, please contact Endress+Hauser Customer Service (→ p. 124, § 8.1).

Fig. 57 Loading the parameter backup



NOTICE: Parameter protection

- Check the position of the parameter locking switch, see → p. 83, § 5.2.1.
- When open, proceed with step 1.
- When closed, the counter values and the configuration of the digital outputs cannot be written to the meter.
An information message is output when the parameters are being written. If the further parameters are to be written, click "OK" to confirm the information message.

- 1 Connect to device → p. 75, § 4.3.1.
- 2 Open the "Meter Replacement" file in the "Service" menu.
- 3 Set the source for the parameter exchange to "Parameter file".
- 4 Select the parameter file stored before exchanging the meter. → p. 115, § 7.4.5.

Fig. 58

Parameter file



- 5 An overview of the old and new values is shown under "Values to replace". Activate the "Show only differences" checkbox to show only the differences.
- 6 Activate Configuration mode.
- 7 Click "Start Value Exchange" to load the parameter backup.

Fig. 59

Starting the exchange



8. In the dialog that opens, select whether the totalizer values are to be used from the saved parameter set or should be reset. The operating company is responsible for deciding whether to accept or reset the volume counters.

Fig. 57

Counter values

9. Confirm with "OK".

10. The serial numbers of the pressure and temperature sensor are queried for gas flow meters with external pressure and temperature technology.

Fig. 58

Serial numbers for pressure and temperature sensors

11. Check the serial numbers.

12. Enter the new serial numbers when the numbers do not match the serial numbers of the installed pressure and temperature sensors.

13. Confirm with "OK".

14. Check the serial number of the adapter; enter the serial number when different from the one stored.

Fig. 59

Adapter serial number

15. During transfer of the parameter values, the sequence is shown in a progress bar.

16. Confirm the upload with "OK" after completion of the upload.

The "Meter exchange report" is created.

17. Save the report as pdf file or csv file or send by e-mail.

Fig. 80:

Saving the water exchange report.



7.4.12 Checking the function of the new gas flow meter

- Check on the display if there are any malfunctions or warnings:

	Device status: Malfunction	The device has entered the measured value 6 state.
	Device status: Warning	The device has a warning, the measured value is still valid.

- If any malfunctions or warnings exist, clear the cause (→ p. 133 § 6).
- Alternatively, check the device status with the FLOgate™ operating software (→ p. 83 § 3.5.5).
- Create a diagnostics session and file with the device documentation (→ p. 137 § 6.4).

7.4.13 Securing metrologically

- Gas flow meter and adapter can be secured at the J175 by a user seal (protective cap) (→ p. 34 § 2.8).
- If the parameter locking switch has been opened during the meter exchange, secure the parameter locking switch again metrologically (→ Fig. 9, p. 35).

7.2 Function check of a pressure or temperature sensor

The error status of a sensor is displayed on the device as an event.

1. Switch to main display "Current alerts".
2. Check the list for a current event with type E3010 (temperature sensor failure) or E3012 (pressure sensor failure).

Exchange the sensor involved when one of these errors is displayed – p. 134, § 7.3.



Replace the gas flow meter in the device configuration with internal pressure and temperature sensors.

If an error is not displayed, the sensor function can be checked by comparing the measured value on the FLOWSiC500 with the measured value of a reference sensor.

7.3 Exchanging an external pressure or temperature sensor



WARNING: Hazard through wrong spare parts

The FLOWSiC500 and the delivered pressure and temperature sensors are designed intrinsically safe.

- Only pressure and temperature sensors from Endress+Hauser may be used – p. 140, § 6.2.2.
- The pressure and temperature sensors can be connected and disconnected in the hazardous area as well.
- The pressure and temperature sensors may only be connected using the IAB plug-in connectors marked accordingly on the FLOWSiC500.
- Modifying the electrical connection parts is not allowed.



NOTE:

The pressure and temperature sensors can only be replaced when the parameter locking switch is open.

7.3.1 Exchanging the pressure sensor

1. Three-way test valve: Move the lever to the test position (→ Fig. 2).
- Fast valve: Fit the adapter on the test connection (Part no. 2071841).
2. Unscrew the sensor from the three-way test valve.
Here, loosen the screw fitting slowly, so that any overpressure can escape under control.
3. Loosen the plug-in connector cover.
4. Disconnect the plug.
5. Connect the plug to the IAB connector on the FLOWSiC500.
6. Screw the plug-in connector cover tight.
7. Install a new pressure sensor on the pressure-measuring port marked "P₁" – p. 60, § 3.5.2.
8. Enter the serial number of the new sensor in the FLOWSiC500 with the FLOWgo® operating software.
 - Connect to device – p. 75, § 6.3.1.
 - Open the "Device identification" file in the "Parameter Modification" menu.
 - Go to the configuration mode.
 - Enter the new serial number in the field "Pressure sensor serial number".
 - Return to the operating mode. The new serial number is written to the device.

- 9 Check the function by comparing the operating point or checking the display value (remove adapter or fast connection) against a reference measurement.



NOTICE: Leak tightness check

Endress+Hauser recommends a leak tightness check after sensor replacement.

7.4.2

Exchanging the temperature sensor



The temperature sensor can be glazed with hard-conductive oil or paste to improve its performance.

- 1 Loosen the locknut and pull the temperature sensor out of the protective tube.
- 2 Loosen the plug-in connector cover.
- 3 Disconnect the plug.
- 4 Guide the plug of the new sensor through the plug-in connector cover.
- 5 Connect the plug to the MS connection on the FLOWSiC500.
- 6 Screw the plug-in connector cover tight.
- 7 Fit the new temperature sensor in the protective tube – p. 65.33.8.2.
- 8 Enter the serial number of the new sensor in the FLOWSiC500 with the FLOWgate® operating software:
 - Connect to device – p. 75.34.3.1.
 - Open the "Device Identification" file in the "Parameter Identification" menu.
 - Start the configuration mode.
 - Enter the new serial number in the field "Temperature sensor serial number".
 - Return to the operating mode. The new serial number is written to the device.
- 9 Check the function by comparing the operating point or checking the display value (remove adapter or fast connection) against a reference measurement.

FLWSIC500

8 Accessories and spare parts

Accessories

Spare parts

2.1 Accessories

2.1.1 Gas flow meter accessories

Description	Part No.
Mounting set for meter installation 2" / DN50 with flange type PN16 (EN1092-1)	2007400
Mounting set for meter installation 2" / DN50 with flange type PN16 (EN1092-1)	2007403
Mounting set for meter installation 4" / DN100 with flange type PN16 (EN1092-1)	2007404
Mounting set for meter installation 6" / DN150 with flange type PN16 (EN1092-1)	2007406
Mounting set for meter installation 2" / DN50 with flange type PN16 (EN1092-1)	2007408
Mounting set for meter installation 2" / DN50 with flange type PN16 (EN1092-1)	2007407
Mounting set for meter installation 4" / DN100 with flange type PN16 (EN1092-1)	2007408
Mounting set for meter installation 6" / DN150 with flange type PN16 (EN1092-1)	2007409
Mounting set for meter installation 2" / DN50 with flange type PN16 (GOET 12819-80 and GOET 33259-2015), flange face 1: series 1/2	2007411
Mounting set for meter installation 2" / DN50 with flange type PN16 (GOET 12819-80) for flange face 1: series 1, or with flange type PN16 (GOET 33259-2015) for flange face series 2	2007412
Mounting set for meter installation 2" / DN50 with flange type PN16 (GOET 12819-80) for flange face 1: series 2, or with flange type PN16 (GOET 33259-2015) for flange face series 1	2007413
Mounting set for meter installation 4" / DN100 with flange type PN16 (GOET 12819-80 and GOET 33259-2015), flange face 1: series 1/2	2007414
Mounting set for meter installation 6" / DN150 with flange type PN16 (GOET 12819-80 and GOET 33259-2015), flange face 1: series 1/2	2007416
Bump plug for pressure connection 1/4"	2007386
Bump plug for temperature connection 1/2"	2007401
M12 plug (B-coded) for data transfer	2007419
M12 connector (B-coded) for power supply	2007420
2 m connection cable for data transfer: -25 °C ... +60 °C / -15 °F ... +140 °F with connector (B-coded) and ferrules	2007421
5 m connection cable for data transfer: -25 °C ... +60 °C / -15 °F ... +140 °F with connector (B-coded) and ferrules	2007422
2 m connection cable for data transfer: -40 °C ... +70 °C / -40 °F ... +158 °F with connector (B-coded) and ferrules	2007630
5 m connection cable for data transfer: -40 °C ... +70 °C / -40 °F ... +158 °F with connector (B-coded) and ferrules	2007631
10 m connection cable for power supply: -25 °C ... +60 °C / -15 °F ... +140 °F with connector (B-coded) and ferrules	2007424
20 m connection cable for power supply: -25 °C ... +60 °C / -15 °F ... +140 °F with connector (B-coded) and ferrules	2007425
10 m connection cable for power supply: -40 °C ... +70 °C / -40 °F ... +158 °F with connector (B-coded) and ferrules	2007632
20 m connection cable for power supply: -40 °C ... +70 °C / -40 °F ... +158 °F with plug (B-coded) and connector set 65	2007633
Zero-Point 5000, working voltage 12 V at 12.5 A; ABS 1 (1) 5000-0-02-00 20001 mounting Position data (F0): Operating temperature -20 to +60 °C / -4 to +140 °F Single-channel safety barrier series 9001; operating voltage 12 V DC; ABS 1 (1) 0-0-04 (a) 0-0-04, 15 TA 0-0-04 Class 1, Output 2, Group A, S, Q, degree of protection IP20 20 operating temperature -20 °C ... +60 °C	9075551 9050900

Description	Part no.
Probe cable with 255 x 40 x 12 mm operating voltage 12 V DC, 1 A, 1-phase, screw connection DIN rail mounting BS 35, BS 30715, fully isolated degree of protection IP20, operating temperature -25 °C ... 70 °C	8050640
Thermal cable with 4 x 0.4 cable, outer diameter up to 33 mm, cable length 1.58 m, cable weight 2.25 m, ATB II 10 to 100 °C, operating temperature -25 °C ... +85 °C, degree of protection IP30	8050640
Temperature of protection of connectors	2071357
Display, protection for FLOWSiC500, anti-theft	2071347

B.1.2

Volume conversion (device option) accessories

Description	Part no.
Pressure connector set -40 °C to 70 °C, three-way conn. fitting with female 9 mm, seal connection, 1/16" NPT coupling	2071731
Pressure connector set -40 °C to 70 °C, three-way conn. fitting with female 1/4", seal connection, 1/16" NPT coupling	2071732
Pressure connector set -25 °C to 90 °C, Test -area BS 404 (G1/4"), fitting with female	2071088
Test connection set DIN 991-4	2071841
Thermowell for nominal width DN50 and DN100 (2" and 4"), 75 mm length, all directions, seal for use in -40 °C to 70 °C	2090309
Thermowell for nominal width DN150 (6"), 75 mm length, all directions, seal for use in -40 °C to 70 °C	2090397
Thermowell for nominal width DN50 and DN100 (2" and 4"), 75 mm length, all directions, seal for use in -40 °C to 70 °C	2090388
mm. seal tightness, strength test according to DIN 30690-1	
Thermowell for nominal width DN150 (6"), 75 mm length, all directions, seal for use in -40 °C to 70 °C	2090389
mm. seal tightness, strength test according to DIN 30690-1	
Thermowell for nominal width DN50 (2"), 115 mm length, direction right/left, seal for use in -40 °C to 70 °C	2151358
mm. seal tightness, strength test according to DIN 30690-1	
Thermowell for nominal width DN50 (2"), 115 mm length, direction right/left, seal for use in -40 °C to 70 °C	2151359
mm. seal tightness, strength test according to DIN 30690-1	
Thermowell for nominal width DN50 (2"), 75 mm length, direction left/right, seal for use in -40 °C to 70 °C	2151360
mm. seal tightness, strength test according to DIN 30690-1	
Thermowell for nominal width DN50 (2"), 75 mm length, direction left/right, seal for use in -40 °C to 70 °C	2151361
mm. seal tightness, strength test according to DIN 30690-1	

B.1.3

Transport accessories

Description	Part no.
Transport protection for gas flow meter, rated with DN50 (2")	2079001
Transport protection for gas flow meter, rated with DN50 (2")	2079001
Transport protection for gas flow meter, rated with DN100 (4")	2079002
Transport protection for gas flow meter, rated with DN150 (6")	2079003

3.2 Spare parts

3.2.1 Gas flow meter spare parts

Description	Part no.
Battery (7.2 V, 1.9 Ah, for non-rechargeable flow meter)	2084018
Battery pack (2P8 – 6034882 Tachin SL-580)	
Recharge battery (7.2 V, 2.7 Ah) for non-rechargeable main power supply (Batter) pack (2P8 – 6034880 Tachin SL-580)	2085810
Display module for FLOWSiC500, for output configuration "A-E" (type code)	2086077
Display module for FLOWSiC500, for output configuration "F-I" (type code)	2083847
Display case	2086177
PS405 module used input voltage 4 ~ 10 V, for output configuration "J" (type code)	2087848
PS405 module used input voltage 2.7 ~ 5 V, for output configuration "K" (type code)	2087849
Tool set for gas flow meter exchange 2" / DN50	2087510
Tool set for gas flow meter exchange 3" / DN80	2087511
Tool set for gas flow meter exchange 4" / DN100 and 6" / DN150	2087512
Cable set for gas flow meter exchange 2" / DN50	2087554
Cable set for gas flow meter exchange 3" / DN80	2087586
Cable set for gas flow meter exchange 4" / DN100 and 6" / DN150	2087589

3.2.2 Volume conversion (device option) spare parts

Description	Part no.
ED712 - digital pressure sensor: absolute pressure 0 to 4 bar, G1/4" male thread	2071178
ED713 - digital pressure sensor: absolute pressure 0 to 10 bar, G1/4" male thread	2071179
ED714 - digital pressure sensor: absolute pressure 0 to 20 bar, G1/4" male thread	2071179
ED715 - digital pressure sensor: absolute pressure 2.5 to 5.2 bar, G1/4" male thread	2071179
ED716 - digital pressure sensor: absolute pressure 2 to 10 bar, G1/4" male thread	2071179
ED717 - digital pressure sensor: absolute pressure 4 to 20 bar, G1/4" male thread	2071180
ED718 - digital pressure sensor: absolute pressure 0.2 to 20 bar, G1/4" male thread	2119800
ED714 - digital temperature sensor: -25 °C to +50 °C	2071181
ED717 - digital temperature sensor: -40 °C to +70 °C	2071177
Gearing plug 1/4"	2087388
Gearing plug 1/4"	2087400
Pipe union fitting for pipe diameter 6 mm	2071171
Pipe union fitting for pipe diameter 1/4"	2089073
Adaptor from 3/8" 1/4" male thread to G1/4" female thread	2075804

FLWSIC500

9 Annex

Conformities and Technical Data

Application ranges

Volume conversion: input variables and limit values of the algorithms

Type code

Type plates

Dimensional drawings

Internal terminal assignment

Installation examples

Connection diagrams for operation of the FLWSIC500 in accordance with CSA

Connection diagrams for operation of the FLWSIC500 in accordance with ATEX
IECEx

8.1 Conformities and Technical Data

8.1.1 CE certificate

The FLOW5000 has been developed, manufactured and tested in accordance with the following EU Directives:

- Pressure Equipment Directive 2014/68/EU
- ATEX Directive 2014/34/EU
- EMC Directive 2014/53/EU
- Measuring Instrument Directive 2014/32/EU

Conformity with the above Directives has been determined and the CE label attached to the device.

8.1.2 Standards compatibility

The FLOW5000 conforms to the following standards or recommendations:

- OMA R137.0&2 - 2012
See Annex - Part 1: Manufacturing And Technical Requirements; Part 2: Manufacturing Controls And Performance Tests
- EN 60079-0:2012, IEC 60079-0:2012, EN 60079-11:2012, EN 60079-32:2007
Explosive atmospheres - Part 0: Equipment - General requirements; Part 11: Equipment protection by intrinsic safety "i"; Part 32: Protection of equipment and transmission systems using optical isolation
- IEC 60079-0: 2011, IEC 60079-32: 2011 (0th Edition)
Explosive atmospheres - Part 0: Equipment - General requirements; Part 32: Protection of equipment and transmission systems using optical isolation
- IEC 60079-11: 2011 - 0th - 2012 (0th Edition)
Explosive atmospheres - Part 11: Equipment protection by intrinsic safety "i"
- EN 61326-1:2009
Electrical equipment for measurement, control and laboratory use - EMC requirements - Part 1: General requirements (IEC 61326-1:2009)
- IEC 61326:2009
Electrical equipment for measurement, control and laboratory use - EMC requirements
- EN 61326-1:2009
Safety requirements for electrical equipment for measurement, control, and laboratory use - Part 1: General requirements (IEC 61326-1:2009)
- IEC 61310-1:2010 - 0th - 2011
Safety requirements for electrical equipment for measurement, control and laboratory use - Part 1: General requirements
- EN 12485-1-02:2010-03
See Annex - Connection Devices - Part 1: Volume connector

6.1.3 Technical Data

Basic characteristics and measuring parameters		
Measured variable	Volume flow, volume flow rate	
Measuring principle	Ultrasonic transit time difference measurement	
Measured medium	Natural gas (dry, odorless, nitrogen-free) up to 30 % hydrogen in natural gas	
Measuring range (1)	Volume flow rate: 0.050 ... 1.5 m ³ /h (0.001 ... 0.025 m ³ /min)	
	Volume flow rate: 0.050 ... 3 m ³ /h (0.001 ... 0.014 m ³ /min)	
	Volume flow rate: 20 ... 100 m ³ /h (0.001 ... 0.004 m ³ /min)	
	Volume flow rate: 0.050 ... 5 m ³ /h (0.001 ... 0.014 m ³ /min)	
Repeatability	±0.1%	
Accuracy	Accuracy class 1, typical error limits: Q _{min} up to 0.1 Q _{nom} : ±0.10 % 0.1 Q _{nom} up to Q _{nom} : ±0.05 % Accuracy class 2, maximum allowed error limits: Q _{min} up to 0.1 Q _{nom} : ±0.20 % 0.1 Q _{nom} up to Q _{nom} : ±0.10 % After NIST flow rate calibration: ±0.2% with fast pressure response ±0.2%	
Diagnostic functions	Permanent monitoring of measured values	
Gas temperature	-25 °C ... +60 °C (-13 °F ... 140 °F) optional: -40 °C ... +75 °C (-40 °F ... 165 °F)	
Operating pressure	PN16 (EN 10625, GOST 18254-80): 0 bar(g) ... 16 bar(g) Class 150 (ASME B16.5): 0 bar(g) ... 20 bar(g)	
Ambient conditions		
Ambient temperature	-25 °C ... +60 °C (-13 °F ... 140 °F) optional: -40 °C ... +75 °C (-40 °F ... 165 °F)	
Storage temperature	-40 °C ... +85 °C (-40 °F ... 175 °F)	
Electromagnetic conditions (EMC)	EMC in accordance with EN 61327-1:2012	
Mechanical conditions	IP67 in accordance with DIN EN 60529:2012	
Approvals		
Certification	- p 140, EN 1	
Ex approvals	ExC	Ex ia [ia] IIB T4 Gc, Ex ia [ia] IIC T4 Gc, Ex op IIC T4 Gc
	ATEX	(120 Ex ia) IIB T4 Gc, (120 Ex ia) IIC T4 Gc, (120 Ex op) IIC T4 Gc
	NEC/CEC (UL/CSA)	CSA 1, 2, 1H Class I, Division 1, Groups C, D, F, G, E, AEx ia IIB T4 Gc
IP classification	IP 68	
Outputs and interfaces	Configurations: • 1 x pulse + mA function, electrically isolated (I _{max} = 100 mA) • 4 x pulse + mA function, electrically isolated (I _{max} = 1 mA) • 8 output + 1 x pulse, electrically isolated (I _{max} = 100 mA) • 8 output, electrically isolated + 4 x pulse, not electrically isolated (I _{max} = 1 mA) • 2 x 1 x pulse, electrically isolated (I _{max} = 100 mA) Digital outputs and interfaces: • RS-485 module, externally powered, 2 terminals to digital output (Protocol Modbus RTU) • RS-485 module, externally powered + 4 x pulse, electrically isolated (I _{max} = 2 mA) • RS-485 module, externally powered + 1 x pulse, electrically isolated (I _{max} = 100 mA) • Optical interface (according to EN 60595-21 (Section 4.3.3)) • Device option RS-485 module, externally powered	

Installation	
Dimensions (h x w x d)	See dimensions drawings – p. 188, § 6.6
Weight	See dimensions drawings – p. 188, § 6.6
Material (in contact with media)	Aluminum 40-42/100-5/10
Mounting	Horizontal or vertical installation with 60° weight relief safety angle
Electrical connection	
Voltage	Internally wire supply: 4...16 V DC Including 3-months backup battery
Power input	≤ 100 mW
General	
Options	Self-sufficient make (weight relief) battery service life: more than 3 years
Scope of delivery	The scope of delivery is dependent on the application and the customer configuration
General	
Battery type	Battery pack I210 – 5043990 Ferran SL-500
	Battery pack I210 – 6050482 Technic SL-2500
Battery chemistry	Lithium-Iron (chemda.ca) – Li-ION2

(1) Information according to AGA 9

- DN10 (1") 1.6 ... 180 m³/h (57 ... 6,890 cfm)
- DN15 (1/2") 4.0 ... 400 m³/h (141 ... 14,126 cfm)
- DN20 (3/4") 6.6 ... 880 m³/h (233 ... 31,388 cfm)
- DN25 (1") 6.6 ... 1,000 m³/h (233 ... 35.3 cfm)

Table 15: Technical Data (optional for gas) according to your configuration

Volume dimension											
Accuracy	Accuracy class 0.5 Maximum allowed asymmetry of measurement factor C: 0.5 ± 0.5% (at reference conditions)										
Conversion method	PTC or T2										
Calculation method	• First value • ISO9505 • AGA 9 Gross method 1 • AGA 9 Gross method 2 • AGA 10/15 • AGA 10/15 mod. • AGA 10/15 mod. 2007 • ISO9505 mod. • AGA9-9100 (AGA 9 data)										
Additional unit features											
Logbook	• Operatingbook (1000 entries) • Remote logbook (150 entries) • Memory logbook (100 entries) • Gas consumption logbook (150 entries)										
Alarm	• Sling alarm (5000 entries) • Day alarm (600 entries) • Month alarm (25 entries)										
Pressure sensor (only for device option volume dimension)											
Measuring range	<table border="1"> <thead> <tr> <th>Absolute pressure sensors</th><th>Relative pressure sensors</th></tr> </thead> <tbody> <tr> <td>0.5 ... 5.2 bar (a)</td><td>0 ... 4 bar (g)</td></tr> <tr> <td>1.0 ... 13.0 bar (a)</td><td>0 ... 10 bar (g)</td></tr> <tr> <td>4.0 ... 20.0 bar (a)</td><td>0 ... 20 bar (g)</td></tr> <tr> <td>0.5 ... 20.0 bar (a)</td><td></td></tr> </tbody> </table>	Absolute pressure sensors	Relative pressure sensors	0.5 ... 5.2 bar (a)	0 ... 4 bar (g)	1.0 ... 13.0 bar (a)	0 ... 10 bar (g)	4.0 ... 20.0 bar (a)	0 ... 20 bar (g)	0.5 ... 20.0 bar (a)	
Absolute pressure sensors	Relative pressure sensors										
0.5 ... 5.2 bar (a)	0 ... 4 bar (g)										
1.0 ... 13.0 bar (a)	0 ... 10 bar (g)										
4.0 ... 20.0 bar (a)	0 ... 20 bar (g)										
0.5 ... 20.0 bar (a)											
Temperature sensor (only for device option volume dimension)											
Measuring range	-25 ... +50 °C -40 ... +70 °C (optional)										

- (1) Remote configuration with the gas data option: consult the manufacturer's pressure map, or contact the pressure sensor of the book. The pressure rating indicated on the sensor type plate applies.

§ 1.4 Design pressure and design temperature

Please refer to the supplied acceptance test certificate (E1 10004-E 1) and the type plate in the adapter for the actual values for the design pressure and design temperature for your specific device.

1998, 1999, 2000, 2001, 2002, 2003, 2004, 2005, 2006, 2007, 2008, 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018, 2019, 2020, 2021, 2022, 2023, 2024, 2025, 2026, 2027, 2028, 2029, 2030, 2031, 2032, 2033, 2034, 2035, 2036, 2037, 2038, 2039, 2040, 2041, 2042, 2043, 2044, 2045, 2046, 2047, 2048, 2049, 2050, 2051, 2052, 2053, 2054, 2055, 2056, 2057, 2058, 2059, 2060, 2061, 2062, 2063, 2064, 2065, 2066, 2067, 2068, 2069, 2070, 2071, 2072, 2073, 2074, 2075, 2076, 2077, 2078, 2079, 2080, 2081, 2082, 2083, 2084, 2085, 2086, 2087, 2088, 2089, 2090, 2091, 2092, 2093, 2094, 2095, 2096, 2097, 2098, 2099, 2100, 2101, 2102, 2103, 2104, 2105, 2106, 2107, 2108, 2109, 2110, 2111, 2112, 2113, 2114, 2115, 2116, 2117, 2118, 2119, 2120, 2121, 2122, 2123, 2124, 2125, 2126, 2127, 2128, 2129, 2130, 2131, 2132, 2133, 2134, 2135, 2136, 2137, 2138, 2139, 2140, 2141, 2142, 2143, 2144, 2145, 2146, 2147, 2148, 2149, 2150, 2151, 2152, 2153, 2154, 2155, 2156, 2157, 2158, 2159, 2160, 2161, 2162, 2163, 2164, 2165, 2166, 2167, 2168, 2169, 2170, 2171, 2172, 2173, 2174, 2175, 2176, 2177, 2178, 2179, 2180, 2181, 2182, 2183, 2184, 2185, 2186, 2187, 2188, 2189, 2190, 2191, 2192, 2193, 2194, 2195, 2196, 2197, 2198, 2199, 2200, 2201, 2202, 2203, 2204, 2205, 2206, 2207, 2208, 2209, 2210, 2211, 2212, 2213, 2214, 2215, 2216, 2217, 2218, 2219, 2220, 2221, 2222, 2223, 2224, 2225, 2226, 2227, 2228, 2229, 2230, 2231, 2232, 2233, 2234, 2235, 2236, 2237, 2238, 2239, 2240, 2241, 2242, 2243, 2244, 2245, 2246, 2247, 2248, 2249, 2250, 2251, 2252, 2253, 2254, 2255, 2256, 2257, 2258, 2259, 2260, 2261, 2262, 2263, 2264, 2265, 2266, 2267, 2268, 2269, 2270, 2271, 2272, 2273, 2274, 2275, 2276, 2277, 2278, 2279, 2280, 2281, 2282, 2283, 2284, 2285, 2286, 2287, 2288, 2289, 2290, 2291, 2292, 2293, 2294, 2295, 2296, 2297, 2298, 2299, 2300, 2301, 2302, 2303, 2304, 2305, 2306, 2307, 2308, 2309, 2310, 2311, 2312, 2313, 2314, 2315, 2316, 2317, 2318, 2319, 2320, 2321, 2322, 2323, 2324, 2325, 2326, 2327, 2328, 2329, 2330, 2331, 2332, 2333, 2334, 2335, 2336, 2337, 2338, 2339, 2340, 2341, 2342, 2343, 2344, 2345, 2346, 2347, 2348, 2349, 2350, 2351, 2352, 2353, 2354, 2355, 2356, 2357, 2358, 2359, 2360, 2361, 2362, 2363, 2364, 2365, 2366, 2367, 2368, 2369, 2370, 2371, 2372, 2373, 2374, 2375, 2376, 2377, 2378, 2379, 2380, 2381, 2382, 2383, 2384, 2385, 2386, 2387, 2388, 2389, 2390, 2391, 2392, 2393, 2394, 2395, 2396, 2397, 2398, 2399, 2400, 2401, 2402, 2403, 2404, 2405, 2406, 2407, 2408, 2409, 2410, 2411, 2412, 2413, 2414, 2415, 2416, 2417, 2418, 2419, 2420, 2421, 2422, 2423, 2424, 2425, 2426, 2427, 2428, 2429, 2430, 2431, 2432, 2433, 2434, 2435, 2436, 2437, 2438, 2439, 2440, 2441, 2442, 2443, 2444, 2445, 2446, 2447, 2448, 2449, 2450, 2451, 2452, 2453, 2454, 2455, 2456, 2457, 2458, 2459, 2460, 2461, 2462, 2463, 2464, 2465, 2466, 2467, 2468, 2469, 2470, 2471, 2472, 2473, 2474, 2475, 2476, 2477, 2478, 2479, 2480, 2481, 2482, 2483, 2484, 2485, 2486, 2487, 2488, 2489, 2490, 2491, 2492, 2493, 2494, 2495, 2496, 2497, 2498, 2499, 2500, 2501, 2502, 2503, 2504, 2505, 2506, 2507, 2508, 2509, 2510, 2511, 2512, 2513, 2514, 2515, 2516, 2517, 2518, 2519, 2520, 2521, 2522, 2523, 2524, 2525, 2526, 2527, 2528, 2529, 2530, 2531, 2532, 2533, 2534, 2535, 2536, 2537, 2538, 2539, 2540, 2541, 2542, 2543, 2544, 2545, 2546, 2547, 2548, 2549, 2550, 2551, 2552, 2553, 2554, 2555, 2556, 2557, 2558, 2559, 2560, 2561, 2562, 2563, 2564, 2565, 2566, 2567, 2568, 2569, 2570, 2571, 2572, 2573, 2574, 2575, 2576, 2577, 2578, 2579, 2580, 2581, 2582, 2583, 2584, 2585, 2586, 2587, 2588, 2589, 2590, 2591, 2592, 2593, 2594, 2595, 2596, 2597, 2598, 2599, 2600, 2601, 2602, 2603, 2604, 2605, 2606, 2607, 2608, 2609, 2610, 2611, 2612, 2613, 2614, 2615, 2616, 2617, 2618, 2619, 2620, 2621, 2622, 2623, 2624, 2625, 2626, 2627, 2628, 2629, 2630, 2631, 2632, 2633, 2634, 2635, 2636, 2637, 2638, 2639, 2640, 2641, 2642, 2643, 2644, 2645, 2646, 2647, 2648, 2649, 2650, 2651, 2652, 2653, 2654, 2655, 2656, 2657, 2658, 2659, 2660, 2661, 2662, 2663, 2664, 2665, 2666, 2667, 2668, 2669, 2670, 2671, 2672, 2673, 2674, 2675, 2676, 2677, 2678, 2679, 26

FLWSIC500: Inspection Certificate:

Copyright © 2004 John Wiley & Sons, Inc.

[illegible]

Example 2.20b *How state*



- [illegible]

5.1.5 Flow rates

Table 59 Flow rates

Hydro size	Q (l/s)	measured (m³/h)	measured (m³/h)	hydro rate
2000 / 2"	0.40	1.3 - 55	49.5 - 2.030.3	1.60
	0.65	2.0 - 100	70.6 - 3.030.6	1.60
	0.90	3.2 - 140	113.0 - 5.050.3	1.60
	0.100	1.0 - 140	35.3 - 3.030.3	1.180
2000 / 3"	0.100	3.2 - 140	113.0 - 5.050.3	1.60
	0.160	5.0 - 230	179.6 - 8.028.7	1.60
	0.160	2.5 - 230	88.3 - 8.028.7	1.130
	0.250	8.0 - 400	283.6 - 14.126.9	1.60
2000 / 4"	0.250	4.0 - 400	141.8 - 14.126.9	1.130
	0.250	2.5 - 400	88.3 - 14.126.9	1.180
	0.100	5.0 - 230	179.6 - 8.028.7	1.60
	0.160	8.0 - 400	283.6 - 14.126.9	1.60
2000 / 4"	0.250	4.0 - 400	141.8 - 14.126.9	1.130
	0.250	13.0 - 590	489.1 - 21.954.9	1.60
	0.400	8.5 - 590	329.9 - 21.954.9	1.130
	0.400	4.0 - 590	141.8 - 21.954.9	1.180
2000 / 5"	0.250	5.0 - 400	179.6 - 14.126.9	1.60
	0.250	4.0 - 400	141.8 - 14.126.9	1.130
	0.400	13.0 - 590	489.1 - 21.954.9	1.60
	0.400	8.5 - 590	329.9 - 21.954.9	1.130
2000 / 5"	0.400	4.0 - 590	141.8 - 21.954.9	1.180
	0.650	20.0 - 1000	700.3 - 35.314.7	1.60
	0.650	10.0 - 1000	353.1 - 35.314.7	1.130
	0.850	8.1 - 1000	218.0 - 35.314.7	1.180
2000 / 5"	0.850	5.0 - 1000	179.6 - 35.314.7	1.200
	0.950	4.0 - 1000	141.8 - 35.314.7	1.250

5.1.6 Overload protection

Table 60 Overload protection

Hydro size	Q _{max}	Q _{max}	Q _{max}	Q _{max}	Q _{max}
2000 / 2"	1.30	5.950	180% Q _{max}	240	8.475
2000 / 3"	400	14.123	180% Q _{max}	800	21.127.5
2000 / 4"	850	22.955	180% Q _{max}	975	34.432.5
2000 / 5"	1.000	35.314	180% Q _{max}	1.200	42.378.5


E.1 Application ranges

The following diagrams describe the promised measuring characteristics of the FLOWSi500 in relation to different gas compositions and process conditions. The diagrams are used to better check the suitability of the device before installation.

The characteristics in the diagrams should be interpreted as guidelines, not as absolute limit values. Please contact your Endress+Hauser representative for evaluation of your specific application.

E.2 Pressure loss

Fig. E4 Typical pressure loss FLOWSi500




5.1.2 Methane concentration (CH₄) in natural gas

In case high methane concentrations, the FLDING5000 requires a minimum operating pressure for meter size DN50 up to DN150. Methane has a damping effect on the signal transmission.

Meter size DN50

Fig. 55 Minimum operating pressure CH₄ (E)



Meter size DN50, DN100, DN150

Fig. 56 Minimum operating pressure CH₄, CH₄/CO₂, CH₄/H₂





Fig. 57 Carbon dioxide concentration (CO₂) in natural gas

The measuring capability of the FLOWSiC500 is limited by a maximum carbon dioxide concentration.


Meter size DN50

Fig. 57 Maximum carbon dioxide concentration DN50



Meter size DN80 / DN100 / DN150

Fig. 58 Maximum carbon dioxide concentration DN80 / DN100 / DN150



314

Speed of sound

The speed of sound of the measured gas needs to be in a range of 300 m/s to 600 m/s.

3.3 Volume conversion: input variables and limit values of the algorithm

3.3.1 3GER088

Parameter	Normal range	Expanded range	Unit
Heating value	30.48	20.48	$\text{kJ} \cdot \text{m}^{-3}$
Relative density	0.55-1.2	0.55-1.2	-
Visa factor CO2	0.02	0.03	mol/mol
Visa factor H2	0.01	0.01	mol/mol
Pressure	0.120	0.120	bar(a)
Temperature	-10.85	-10.85	$^{\circ}\text{C}$

3.3.2 AGA 8 Gross method 1 und 2

Parameter	AGA 8 Gross 1	AGA 8 Gross 2	Unit
Heating value	18.7-48.1	-	$\text{kJ} \cdot \text{m}^{-3}$
Relative density	0.554-0.67	0.554-0.67	-
Visa factor CO2	0.03	0.03	mol/mol
Visa factor H2	-	0.03	mol/mol
Visa factor H2	0.01	0.01	mol/mol
Pressure	0.120	0.120	bar(a)
Temperature	-8.82	-8.82	$^{\circ}\text{C}$

3.3.3 AGA NX-19 und NX-19 mod.

Parameter	NX19	NX19mod	AGA NX-19 Gas 2m Unit	Unit
Heating value	-	31.8-39.8	39.8-48.1	$\text{kJ} \cdot \text{m}^{-3}$
Relative density	0.554-1.0	0.554-0.78	0.554-0.691	-
Visa factor CO2	0.015	0.015	0.025	mol/mol
Visa factor H2	0.015	0.015	0.07	mol/mol
Pressure	0.344-74	0.120-8	0.30	bar(a)
Temperature	-40.112-58	-40.112-8	0.30	$^{\circ}\text{C}$

3.3.4 AGA NX-19 mod GOST

Parameter	NX-19mod-GOST	Unit
Reference density	0.55-1.0	$\text{kg} \cdot \text{m}^{-3}$
Visa factor CO2	0.015	mol/mol
Visa factor H2	0.02	mol/mol
Pressure	0.120	bar(a)
Temperature	-21.15-86.55	$^{\circ}\text{C}$

3.3.5 GER091 mod.

Parameter	Normal range	Expanded range	Unit
Reference density	0.55-1.05	0.55-1.05	$\text{kg} \cdot \text{m}^{-3}$
Visa factor CO2	0.02	0.02	mol/mol
Visa factor H2	0.02	0.02	mol/mol
Pressure	0.75	0.120	bar(a)
Temperature	-22.15-78.55	-22.15-78.55	$^{\circ}\text{C}$

Table 1: AGA8-B2DC (AGA-8 Detail)

Parameter	Normal range	Extended range	Unit
Molar fraction methane	0.45 - 1.0	0 - 1	mol/mol
Molar fraction N_2	0 - 0.5	0 - 1	mol/mol
Molar fraction CO_2	0 - 0.5	0 - 1	mol/mol
Molar fraction Ethane	0 - 0.1	0 - 1	mol/mol
Molar fraction Propane	0 - 0.04	0 - 0.12	mol/mol
Molar fraction Water	0 - 0.0008	0 - 10^{-6}	mol/mol
Molar fraction Hydrogen Sulfide	0 - 0.0001	0 - 1	mol/mol
Molar fraction H_2	0 - 0.1	0 - 1	mol/mol
Molar fraction Carbon Monoxide	0 - 0.01	0 - 0.03	mol/mol
Molar fraction Oxygen	-	0 - 0.21	mol/mol
Molar fraction n-Butane	0 - 0.01111	0 - 0.054	mol/mol
Molar fraction n-Pentane	0 - 0.01111	0 - 0.054	mol/mol
Molar fraction n-Hexane	0 - 0.00222	0 - 0.0108	mol/mol
Molar fraction n-Heptane	0 - 0.00222	0 - 0.0108	mol/mol
Molar fraction n-Octane	0 - 0.00222	0 - 10^{-6}	mol/mol
Molar fraction n-Nonane	0 - 0.00222	0 - 10^{-6}	mol/mol
Molar fraction n-Decane	0 - 0.00222	0 - 10^{-6}	mol/mol
Molar fraction Helium	0 - 0.002	0 - 0.03	mol/mol
Molar fraction Argon	-	0 - 0.01	mol/mol
Pressure	0 - 1379	0 - 1375	bar(a)
Temperature	-123 - 204	-123 - 204	°C

- (1) The sum of all hydrocarbon factors must not exceed the specified limit.
- (2) The sum of all oxygen factors must not exceed the specified limit.
- (3) The sum of all hydrocarbon factors n-Heptane must not exceed the specified limit.
- (4) The algorithm is only valid up to the dew point. Before applying the algorithm, make sure that the gas is completely in the gas phase (above dew point).

E.4 Type code

Fig. E8 Type code FLV551C500 (internal)



pg. 75

Type 0049 FLUENCY OF EXPRESSION

3	Don't forget
4	Don't forget to
5	Don't forget to
6	Don't forget to
7	Don't forget to
8	Don't forget to
9	Don't forget to
10	Don't forget to
11	Don't forget to
12	Don't forget to
13	Don't forget to
14	Don't forget to
15	Don't forget to
16	Don't forget to
17	Don't forget to
18	Don't forget to
19	Don't forget to
20	Don't forget to
21	Don't forget to
22	Don't forget to
23	Don't forget to
24	Don't forget to
25	Don't forget to
26	Don't forget to
27	Don't forget to
28	Don't forget to
29	Don't forget to
30	Don't forget to
31	Don't forget to
32	Don't forget to
33	Don't forget to
34	Don't forget to
35	Don't forget to
36	Don't forget to
37	Don't forget to
38	Don't forget to
39	Don't forget to
40	Don't forget to
41	Don't forget to
42	Don't forget to
43	Don't forget to
44	Don't forget to
45	Don't forget to
46	Don't forget to
47	Don't forget to
48	Don't forget to
49	Don't forget to
50	Don't forget to
51	Don't forget to
52	Don't forget to
53	Don't forget to
54	Don't forget to
55	Don't forget to
56	Don't forget to
57	Don't forget to
58	Don't forget to
59	Don't forget to
60	Don't forget to
61	Don't forget to
62	Don't forget to
63	Don't forget to
64	Don't forget to
65	Don't forget to
66	Don't forget to
67	Don't forget to
68	Don't forget to
69	Don't forget to
70	Don't forget to
71	Don't forget to
72	Don't forget to
73	Don't forget to
74	Don't forget to
75	Don't forget to
76	Don't forget to
77	Don't forget to
78	Don't forget to
79	Don't forget to
80	Don't forget to
81	Don't forget to
82	Don't forget to
83	Don't forget to
84	Don't forget to
85	Don't forget to
86	Don't forget to
87	Don't forget to
88	Don't forget to
89	Don't forget to
90	Don't forget to
91	Don't forget to
92	Don't forget to
93	Don't forget to
94	Don't forget to
95	Don't forget to
96	Don't forget to
97	Don't forget to
98	Don't forget to
99	Don't forget to
100	Don't forget to

101	Don't forget to
102	Don't forget to
103	Don't forget to
104	Don't forget to
105	Don't forget to
106	Don't forget to
107	Don't forget to
108	Don't forget to
109	Don't forget to
110	Don't forget to
111	Don't forget to
112	Don't forget to
113	Don't forget to
114	Don't forget to
115	Don't forget to
116	Don't forget to
117	Don't forget to
118	Don't forget to
119	Don't forget to
120	Don't forget to
121	Don't forget to
122	Don't forget to
123	Don't forget to
124	Don't forget to
125	Don't forget to
126	Don't forget to
127	Don't forget to
128	Don't forget to
129	Don't forget to
130	Don't forget to
131	Don't forget to
132	Don't forget to
133	Don't forget to
134	Don't forget to
135	Don't forget to
136	Don't forget to
137	Don't forget to
138	Don't forget to
139	Don't forget to
140	Don't forget to
141	Don't forget to
142	Don't forget to
143	Don't forget to
144	Don't forget to
145	Don't forget to
146	Don't forget to
147	Don't forget to
148	Don't forget to
149	Don't forget to
150	Don't forget to
151	Don't forget to
152	Don't forget to
153	Don't forget to
154	Don't forget to
155	Don't forget to
156	Don't forget to
157	Don't forget to
158	Don't forget to
159	Don't forget to
160	Don't forget to
161	Don't forget to
162	Don't forget to
163	Don't forget to
164	Don't forget to
165	Don't forget to
166	Don't forget to
167	Don't forget to
168	Don't forget to
169	Don't forget to
170	Don't forget to
171	Don't forget to
172	Don't forget to
173	Don't forget to
174	Don't forget to
175	Don't forget to
176	Don't forget to
177	Don't forget to
178	Don't forget to
179	Don't forget to
180	Don't forget to
181	Don't forget to
182	Don't forget to
183	Don't forget to
184	Don't forget to
185	Don't forget to
186	Don't forget to
187	Don't forget to
188	Don't forget to
189	Don't forget to
190	Don't forget to
191	Don't forget to
192	Don't forget to
193	Don't forget to
194	Don't forget to
195	Don't forget to
196	Don't forget to
197	Don't forget to
198	Don't forget to
199	Don't forget to
200	Don't forget to

9.9 Type plates

9.9.1 Metrology and electronics type plates

Fig. 71 Legend for type plates

Symbol	Description	Description
1	Flowmeter	Flowmeter
2	Flowmeter (variable pressure)	Flowmeter (variable pressure)
3	Flowmeter	Flowmeter
4	Flowmeter (variable pressure)	Flowmeter (variable pressure)
5	Flowmeter	Flowmeter
6	Flowmeter (variable pressure)	Flowmeter (variable pressure)
7	Flowmeter	Flowmeter
8	Flowmeter (variable pressure)	Flowmeter (variable pressure)
9	Flowmeter	Flowmeter
10	Flowmeter (variable pressure)	Flowmeter (variable pressure)
11	Flowmeter	Flowmeter
12	Flowmeter (variable pressure)	Flowmeter (variable pressure)
13	Flowmeter	Flowmeter
14	Flowmeter (variable pressure)	Flowmeter (variable pressure)
15	Flowmeter	Flowmeter
16	Flowmeter (variable pressure)	Flowmeter (variable pressure)
17	Flowmeter	Flowmeter
18	Flowmeter (variable pressure)	Flowmeter (variable pressure)
19	Flowmeter	Flowmeter
20	Flowmeter (variable pressure)	Flowmeter (variable pressure)
21	Flowmeter	Flowmeter
22	Flowmeter (variable pressure)	Flowmeter (variable pressure)
23	Flowmeter	Flowmeter
24	Flowmeter (variable pressure)	Flowmeter (variable pressure)
25	Flowmeter	Flowmeter
26	Flowmeter (variable pressure)	Flowmeter (variable pressure)
27	Flowmeter	Flowmeter
28	Flowmeter (variable pressure)	Flowmeter (variable pressure)
29	Flowmeter	Flowmeter
30	Flowmeter (variable pressure)	Flowmeter (variable pressure)
31	Flowmeter	Flowmeter
32	Flowmeter (variable pressure)	Flowmeter (variable pressure)
33	Flowmeter	Flowmeter
34	Flowmeter (variable pressure)	Flowmeter (variable pressure)
35	Flowmeter	Flowmeter
36	Flowmeter (variable pressure)	Flowmeter (variable pressure)
37	Flowmeter	Flowmeter
38	Flowmeter (variable pressure)	Flowmeter (variable pressure)
39	Flowmeter	Flowmeter
40	Flowmeter (variable pressure)	Flowmeter (variable pressure)
41	Flowmeter	Flowmeter
42	Flowmeter (variable pressure)	Flowmeter (variable pressure)
43	Flowmeter	Flowmeter
44	Flowmeter (variable pressure)	Flowmeter (variable pressure)
45	Flowmeter	Flowmeter
46	Flowmeter (variable pressure)	Flowmeter (variable pressure)
47	Flowmeter	Flowmeter
48	Flowmeter (variable pressure)	Flowmeter (variable pressure)
49	Flowmeter	Flowmeter
50	Flowmeter (variable pressure)	Flowmeter (variable pressure)
51	Flowmeter	Flowmeter
52	Flowmeter (variable pressure)	Flowmeter (variable pressure)
53	Flowmeter	Flowmeter
54	Flowmeter (variable pressure)	Flowmeter (variable pressure)
55	Flowmeter	Flowmeter
56	Flowmeter (variable pressure)	Flowmeter (variable pressure)
57	Flowmeter	Flowmeter
58	Flowmeter (variable pressure)	Flowmeter (variable pressure)
59	Flowmeter	Flowmeter
60	Flowmeter (variable pressure)	Flowmeter (variable pressure)
61	Flowmeter	Flowmeter
62	Flowmeter (variable pressure)	Flowmeter (variable pressure)
63	Flowmeter	Flowmeter
64	Flowmeter (variable pressure)	Flowmeter (variable pressure)
65	Flowmeter	Flowmeter
66	Flowmeter (variable pressure)	Flowmeter (variable pressure)
67	Flowmeter	Flowmeter
68	Flowmeter (variable pressure)	Flowmeter (variable pressure)
69	Flowmeter	Flowmeter
70	Flowmeter (variable pressure)	Flowmeter (variable pressure)
71	Flowmeter	Flowmeter
72	Flowmeter (variable pressure)	Flowmeter (variable pressure)
73	Flowmeter	Flowmeter
74	Flowmeter (variable pressure)	Flowmeter (variable pressure)
75	Flowmeter	Flowmeter
76	Flowmeter (variable pressure)	Flowmeter (variable pressure)
77	Flowmeter	Flowmeter
78	Flowmeter (variable pressure)	Flowmeter (variable pressure)
79	Flowmeter	Flowmeter
80	Flowmeter (variable pressure)	Flowmeter (variable pressure)
81	Flowmeter	Flowmeter
82	Flowmeter (variable pressure)	Flowmeter (variable pressure)
83	Flowmeter	Flowmeter
84	Flowmeter (variable pressure)	Flowmeter (variable pressure)
85	Flowmeter	Flowmeter
86	Flowmeter (variable pressure)	Flowmeter (variable pressure)
87	Flowmeter	Flowmeter
88	Flowmeter (variable pressure)	Flowmeter (variable pressure)
89	Flowmeter	Flowmeter
90	Flowmeter (variable pressure)	Flowmeter (variable pressure)
91	Flowmeter	Flowmeter
92	Flowmeter (variable pressure)	Flowmeter (variable pressure)
93	Flowmeter	Flowmeter
94	Flowmeter (variable pressure)	Flowmeter (variable pressure)
95	Flowmeter	Flowmeter
96	Flowmeter (variable pressure)	Flowmeter (variable pressure)
97	Flowmeter	Flowmeter
98	Flowmeter (variable pressure)	Flowmeter (variable pressure)
99	Flowmeter	Flowmeter
100	Flowmeter (variable pressure)	Flowmeter (variable pressure)

9.9.2 Identify (permanently according to ATEX/IECE)

Fig. 72 Metrology and electronics type plate example



10. The flowmeter is not suitable for use in explosive atmospheres.



On a system of algebraic connectives

Drinking Water

CE marking: CE 018-00

Warning:

Property	Value	Property	Value
Flow	1.5 l/min	Flow	1.5 l/min
Pressure	1.0 bar	Pressure	1.0 bar
Temperature	10.0 °C	Temperature	10.0 °C
Power	1.0 W	Power	1.0 W

Fishing Tackle

CE marking: CE 018-00

Warning:

Property	Value	Property	Value
Flow	1.5 l/min	Flow	1.5 l/min
Pressure	1.0 bar	Pressure	1.0 bar
Temperature	10.0 °C	Temperature	10.0 °C
Power	1.0 W	Power	1.0 W

3.3.2 Identification according to CSA

Fig. 14. *Illustration of the proposed design.*

222
 223
 224
 225
 226
 227
 228
 229
 230
 231
 232
 233
 234
 235
 236
 237
 238
 239
 240
 241
 242
 243
 244
 245
 246
 247
 248
 249
 250
 251
 252
 253
 254
 255
 256
 257
 258
 259
 260
 261
 262
 263
 264
 265
 266
 267
 268
 269
 270
 271
 272
 273
 274
 275
 276
 277
 278
 279
 280
 281
 282
 283
 284
 285
 286
 287
 288
 289
 290
 291
 292
 293
 294
 295
 296
 297
 298
 299
 300
 301
 302
 303
 304
 305
 306
 307
 308
 309
 310
 311
 312
 313
 314
 315
 316
 317
 318
 319
 320
 321
 322
 323
 324
 325
 326
 327
 328
 329
 330
 331
 332
 333
 334
 335
 336
 337
 338
 339
 340
 341
 342
 343
 344
 345
 346
 347
 348
 349
 350
 351
 352
 353
 354
 355
 356
 357
 358
 359
 360
 361
 362
 363
 364
 365
 366
 367
 368
 369
 370
 371
 372
 373
 374
 375
 376
 377
 378
 379
 380
 381
 382
 383
 384
 385
 386
 387
 388
 389
 390
 391
 392
 393
 394
 395
 396
 397
 398
 399
 400
 401
 402
 403
 404
 405
 406
 407
 408
 409
 410
 411
 412
 413
 414
 415
 416
 417
 418
 419
 420
 421
 422
 423
 424
 425
 426
 427
 428
 429
 430
 431
 432
 433
 434
 435
 436
 437
 438
 439
 440
 441
 442
 443
 444
 445
 446
 447
 448
 449
 450
 451
 452
 453
 454
 455
 456
 457
 458
 459
 460
 461
 462
 463
 464
 465
 466
 467
 468
 469
 470
 471
 472
 473
 474
 475
 476
 477
 478
 479
 480
 481
 482
 483
 484
 485
 486
 487
 488
 489
 490
 491
 492
 493
 494
 495
 496
 497
 498
 499
 500
 501
 502
 503
 504
 505
 506
 507
 508
 509
 510
 511
 512
 513
 514
 515
 516
 517
 518
 519
 520
 521
 522
 523
 524
 525
 526
 527
 528
 529
 530
 531
 532
 533
 534
 535
 536
 537
 538
 539
 540
 541
 542
 543
 544
 545
 546
 547
 548
 549
 550
 551
 552
 553
 554
 555
 556
 557
 558
 559
 560
 561
 562
 563
 564
 565
 566
 567
 568
 569
 570
 571
 572
 573
 574
 575
 576
 577
 578
 579
 580
 581
 582
 583
 584
 585
 586
 587
 588
 589
 590
 591
 592
 593
 594
 595
 596
 597
 598
 599
 600
 601
 602
 603
 604
 605
 606
 607
 608
 609
 610
 611
 612
 613
 614
 615
 616
 617
 618
 619
 620
 621
 622
 623
 624
 625
 626
 627
 628
 629
 630
 631
 632
 633
 634
 635
 636
 637
 638
 639
 640
 641
 642
 643
 644
 645
 646
 647
 648
 649
 650
 651
 652
 653
 654
 655
 656
 657
 658
 659
 660
 661
 662
 663
 664
 665
 666
 667
 668
 669
 670
 671
 672
 673
 674
 675
 676
 677
 678
 679
 680
 681
 682
 683
 684
 685
 686
 687
 688
 689
 690
 691
 692
 693
 694
 695
 696
 697
 698
 699
 700
 701
 702
 703
 704
 705
 706
 707
 708
 709
 710
 711
 712
 713
 714
 715
 716
 717
 718
 719
 720
 721
 722
 723
 724
 725
 726
 727
 728
 729
 730
 731
 732
 733

3.1 Dimensional drawings

fig. 11 Dimensions




Table 10 Dimensions, internal impulse (1)


	0150 (2)		0160 (2)		0170 (2)		0180 (2)	
A	155		154		231		232	
	(6.10)		(7.54)		(9.09)		(9.13)	
B	76		121		189		188	
	(3.07)		(4.78)		(7.49)		(7.47)	
C	190	171	171	241	241	300	450	
	(7.48)	(6.73)	(6.73)	(9.49)	(9.49)	(11.81)	(17.72)	
D	71		94		105		140	
	(2.80)		(3.70)		(4.13)		(5.51)	
E	272		417		478		478	
	(10.71)		(16.42)		(18.74)		(18.74)	
height	11	11	14	21	25	31	38	
	(4.29)	(4.29)	(4)	(8.3)	(1)	(12.1)	(15.1)	

(1) All dimensions in mm (inch, see fig. 9)

(2) C = fitting length, but fitting lengths are available for meter sizes 0150 (2") to 0170 (4")

E.7 Internal terminal assignment

Fig. 78 Terminal assignment



2.2 Installation examples

Fig. 15 Battery connection

FLOW51C500 with LF output connected to electronic volume controller (both battery powered and intrinsically safe)




Fig. 10. Comparison with safety barrier and external JWB design.

FLOW3IC500 with HF output powered with safety battery and external power supply, connected to electronic voltage converter







Fig. 21 Selection with external power supply (intimately safe)

FLWSIC530 intimately powered (IS) and connected to electronic volume controller, RS485 externally powered



5.3 Connection diagrams for operation of the FLOWSIC500 in accordance with CSA

Fig. 32 Circuit diagram F02LF005 (page 3)






Fig. 88. Control diagram of the engine




Fig. 37 Control Diagram 5510000 (page 2)




Fig. 50 Control diagram 92.5386 (page 2)





Fig. 31. Control system 82-1998, page 31







Fig. 95: Control diagram 5022888 (page 1)



www.endress.com

www.addresses.endress.com
